

MCE



TORQMAX F5 ELEVATOR DRIVE

Version 1.71



Mat. No.	Rev.
00PC0UB-K171	1B

1. General	9	5. Initial Start-up	54
1.2 Model number information.....	10	5.1 Selecting The Configuration.....	54
1.3 Mounting instructions	11	5.2 Loading The Configuration.....	54
1.3.1 Classification	11	5.3 Setting The Control Type.....	55
1.3.2 Physical Mounting	11	5.4 Entering The Operating Data	55
1.3.3 Harsh Environments	11	5.5 Induction Motors	55
1.4 Electrical connections	12	5.5.1 Motor Overload	55
1.4.4 Ambient Conditions.....	12	5.5.2 Induction Motor Data.....	56
1.4.1 Safety First	12	5.5.3 Auto-Tuning Induction Motors.....	56
1.4.2 Voltage Supply.....	12	5.6 PM Synchronous Motors	58
1.4.3 Disconnect switch	13	5.6.1 Motor Overload	58
1.4.4 Fusing	13	5.6.2 Motor Data.....	58
1.4.5 Line Chokes.....	15	5.6.3 Auto-Tuning PM motors	59
1.4.6 Motor Thermal Protection.....	15	5.7 Machine Data	60
1.4.7 Motor Cable Length	15	5.8 Encoder Feedback	61
1.4.8 High Voltage Connections.....	16	5.8.1 Encoder card verification	61
1.4.9 Ground Connections	16	5.8.2 Encoder serial com. verification	62
1.4.10 High Frequency Shielding	17	5.8.3 Loading motor data from encoder	62
		5.8.4 Other encoder adjustments.....	63
2. Technical Data	18	5.9 Controller Settings	63
2.1 Technical data 230V (size 13 to 21)	18	5.10 Speed and Profile Settings	63
2.2 Technical Data 480V (Size 13 to 19).....	20	5.11 Running the Motor	64
2.2 Technical Data 480V (Size 20 to 26)	22	5.11.1 Stationary Pole Identification (SPI).....	64
2.3 Dimensions and weight	23	5.11.2 Absolute Encoder Setup (no ropes)	66
2.4 Summary of the power circuit terminals	24	5.11.3 Absolute Encoder Setup (with ropes)	68
2.5 Connection of the power circuit.....	25	5.11.4 Absolute Encoder Position Verification.....	70
2.6 Time dependent overload curve	27	5.11.5 Encoder Synchronization	71
2.7 Low Speed Overload	28	5.12 High Speed Tuning	72
		5.12.1 System Inertia Learn	72
3.0 Installation and Connection	29	5.12.2 Feed Forward Torque Control, FFTC	73
3.1 Control Circuit	29	5.12.3 Speed Gain Adjustment	74
3.1.1 Terminal Strip Connections.....	29	5.12.4 Synthetic Pre-Torque.....	78
3.1.2 Connection of the control signals.....	30	5.13 Function Test	80
3.1.3 Digital Inputs	30	5.13.1 Over Speed Function Test.....	80
3.1.4 Analog Inputs	30		
3.1.5 Voltage Input / External Power Supply	31	6. Parameter Description	81
3.1.6 Digital Outputs	31	6.1 US-Parameters	81
3.1.7 Relay Outputs.....	31	Password.....	81
3.1.8 Analog Outputs.....	31	Load defaults	81
3.1.9 Voltage Output.....	31	Load configuration.....	81
3.2 Encoder Connections	32	Select configuration	81
3.2.1 X3A RS422/TTL Incremental Encoder Input.....	32	Other US parameters	82
3.2.2 X3A TTL Inc. Enc. In Screw Terminals.....	34	6.2 LF-Elevator Parameters	83
3.2.3 X3A Hiperface Encoder	36	Signal / operating mode.....	83
3.2.4 X3A EnDat Encoder	40	Drive configuration.....	89
3.2.5 X3A SIN/COS-SSI Encoder	44	Selected motor.....	90
3.2.6 X3B Incremental Encoder Output	48	Drive fault auto reset.....	90
		Electronic motor overload protection.....	91
4. Operation of the unit	50	Electronic motor overload current	92
4.1 Digital Operator	50	Rated motor power	93
4.2 Parameter Identification.....	51	Rated motor speed	93
4.3 Parameter Selection	51	Rated motor speed	94
4.4 Changing Parameter Values	52	Rated motor current	94
4.5 Parameter Structure	52	Rated motor frequency	94
4.6 Saving Parameter Values	53	Rated motor voltage.....	95
4.7 Error Messages.....	53	Power factor	95
		Field weakening speed.....	96
		Rated motor torque	97
		PM motor resistance	98
		PM motor inductance	98
		Contract speed	99
		Traction sheave diameter.....	99
		Gear reduction ratio	99
		Roping ratio	100
		Load weight.....	100

Table of Contents

Estimated gear reduction	100	Over temperature cooled down	133
Encoder interface	101	Motor over temperature.....	133
Encoder pulse number.....	107	Over speed	133
Encoder channel swap / direction.....	107	DC Bus charging error	133
Encoder sample time	107	Encoder signal loss	133
Control Mode	108	Encoder communication error	134
Kp speed accel.	109	Power unit code	134
Kp speed decel.	109	Power unit code changed	134
Kp speed pretorque.....	109	Error current check	134
Ki speed accel.....	109	External Fault.....	134
Ki speed decel.	109	Encoder card invalid	134
Ki speed pretorque	109	Electronic motor overload.....	135
Ki speed offset accel.....	110	Bus com. fault.....	135
Ki speed offset decel.....	110	Base block time	135
Maximum torque.....	110	No Power Unit.....	135
Max. torque emergency oper.	110	Error calculate drive data.....	135
Open loop torque boost.....	111	Inverter status	136
Switching frequency	111	7.0 Run Parameters	137
Leveling speed, S_L	112	Inverter state	137
High speed, S_H	112	Set speed	137
Inspection speed, S_I	112	Command speed	137
High leveling speed, S_{HL}	112	Actual output frequency	137
Earthquake speed, S_{EQ}	113	Actual speed value	137
Emergency gen. speed, S_{EG}	113	Encoder 1 speed.....	137
Intermediate speed, S_{INT}	113	Encoder 2 speed.....	137
Over Speed Function Test.....	113	Commanded torque.....	138
Starting jerk	114	Actual torque.....	138
Acceleration	114	Actual load	138
Acceleration jerk.....	115	Peak load.....	138
Deceleration jerk.....	115	Phase current.....	138
Deceleration	115	Peak current.....	138
Approach jerk	115	Torque current	138
Stop jerk	115	DC bus voltage	138
Recommended Profile Settings.....	118	Peak DC bus voltage	138
Speed following error.....	119	Output voltage	139
Speed difference.....	119	Input terminal state	139
Following error timer.....	119	Input terminal state	139
Emergency operation mode	120	Output terminal state	139
Pre-torque gain	121	Output flag state.....	140
Pre-torque offset.....	121	Output status	140
Pre-torque direction	121	Active parameter set	140
Speed pick delay	122	Analog pattern raw	140
Brake pick delay	122	Analog pattern processed	140
Encoder resolution multiplier.....	123	Analog pre-torque raw	141
Absolute encoder position	123	Analog pre-torque processed.....	141
Brake engage time.....	124	Analog option raw	141
Current hold time.....	124	Analog option processed	141
Software version.....	125	Analog Out 1 preamp	141
Software date	125	Analog Out 1 post-amp.....	141
X2A Input state	126	Analog Out 2 preamp	141
X2A Output state	128	Analog Out 2 post-amp	141
Operation phase	128	Motor pot value.....	141
Inverter load	129	Power module temperature.....	142
Motor command speed	129	Overload counter.....	142
Actual motor speed.....	129	Power on counter	142
Actual elevator speed.....	129	Run counter	142
Phase current.....	130	Modulation grade.....	142
Peak phase current	130	Timer 1.....	142
Actual DC voltage.....	130	Timer 2.....	142
Peak DC voltage	130	Actual switching frequency	142
Actual output frequency	130	Motor temperature	142
Last fault	130	Position counter	142
6.3 Error Messages and Their Cause	132	Active Motor Power	143
Under voltage.....	132	Peak Motor Speed	143
Over voltage	132	Magnetizing Current.....	143
Over current	132	8.0 Advanced Adjustments	144
Overload	132	Comm error para address.....	144
Low speed overload	132	Comm error para data	144
Cool down phase completed.....	132	E.OL2 function.....	144
Inverter overheat.....	133	Pre-torque timer ramp up.....	145

Pre-torque timer ramp down.....	145
Max. speed for max. KI.....	146
Speed for min KI.....	146
Speed dependent KP gain.....	147
Min KP gain at high speed.....	147
KD speed gain.....	147
Phase current check.....	148
Power unit code.....	149
Analog input noise clamp.....	149
HSP5 Watchdog time.....	149
E.dOH function.....	150
Analog pattern gain.....	150
Reference splitting.....	150
Function Test.....	150

9.0 Output Configuration 152

9.1 Digital Output Parameters.....	152
Output X2A.24..26.....	152
Output X2A.27..29.....	152
9.2 Timing Graph - Analog Control.....	154
9.3 Timing Graph - Digital Control.....	156

10.0 Advanced Drive Data 159

10.1 Elevator Drive Data.....	159
Field weakening corner.....	159
Field weakening curve.....	159
Stator resistance.....	160
Sigma inductance.....	160
Rotor resistance.....	160
Magnetizing inductance.....	160
Motor control.....	160
Vmax regulation.....	161
KP current.....	161
KI current.....	161
Acceleration torque.....	161
System inertia.....	161
FFTC filter.....	161
FFTC gain.....	161
Torque command filter.....	161

11.0 Position Control..... 162

11.1 Position Control.....	162
Position Control.....	162
Min. slowdown dist.....	162
Slowdown distance.....	162
Correction distance.....	163
Current position.....	165
Scaling increments high.....	165
Scaling increments low.....	165
Scaling distance.....	165

12.0 Trouble Shooting..... 166

12.1 Operation Problems.....	166
12.2 Drive Faults.....	170
A.1 Parameter List Reference.....	173
A.2 Customer Parameter Values.....	177

This page left blank.



Danger to Life

AC motor controls and servo drives contain dangerous voltages which can cause death or serious injury. During operation they can have live "energized" un-insulated live parts, moving parts, as well as hot surfaces. Care should be taken to ensure correct and safe operation in order to minimize risk to personnel and equipment.



Only Qualified Personnel

All work involving this product, installation, start up as well as maintenance may only be performed by qualified electrical technical personnel. According to this manual "qualified" means: those who are able to recognize and acknowledge the possible dangerous conditions based on their training and experience and those who are familiar with the relevant standards and installation codes as well as the field of power transmission.



Protect Against Accidental Contact

AC motor controls and servo drives must be protected against physical damage during transport, installation, and use. Components or covers must not be bent or deformed as this may decrease insulation distances inside the unit resulting in an unsafe condition. On receipt of the unit visual damage should be reported immediately to the supplier. **DO NOT ATTEMPT TO POWER UP A UNIT WITH VISIBLE PHYSICAL DAMAGE.** This unit contains electrostatically sensitive components which can be destroyed by in correct handling. For that reason, disassembly of the unit or contact with the components should be avoided.



Note Capacitor Discharge Time

Before any installation and connection work can be done the supply voltage must be turned off and locked out. After turning off the supply voltage, dangerous voltages may still be present within the unit as the bus capacitors discharge. Therefore it is necessary to wait 5 minutes before working on the unit after turning off the supply voltage.



Secure Isolation

The low voltage control terminal strip and communication ports are securely isolated in accordance with EN50178. When connecting to other systems, it is necessary to verify the insulation ratings of these systems in order to ensure the EN requirements are still met. When connecting the unit to a grounded delta power system, the control circuit can no longer be classified as a "securely isolated circuit".

Before putting the motor control into operation be sure the connection terminals are tight and all covers removed for installation have been replaced.



Damage to Property and Injury to Persons

The AC motor control or servo system can be adjusted to self initiate an automatic restart in the even of a fault or error condition. The design of the system must take this into account, such that personnel are safe guarded against potentially dangerous circumstances.



Redundant Safety Mechanisms

Software functions in the AC motor control or servo system can be used to control or regulate external systems. However, in the event of failure of the motor control or servo system there is no guarantee these software function(s) will continue to provide the desired level of control. As a result, when operator or machine safety is at stake, external elements must be used to supplement or override the software function within the AC motor control or servo system.

This page left blank.

1. General

1.1 Product description

In selecting the TORQMAX F5 Elevator Drive, you have chosen a frequency inverter with the highest quality and dynamic performance.


The TORQMAX F5 inverter has the following features:

- small mounting footprint
- large die IGBTs
- power circuit gives low switching losses
- low motor noise with high carrier frequency
- extensive protection for over-current, voltage and temperature
- voltage and current monitoring in static and dynamic operation
- short circuit proof and ground-fault proof
- noise immunity in accordance with IEC1000
- hardware current regulation
- integrated temperature controlled cooling fan
- PM motor control capable
- Synthesized-pre torque for roll back compensation
- CE compliant and cULus listed
- extensive functional capabilities
- DPC - Direct Position Control


This manual describes the frequency inverter COMBIVERT F5.

- 10 hp...60 hp 270A peak / 230V class
- 10 hp...175 hp 450A peak / 480V class

CPU Software version 4.0 or greater
Application Software Version 1.71



It is exclusively designed for smooth speed regulation of a three-phase motor.




The operation of other electrical loads is forbidden and can lead to destruction of the unit.

General

1.2 Model number information

Part Number

15.F5.A1G-RP00



1.3 Mounting instructions


1.3.1 Classification



- The elevator drive is classified as an "Open Type" inverter with an IP20 rating and is intended for "use in a pollution degree 2 environment." The unit must be mounted inside of a control cabinet offering proper environmental protection.

1.3.2 Physical Mounting

- Install the inverter in a stationary location offering a firm mounting point with low vibration.
- Installation of the inverter on moving system may require special earth ground connections to the inverter.
- For best high frequency grounding, install the inverter on a bare metal sub-panel, i.e. zinc plated steel or galvanized steel.
- Take into consideration the minimum clearance distances when positioning the inverter (see drawing below). The F5 series inverters are designed for vertical installation and can be aligned next to each other. Maintain a distance of at least 2 inches in front of the unit. Make sure cooling is sufficient.



1.3.3 Harsh Environments

- For extended life, prevent dust from getting into the inverter.
- When installing the unit inside a sealed enclosure, make sure the enclosure is sized correctly for proper heat dissipation or that a cooling system has been installed in the panel.



- Protect the inverter against conductive and corrosive gases and liquids. Water or mist should not be allowed into the inverter.
- The F5 elevator drive inverter must be installed in an explosion-proof enclosure when operating in an explosion-proof environment.

1.3.4 Ambient Conditions



- Maximum Surrounding Air Temperature 45°C!** The operating temperature range of the unit is -10°C to + 45°C (14° to +113°F). Operation outside of this temperature range can lead to shut down of the inverter.
- The unit can be stored (power off) in the temperature range -25°C to 70°C (-13 to +158°F). After prolonged storage, one half year or more, apply voltage to the inverter for 2 hours before operating the motor. This will allow the electrolytic bus capacitors to stabilize before use and result in longer lifetime of the unit.
- The power rating of the inverter must be derated for operation above 3,300 ft (1000 m). Reduce the rated power 1% for each additional 330 ft (100 m). The maximum elevation for operation is 6,560 ft (2000 m)
- The relative humidity shall be limited to 95% without condensation.

1.4 Electrical connections

1.4.1 Safety First



- CAUTION - RISK OF ELECTRIC SHOCK!** Always disconnect supply voltage before servicing the F5 Elevator Drive.
- After disconnecting the supply voltage, always wait 5 minutes before attempting to change the wiring. The internal DC BUS capacitors must discharge.

1.4.2 Voltage Supply

- Pay attention to the supply voltage and be sure the supply voltage matches that of the inverter. A 230V unit can be supplied with voltage in the range 180 to 260VAC +/-0%, for a 480V unit the range is 305 to 500VAC +/- 0%, 48Hz to 62 Hz.
- All 240V models are suitable for use on a circuit capable of delivering not more than ___ kA rms symmetrical amperes, 240 volts maximum when protected by class ___ fuses rated ___ Amperes as specified in table 1.4.4.1 or when protected by a circuit breaker having an interrupt rating not less than ___ kA rms symmetrical amperes, 240V maximum, rated ___ amperes as specified in table 1.4.4.1.
- All 480V models are suitable for use on a circuit capable of delivering not more than ___ kA rms symmetrical amperes, 480 volts maximum when protected by class ___ fuses rated ___ Amperes as specified in table 1.4.4.2 or when protected by a circuit breaker having an interrupt rating not less than ___ kA rms symmetrical amperes, 480V maximum, rated ___ amperes as specified in table 1.4.4.2.



- Connection of the F5 series inverters to voltage systems configured as a corner grounded delta, center tap grounded delta, open delta, or ungrounded delta, may defeat the internal noise suppression of the inverter. Increased high frequency disturbance in the controller and on the line may be experienced. A balanced, neutral grounded wye connection is always recommended. The three phase voltage imbalance must be less than 2% phase to phase. Greater imbalance can lead to damage of the inverter's power circuit.

1.4.3 Disconnect switch

- A disconnect switch or contactor should be provided as a means of turning off the supply voltage when the unit is not in use or when it must be serviced.
- Repetitive cycling on and off of the input supply voltage more than once every two minutes can lead to damage of the inverter.

1.4.4 Fusing



- Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the Manufacturer Instructions, National Electrical Code (NFPA70 or CSA22.1) and any additional local codes.
- For UL relevant installations, branch circuit protection for the F5 must be provided using the devices as listed in the tables 1.4.4.1 and 1.4.4.2 below. The class RK5 fuses are recommend as they are widely available. As an Example, use BUSSMANN type FRS-R for 480V or FRN-R for 230V. Other manufacturers' class RK5 fuses are also acceptable.
- The minimum voltage rating for protection devices used with 230V inverters shall be 250VAC. The minimum voltage rating for protection devices used with 460V inverters shall be 600VAC.

Table 1.4.4.1 - 230V Units

Unit Size / Housing	SCCR [kA] rms	UL 248		Semiconductor	UL 489
		TYPE RK5 Rating [A]	TYPE L Rating [A]	Fuse Number ¹⁾ / Rating [A]	MCCB [A] / Siemens Cat. No.
13 / E	10	40	--	50 140 06 80 / 80	
14 / G	10	50	--	50 140 06 100 / 100	
15 / G , H	10	70	--	50 140 06 80 / 80	70A / DG-frame 3VL 70 UL ²⁾
16 / H	10	90	--	--	100A / DG-frame 3VL 100 UL ²⁾
17 / H	10	110	--	--	150A / DG-frame 3VL 150 UL ²⁾
18 / R	100	125	--	--	150A / DG-frame 3VL 150 UL
19 / R	100	150	--	--	150A / DG-frame 3VL 150 UL
20 / R	100	175	--	--	250A / FG-frame 3VL 250 UL
21 / R	100	200	--	--	250A / FG-frame 3VL 250 UL

1) Semiconductor fuses are manufactured by Siba Fuse Inc. When using this type of fuse, this is the model number of the fuse is the fuse that must be used.

2) Only for non-UL relevant installations

Table 1.4.4.2 - 480V Units

Unit Size / Housing	SCCR [kA] rms	UL 248		Semiconductor Fuse Number ¹⁾ / Rating [A]	UL 489 MCCB [A] / Siemens Cat. No.
		TYPE RK5 Rating [A]	TYPE L Rating [A]		
13 / E	10	25	--	50 140 06 40 / 40	
14 / E	10	30	--	50 140 06 50 / 50	
14 / G	10	30	--	50 140 06 80 / 80	
15 / E	10	40	--	50 140 06 80 / 80	
15 / G, H	10	40	--	50 140 06 40 / 40	40A / DG-frame 3VL 40 UL ²⁾
16 / G, H	10	50	--	50 140 06 63 / 63	70A / DG-frame 3VL 70 UL ²⁾
17 / G, H	10	60	--	50 140 06 80 / 80	70A / DG-frame 3VL 70 UL ²⁾
18 / H	10	70	--	50 140 06 80 / 80	100A / DG-frame 3VL 100 UL ²⁾
19 / H	10	90	--	50 140 06 100 / 100	100A / DG-frame 3VL 100 UL ²⁾
19 / R	100	90	200	--	150A / DG-frame 3VL 150 UL
20 / H	10	100	--	--	100A / DG-frame 3VL 100 UL ²⁾
20 / R	100	100	250	--	150A / DG-frame 3VL 150 UL
21 / R	100	150	300	--	150A / DG-frame 3VL 150 UL
22 / R	100	175	400	--	150A / DG-frame 3VL 150 UL
23 / R,U	100	200	500	--	250A / FG-frame 3VL 250 UL
24 / R,U	100	225	600	--	250A / FG-frame 3VL 250 UL
25 / U	100	275	700	--	400A / JG-frame 3VL 400 UL
26 / U	100	300	800	--	400A / JG-frame 3VL 400 UL
27 / U	100	350	1000	--	400A / JG-frame 3VL 400 UL
28 / U	100	400	--	--	400A / JG-frame 3VL 400 UL

1) Semiconductor fuses are manufactured by Siba Fuse Inc. When using this type of fuse, this is the model number of the fuse is the fuse that must be used.

2) Only for non-UL relevant installations

- Fuses shall not be installed between the drive and the motor.
- In PM motor applications where the drive input current can be lower than the output current, it is allowed to use a protection device with a lower current rating thus being able to optimize line side wiring and ancillary components.
- In the event a drive isolation transformer is installed, the maximum fuse rating on either the primary or secondary side of the transformer shall be no greater than 125% of the respective rated primary or secondary current of the transformer as defined in article 450-3 of NFPA 70. Use this value even if it is lower than the value specified in tables 1.4.4.1 or 1.4.4.2.



1.4.5 Line Chokes



- A line choke with minimum 3% impedance is required for all 230 V inverters 50hp (size 20) and greater. A line choke with minimum 3% impedance is required for all 480V inverters 100hp (size 23) and greater.
- Installation of a line choke is recommended and can be used prevent nuisance errors and protection caused by voltage spikes. Additionally, the use of a line choke will double the operational lifetime of the DC bus capacitors in the unit.

1.4.6 Motor Thermal Protection

- The F5 series inverters are UL approved as a solid state motor overload protection device. It is necessary to adjust the current trip level in parameter LF.9 or LF.12. The function assumes the use of a non-ventilated motor. The function meets the requirements set forth in VDE 0660 Part 104, UL508C section 42, NFPA 70 Article 430 part C. See the description for parameter LF.9 for the trip characteristics.
- A motor winding sensor can also be used for additional safety and the highest level of protection. Either a normally closed contact (rating: 15V / 6mA) or a PTC (positive temperature coefficient) resistor can be connected to the T1, T2 terminals on the inverter. The thermal device should be connected as indicated on page 24.

1.4.7 Motor Cable Length

- In some conventional installations and many MRL applications, the motor can be a considerable distance (greater than 40 feet) from the elevator drive. Under these circumstances the long cable length can cause high voltage peaks or high dv/dt (rate of voltage rise) on the motor windings. Depending on the design of the motor, these can lead to damage of the motor winding. Therefore, in these installations use of a special dv/dt filter is highly recommended.
- The standard approved solution is special output choke designed for use with the a maximum of 16kHz switching frequency and low inductance so as not to drastically influence the motor's equivalent circuit model.
- There are three sizes available for motors rated up to 136A. The part numbers and current ratings are listed below.

<u>Part Number</u>	<u>Rated Current</u>
16DRC08-3242	22A
15Z1F04-1005	22A (available 4th qtr 2010)
17Z1F04-1005	42A
21Z1F04-1005	100A (available 4th qtr 2010) Alternate (U090290-7501)

- The use of a conventional line or motor choke on the output of the drive is not recommend since the inductance value is high enough that it would distort the values in the motor model and result in poor control of the motor.

1.4.8 High Voltage Connections

- Always note inverter voltage, select appropriate over current protection devices, select disconnect device, and select proper wire size before beginning the wiring process. Wire the drive according to NFPA 70 Class 1 requirements.
- The correct wire gauge for each size inverter can be selected from the charts on pages 18-22. The wire gauge is based on the maximum fuse rating for the inverter. The terminal tightening torque can be found for each unit in the same charts.
- Always use UL listed and CSA approved wire. Use 60/75°C copper conductors only for equipment rated 100 Amperes or less and use 75°C Copper Conductors only for equipment rated greater than 100 Amperes! Use minimum 300V rated wire with 230V systems and minimum 600V rated wire with 480V systems.
- To prevent coupling high frequency noise, the following wires must be spatially separated from each other a minimum distance of 8 inches (20 cm) when they are laid parallel to each other :
 - AC supply power and motor lines not connected to inverters
 - motor lines connected to inverters
 - control and data lines (low-voltage level < 48 V)
- When using EMI filters, use only the wire provided with the filter to connect the filter to the inverter. Do not add additional wire between the filter and the inverter as this will have a negative effect on the operation of the filter.

1.4.9 Ground Connections

- When working with high frequencies (> 1kHz) and power semiconductors it is recommended to make all ground connections with large exposed metal surfaces in order to minimize the ground resistance.
- The metal sub-plate the inverter is mounted on is regarded as the central ground point for the machine or the equipment. For best results use an unpainted, galvanized or plated sub-panel.
- An additional high frequency ground wire should be connected between the inverter and the sub-panel. Use a stranded wire equal in size to the main line conductor or a thick ground strap. This is in addition to the ground wire required by NFPA 70, UL 508, CSA 22.1
- All ground connections should be kept as short as possible and as close as possible to the ground system, sub-panels.
- If other components in the system exhibit problems due to high frequency disturbances, connect an additional high frequency ground wire between them and the sub-panel.
- The EMI filter should be mounted to the drive or as close as possible to the inverter and on the same sub-panel as the inverter. Good metallic surface contact to the sub-panel is required to provide adequate high frequency grounding of the filter.

1.4.10 High Frequency Shielding

- Use of shielded cable is recommended when high frequency emissions or easily disturbed signals are present. Examples are as follows:
 - motor wires: connect shield to ground at both the drive and motor, NOTE the shield should never be used as the protective ground conductor required by NFPA70 or CSA22.1. Always use a separate conductor for this.
 - digital control wires: connect shield to ground at both ends.
 - analog control wires: connect shield to ground only at the inverter.

- The connection of meshed shields to the ground connection should **not** be done through a single strand or drain wire of the shield, but with metallic clamps to provide 360° contact around the surface of the shield to the ground point. Connection with a single wire from the braided shield reduces the effectiveness of the shield 70%. Metal conduit clamps work well for this. Be sure the fit is tight.
- Ridged metal conduit can be used as the shield of the motor wires. Always observe the following points :
 - remove all paint from the control cabinet and motor housing where the conduit is fastened
 - securely fasten all conduit fittings
 - run only the motor wires through the conduit, all other wires, high voltage AC and low voltage signal, should be pulled through a separate conduit.
 - connect the control panel to the Sub-panel with a heavy ground strap.
- If EMI filters are used, they should be mounted to the inverter or as close as possible to the inverter and on the same sub-panel as the inverter. Good metallic surface contact to the sub-panel is required to provide adequate high frequency grounding of the filter. Always use the shielding plate provided with the filter when connecting the filter to the inverter.
- Shielding of control wires:

If digital signal wires are terminated on a terminal block in the control panel, the shields should be firmly connected to the sub-panel on both sides of the terminal block.

The shields of digital signal wires originating outside the control cabinet which are not terminated on a terminal block, must be connected to the sub-panel at the point where the cable enters the control panel and at the inverter.

If the shield is terminated to the sub-panel within 8 inches (20cm) of the inverter, then the shield no longer needs to be connected to the inverter.

When using un-shielded signal wires, they should always be installed as a twisted pair (signal and common).

Low voltage signal wires should cross high voltage wires at right angles.

2. Technical Data

2.1 Technical data 230V (size 13 to 21)

Inverter Size	13	14	15	16	17				
Recommended Motor Power [hp]	7.5	10	15	20	25				
Housing size	E	E	G	G	H				
Input Ratings									
Supply voltage [V]	180...260 ±0 (230 V rated voltage)								
Supply voltage frequency [Hz]	50 / 60 +/- 2								
Input phases	3	3	3	3	3				
Rated input current [A]	28	36	55	63	92				
Recommended wire gauge ¹⁾ [awg]	10	8	8	6	4				
Output Ratings									
Rated output power [kVA]	9.5	13	17	23	29				
Rated motor power [kW]	5.5	7.5	11	15	18.5				
Rated output current [A]	22	28	42	57	84				
Peak current (30 seconds) ²⁾ [A]	36	49.5	72	86	99	118	151	168	
Over current fault (E.OC) trip level [A]	43	59	86	104	118	142	181	201	
Output voltage [V]	3 x 0...V input (3 x 0...255V ²⁾)								
Output frequency [Hz]	Generally 0 to 1600Hz (limited by control board and carrier frequency)								
Rated switching frequency ³⁾ [kHz]	8	4	16	4	16	16	16	4	4
Maximum switching frequency [kHz]	16	16	16	8	16	16	16	16	16
Power loss at rated operation ⁴⁾ [W]	290	350	330	330	430	550	550	850	850
Stall current at 4kHz [A]	24	33	33	36	53	73	73	126	118
Stall current at 8kHz [A]	24	24	33	31	53	73	73	109	97
Stall current at 16kHz [A]	16.8	16.8	33	26	53	66	73	92	59
Braking Circuit									
Min. braking resistance[Ohm]	16	16	8.0	8.0	5.6	5.6	4.7		
Typ. braking resistance[Ohm]	27	20	20	13	13	10	7.0		
Max. braking current [A]	25	25	50	50	70	70	85		
Installation Information									
Max. shielded motor cable length ⁵⁾ [ft]	330	330			330		330		
Tightening torque for power terminals [in lb]	11	11			11		35		35
Environmental									
Max. heat sink temperature TOH [°C]	90°C / 194°F								
Storage temperature [°C]	-25...70 °C / -13...158°F								
Operating temperature [°C]	-10...45 °C / 14...113°F								
Housing design / protection	Chassis / IP20 / Pollution Degree 2								
Relative humidity	max. 95% without condensation								
Approvals									
Tested in accordance with...	EN 61800-3 /UL508C								
Standards for emitted interference	EN 55011 Class B / EN 55022 Class A								
Standards for noise immunity	IEC 1000-4-2 / -3 / -4 / -5/ -6								
Climatic category	3K3 in accordance with EN 50178								



The recommended motor rating is for 4/6 pole standard motors. When using motors with different numbers of poles, the inverter must be dimensioned based on the motor rated current. Contact the manufacturer for special frequency motors.

The power rating of the inverter must be de-rated for operation above 3,300 ft (1000 m). Reduce the rated power 1% for each additional 330 ft (100 m). The maximum elevation for operation is 6,560 ft (2000 m)

Inverter Size	18	19	20	21
Recommended Motor Power [hp]	30	40	50	60
Housing size	R	R	R	R
Input Ratings				
Supply voltage [V]	180...260 ±0 (230 V rated voltage)			
Supply voltage frequency [Hz]	50 / 60 +/- 2			
Input phases	3	3	3	3
Rated input current [A]	88	115	143	170
Recommended wire gauge ¹⁾ [awg]	3	1	2/O	3/O
Output Ratings				
Rated output power [kVA]	35	42	52	62
Rated motor power [kW]	22	30	37	45
Rated output current [A]	80	104	130	154
Peak current (30 seconds) ²⁾ [A]	150	172	217	270
Over current fault (E.OC) trip level [A]	162	207	270	315
Output voltage [V]	3 x 0...V input (3 x 0...255V ²⁾)			
Output frequency [Hz]	Generally 0 to 1600Hz (limited by carrier frequency)			
Rated switching frequency [kHz]	8	8	8	8
Maximum switching frequency ³⁾ [kHz]	16	16	16	16
Power loss at rated operation ⁴⁾ [W]	1020	1200	1400	1700
Stall current at 4kHz [A]	110	123	160	198
Stall current at 8kHz [A]	100	115	145	180
Stall current at 16kHz [A]	70	70	101	101
Braking Circuit				
Min. braking resistance [Ohm]	4.7	3.9	2.0	2.0
Typ. braking resistance [Ohm]	5.6	4.7	3.9	3.0
Max. braking current [A]	85	102	160	160
Installation Information				
Max. shielded motor cable length ⁵⁾ [ft]	165			
Tightening torque for power terminals [in lb]	53			
Environmental				
Max. heat sink temperature TOH [°C]	90°C / 194°F			
Storage temperature [°C]	-25...70 °C / -13...158°F			
Operating temperature [°C]	-10...45 °C / 14...113°F			
Housing design / protection	Chassis / IP20 / Pollution Degree 2			
Relative humidity	max. 95% without condensation			
Approvals				
Tested in accordance with...	EN 61800-3 /UL508C			
Standards for emitted interference	EN 55011 Class B / EN 55022 Class A			
Standards for noise immunity	IEC 1000-4-2 / -3 / -4 / -5/ -6			
Climatic category	3K3 in accordance with EN 50178			

- 1) The wire gauge is based on the maximum fuse rating, copper wire with a 75°C insulation rating, THHW or equivalent. If circuit protection is selected based on the actual input current, the wire size could be reduced.
- 2) This is the peak output current limited by hardware regulation. The software current control reserves 5% for closed loop regulation.
- 3) This is the maximum carrier frequency the power stage can support. The actual operating carrier frequency is adjusted and limited by the control card.
- 4) This is the power dissipation at the rated carrier frequency, rated voltage and rated load. Operation at reduced carrier frequencies or reduced load will decrease this value.
- 5) Max motor cable length when using shielded cable, KEB EMI filter, and the installation must conform to EN55011 / EN55022.

Technical Data

2.2 Technical Data 480V (Size 13 to 19)

Inverter Size	13		14		15		
Recommended Motor Power [hp]	7.5		10		15		
Housing size	E	G	E	G	E	G	H
Input Ratings							
Supply voltage [V]	305...500 ±0 (460 V Nominal voltage)						
Supply voltage frequency [Hz]	50 / 60 +/- 2						
Input phases	3		3		3		
Rated input current [A]	15.4		19.6		27.3		
Recommended wire gauge ¹⁾ [awg]	12		10		10		
Output Ratings							
Rated output power [kVA]	8.3		11		17		
Rated motor power [kW]	5.5		7.5		11		
Rated output current [A]	11		14		21		
Peak current (30 seconds) ²⁾ [A]	21.6	18	29.7	24.8	36		
Over current fault (E.O.C) trip level [A]	25.9	21.6	35.6	29.7	43.2		
Output voltage [V]	3 x 0...Vsupply						
Output frequency [Hz]	Generally 0 to 1600Hz (limited by carrier frequency)						
Rated switching frequency ³⁾ [kHz]	8	16	8	16	4	8	16
Maximum switching frequency [kHz]	16	16	16	16	16	16	16
Power loss at rated operation ⁴⁾ [W]	250	200	320	260	350	290	360
Stall current at 4kHz [A]	12	12	16.5	16.5	24	24	24
Stall current at 8kHz [A]	12	12	16.5	16.5	16	19	24
Stall current at 16kHz [A]	12	12	10	12	10	8.4	15
Braking Circuit							
Min. braking resistance [Ohm]	39	50	39	39	39	22	
Typ. braking resistance [Ohm]	100		85		56		
Max. braking current [A]	21	15	21	21	21	37	
Installation Information							
Max. shielded motor cable length ⁵⁾ [ft]	300				330		
Tightening torque for power terminals [in lb]	4.5	11	4.5	11	11	35	
Environmental							
Max. heat sink temperature TOH [°C]	90°C / 194°F						
Storage temperature [°C]	-25...70 °C / -13...158°F						
Operating temperature [°C]	-10...45 °C / 14...113°F						
Housing design / protection	Chassis / IP20 / Pollution Degree 2						
Relative humidity	max. 95% without condensation						
Approvals							
Tested in accordance with...	EN 61800-3 /UL508C						
Standards for emitted interference	EN 55011 Class B / EN 55022 Class A						
Standards for noise immunity	IEC 1000-4-2 / -3 / -4 / -5/ -6						
Climatic category	3K3 in accordance with EN 50178						



The recommended motor rating is for 4/6 pole standard motors. When using motors with different numbers of poles, the inverter must be dimensioned based on the motor rated current. Contact the manufacturer for special frequency motors.

The power rating of the inverter must be de-rated for operation above 3,300 ft (1000 m). Reduce the rated power 1% for each additional 330 ft (100 m). The maximum elevation for operation is 6,560 ft (2000 m)

Inverter Size	16		17		18		19	
Recommended Motor Power [hp]	20		25		30		40	
Housing size	G	H	G	H	H	R	H	R
Input Ratings								
Supply voltage [V]	305...500 ±0 (460 V Nominal voltage)							
Supply voltage frequency [Hz]	50 / 60 +/- 2							
Input phases	3		3		3		3	
Rated input current [A]	35		44		52		57	
Recommended wire gauge ¹⁾ [awg]	8		6		6		4	
Output Ratings								
Rated output power [kVA]	23		29		35		42	
Rated motor power [kW]	15		18.5		22		30	
Rated output current [A]	27		34		40		52	
Peak current (30 seconds) ²⁾ [A]	49.5		63		75		90	
Over current fault (E.OC) trip level [A]	59.4		75.6		90		108	
Output voltage [V]	3 x 0...Vsupply							
Output frequency [Hz]	Generally 0 to 1600Hz (limited by carrier frequency)							
Rated switching frequency ³⁾ [kHz]	8	16	4	8	8	16	8	8
Maximum switching frequency [kHz]	16	16	16	16	16	16	16	16
Power loss at rated operation ⁴⁾ [W]	310	490	360	470	610	850	540	750
Stall current at 4kHz [A]	33	42	42	42	60	50	60	60
Stall current at 8kHz [A]	21.5	33	21.5	42	50	50	54	60
Stall current at 16kHz [A]	9.5	20	-	25	30	40	36	27
Braking Circuit								
Min. braking resistance [Ohm]	25	22	25	22	13	9	13	9
Typ. braking resistance [Ohm]	39		28		22		16	
Max. braking current [A]	30	37	30	37	63	88	63	88
Installation Information								
Max. shielded motor cable length ⁵⁾ [ft]	330							
Tightening torque for power terminals [in lb]	11	35	11	35	53	35	53	
Environmental								
Max. heat sink temperature TOH [°C]	90°C / 194°F							
Storage temperature [°C]	-25...70 °C / -13...158°F							
Operating temperature [°C]	-10...45 °C / 14...113°F							
Housing design / protection	Chassis / IP20 / Pollution Degree 2							
Relative humidity	max. 95% without condensation							
Approvals								
Tested in accordance with...	EN 61800-3 / UL508C							
Standards for emitted interference	EN 55011 Class B / EN 55022 Class A							
Standards for noise immunity	IEC 1000-4-2 / -3 / -4 / -5/ -6							
Climatic category	3K3 in accordance with EN 50178							

1) The wire gauge is based on the maximum fuse rating, copper wire with a 75°C insulation rating, THHW or equivalent. If circuit protection is selected based on the actual input current, the wire size could be reduced.

2) This is the peak output current limited by hardware regulation. The software current control reserves 5% for closed loop regulation.

3) This is the maximum carrier frequency the power stage can support. The actual operating carrier frequency is adjusted and limited by the control card.

4) This is the power dissipation at the rated carrier frequency, rated voltage and rated load. Operation at reduced carrier frequencies or reduced load will decrease this value.

5) Max motor cable length when using shielded cable, KEB EMI filter, and the installation must conform to EN55011 / EN55022.

Technical Data

2.2 Technical Data 480V (Size 20 to 26)

Inverter Size	20		21		22		23		24		26	
Recommended Motor Power [hp]	50		60		75		100		125		175	
Housing size	H	R	R	R	R	R	U	U	U	U	U	U
Input Ratings												
Supply voltage [V]	305...500 ±0 (460 V Nominal voltage)											
Supply voltage frequency [Hz]	50 / 60 +/- 2											
Input phases	3	3	3	3	3	3	3	3	3	3	3	3
Rated input current [A]	72	86	105	150	189	254						
Recommended wire gauge ¹⁾ [awg]	4	3	1	2/O	3/O	350						
Output Ratings												
Rated output power [kVA]	52	62	80	104	125	173						
Rated motor power [kW]	37	45	55	75	90	132						
Rated output current [A]	65	77	96	136	172	231						
Peak current (30 seconds) ²⁾ [A]	135	112	135	172	230	225	270	375	450			
Over current fault (E.OC) trip level [A]	162	135	162	207	276	270	324	450	540			
Output voltage [V]	3 x 0...Vsupply											
Output frequency [Hz]	Generally 0 to 1600Hz (limited by control board and carrier frequency)											
Rated switching frequency ³⁾ [kHz]	4	8	8	8	8	8	8	8	4	4		
Maximum switching frequency [kHz]	16	16	16	16	16	8	8	8	12			
Power loss at rated operation ⁴⁾ [W]	900	1100	1500	1500	1900	1900	2400	2800	2800			
Stall current at 4kHz [A]	83	83	99	115	173	150	165	198	330	330		
Stall current at 8kHz [A]	83	75	81	115	150	150	150	180	180	225		
Stall current at 16kHz [A]	45	34	45	63	98	75	-	-	-	125 ⁵⁾		
Braking Circuit												
Min. braking resistance[Ohm]	9	9	9	5	4	4.0						
Typ. braking resistance[Ohm]	13	11	9	6	6	4.3						
Max. braking current [A]	88	88	88	160	200	200						
Installation Information												
Max. shielded motor cable length ⁵⁾ [ft]	165										165	
Tightening torque for power terminals [in lb]	35	53	133	133	220							
Environmental												
Max. heat sink temperature TOH [°C]	90°C / 194°F		°C	73°C	90°C	90°C	60°C					
Storage temperature [°C]	-25...70 °C / -13...158°F											
Operating temperature [°C]	-10...45 °C / 14...113°F											
Housing design / protection	Chassis / IP20 / Pollution Degree 2											
Relative humidity	max. 95% without condensation											
Approvals												
Tested in accordance with...	EN 61800-3 / UL508C											
Standards for emitted interference	EN 55011 Class B / EN 55022 Class A											
Standards for noise immunity	IEC 1000-4-2 / -3 / -4 / -5 / -6											
Climatic category	3K3 in accordance with EN 50178											

1) The wire gauge is based on the maximum fuse rating, copper wire with a 75°C insulation rating, THHW or equivalent. If circuit protection is selected based on the actual input current, the wire size could be reduced.

2) This is the peak output current limited by hardware regulation. The software current control reserves 5% for closed loop regulation.


3) This is the maximum carrier frequency the power stage can support. The actual operating carrier frequency is adjusted and limited by the control card.

4) This is the power dissipation at the rated carrier frequency, rated voltage and rated load. Operation at reduced carrier frequencies or reduced load will decrease this value.


5) Max motor cable length when using shielded cable, KEB EMI filter, and the installation must conform to EN55011 / EN55022.

2.3 Dimensions and weight


E Housing




G Housing




H Housing



R Housing




U Housing



Dimensions in inches

Housing	A	B	C	F	G	H
E	5.12	11.4	8.75	0.28	-	10.8
G	6.7	13.4	10.0	0.28	5.9	13.0
H	11.7	13.4	10.0	0.28	9.8	13.0
R	13.5	20.5	14.0	0.394	11.8	19.5
U	13.5	31.5	14.0	0.394	11.8	30.5


Mounting Holes




Power Circuit Terminals

2.4 Summary of the power circuit terminals


Housing size E ⚠️ Verify input voltage with name plate for proper connection 230V or 480V




- L1, L2, L3** 3 phase supply voltage
- ++, --** Connection for DC supply
- ++, PB** Connection for braking resistor
- U, V, W** Motor connection
- T1, T2** Connection for temperature sensor
-  Connection for earth ground

Terminal Tightening Torque: 4.5 inlbs (0.5Nm)


Housing size G ⚠️ Verify input voltage with name plate for proper connection 230V or 480V



- L1, L2, L3** 3 phase supply voltage
- ++, --** Connection for DC supply
- ++, PB** Connection for braking resistor
- T1, T2** Connection for temperature sensor
- U, V, W** Motor connection
-  Connection for earth ground

Terminal Tightening Torque: 11 inlbs (1.2Nm)

Housing size H ⚠️ Verify input voltage with name plate for proper connection 230V or 460V




- | | | | |
|-------------------|---------------------------------|----------------|-----------------------------------|
| L1, L2, L3 | 3 phase supply voltage | T1, T2 | Connection for temperature sensor |
| ++, -- | DC supply connection | U, V, W | Motor connection |
| ++, PB | Connection for braking resistor | PE | Connection for earth ground |

Terminal Tightening Torque: 35inlbs (4Nm)

Housing size R and U  **Verify input voltage with name plate for proper connection 230V or 460V**

Note always verify input voltage with name plate for proper connection



L1, L2, L3
+ +, - -
+ +, PB

3 phase supply voltage
DC supply connection
Connection for braking resistor

T1, T2
U, V, W


Connection for temperature sensor
Motor connection
Connection for earth ground M8 stud.

Note: Ground Stud and Nut shall be connected with UL Listed Ring Connectors (ZMVV), rated suitable.

Terminal Tightening Torque: R housings size <= 22: 53 inlb (6Nm)
R & U housings size 23/24: 133inlbs (15Nm)
U housings sizes > 24: 221inlbs (25Nm)
Ground nut on R & U housings: 89inlbs (10Nm)

2.5 Connection of the power circuit

See technical data on pages 18-22 to match the wiring diagram to inverter size and housing type.




If the supply voltage is connected to the motor terminals, the unit will be destroyed!




Pay attention to the supply voltage 230/460V and the correct polarity of the motor!

Wiring diagram 1




Wiring diagram 2



Connection of the Power Circuit

Wiring diagram 3




- | | |
|--|---------------------------------------|
| ① Supply fuse | ⑤ TORQMAX F5 |
| ② Disconnect switch or contactor | ⑥ Motor choke or output filter |
| ③ Line choke | ⑦ Motor |
| ④ Interference suppression filter | ⑧ Sub panel in control cabinet |

External motor temperature sensor (for all units)


Don't install sensor wires with control wires!

Must use double shield when running these wires with motor wires!

It is necessary to activate this function via software parameter! See US.33




Connection of braking resistor (Braking circuit installed as standard in housing sizes E,G,H, R and U.)



Braking resistor with line side over temperature cutoff



This is the only way to turn off voltage to the resistor in the event of failure of the internal braking transistor of the inverter.




24VDC or 120VAC contactor control voltage

Note: a NC thermal switch not PTC device on the resistor is required.


2.6 Time dependent overload curve

If the load current exceeds the rated current but is below the over current level, an overload timer begins counting. The rate at which the timer increments is a function of load current. The higher the current the faster the increments. When the counter reaches the limit the fault E.OL is triggered and the output to the motor is shut off. At this point the inverter begins a cool down period where the inverter is allowed to cool before the fault can be reset.

① Less than size 24




② Size 24 and greater



Overload Characteristic

2.7 Low Speed Overload (E.OL2)



At low speeds (below 3 Hz) the rms current flowing through the power transistors is higher, reaching 1.4 times the rated 60Hz rms value. This is caused by the low frequency sine wave created by the PWM. As a result, the continuous output current must be limited at low speeds to prevent the power transistors from overheating. The Torqmax F5 will drop the carrier frequency to 4kHz if necessary to be able to continue to provide current to the motor. Once the output frequency rises above 3Hz or the current drops below the levels listed below, the carrier frequency will be returned to the higher value.

230V Maximum stall current (amps at 0Hz)										
Inverter Housing	Carrier Frequency	Inverter Size								
		13	14	15	16	17	18	19	20	21
E	8 kHz	24	24							
	16 kHz	16.8	16.8							
G	8 kHz		33	31						
	16 kHz		33	26						
H	8 kHz			53	72.5	109				
	16 kHz			53	73	92				
R	8 kHz					84	100	115	145	180
	16 kHz					50	70	70	102	102

460V Maximum stall current (amps at 0Hz)															
Inverter Housing	Carrier Frequency	Inverter Size													
		13	14	15	16	17	18	19	20	21	22	23	24	26	26
E	8 kHz	12	17	17											
	16 kHz	12	10	10											
G	8 kHz	12	17	19	22.0										
	16 kHz	12	12	8.4	9.5										
H	8 kHz			24	33	42	50	54	83						
	16 kHz			15	20	25	30	36	45						
R	8 kHz						50	60	75	81	150				
	16 kHz						40	27	34	45	98				
U	4 kHz											165	198	330	330
	8 kHz											150	180	180	225
	16 kHz											-	-	-	-

X2A

3.1 Control Circuit

3.1.1 Terminal Strip Connections



PIN	Function	Name	Description	
1	Analog input 1 +	AN1+	Pattern speed input or torque command input resolution: 12 Bit scan time: 1 ms	
2	Analog input 1 -	AN1-		
3	Analog input 2 +	AN2+		
4	Analog input 2 -	AN2-		
5	Analog output 1	ANOUT1	Analog output of the real speed 0...±10 VDC (0...± 100 %)	Voltage range: 0...±10V Ri=100 kOhm, resolution: 12Bit
6	Analog output 2	ANOUT2	Analog output of the motor torque 0 ... 10 VDC (0 ... 2 x T _{Rated (motor)})	
7	+10V Output	CRF	Analog supply voltage for speed ref.	+10VDC +5%, max. 4 mA
8	Analog Common	COM	Common for analog in- and outputs	
9	Analog Common	COM	Common for analog in- and outputs	
10	Optional Function	OPT	Inputs 11,12,13 provide binary coded speed selection of up to 7 speeds. See parameter LF.2. With analog control (LF.2=R 5Pd or Rb5Pd)	Ri = 2.1 kOhm scan time: 1 msec digital filter reduces false trigger due to relay chatter. filter time: 20msec (adjustable)
11	Leveling Speed	S _L		
12	High Leveling Speed	S _{HL}		
13	High Speed	S _H	these inputs are not used!	
14	Up	U	Preset rotation;	
15	Down	D	"Up" has priority	
16	Drive Enable	ST	Enable/Disable; response time < 1msec; enable instantly turns off motor current	
17	Reset	RST	Clears a drive error (E.XXX)	
18	Digital Out 1	O1	At speed signal (turns off if the actual speed deviates from the set speed)	
19	Digital Out 2	O2	Fault signal (activates when there is a drive fault)	
20	24V-Output	V _{out}	Approx. 24V output (max.100 mA load)	
21	20...30V-Input	V _{in}	Voltage input when an external 24VDC supply is used	
22	Digital Common	0V	Common for digital in-/outputs	
23	Digital Common	0V	Common for digital in-/outputs	
24	RDY Relay	NO	Ready; relay drops when a drive fault occurs (E.XX).	
25		NC	Picks after fault is cleared with RST input or power cycle	
26	max. 30 V DC, 1 A	COM	See Parameter do.82	
27	DRO Relay	NO	Drive On; relay picks after all of the follow conditions are met:	
28		NC	enable picked, direction picked, motor phase current check passes.	
29	max. 30 V DC, 1 A	COM	Relay drops when one of the following occurs: enable dropped, direction dropped and actual speed is zero, drive fault (E.XX). See Parameter do.83	

Installation and Connection

3.1.2 Connection of the control signals


In order to prevent a malfunction caused by interference voltages on the control inputs, the following steps should be observed:




- Establish a true earth ground for all ground connections!
- Do not connect drive signal commons to earth ground!
- Use shielded cable with twisted pair wires!
- Terminate shield wires to earth ground, only at inverter!
- Separate control and power wires by 8" or more!
- Control and power wires should cross at a right angle!

3.1.3 Digital Inputs

Use of **internal** voltage supply




Use of **external** voltage supply



3.1.4 Analog Inputs


Speed Pattern, Torque Command




Connect unused analog inputs to common to eliminate noise signals!

3.1.5 Voltage Input / External Power Supply

The supply to the control circuit through an external voltage source keeps the control in operational condition even if the power stage is switched off. To prevent undefined conditions (false triggering), first switch on the power supply then the inverter.




3.1.6 Digital Outputs




3.1.7 Relay Outputs

In case of inductive loads on the relay outputs, protective wiring must be provided (e.g. RC or diode arc suppression)!




3.1.8 Analog Outputs



3.1.9 Voltage Output

The voltage output serves for triggering the digital inputs as well as for supplying external control devices. Do not exceed the maximum output current of 100 mA. This output is short circuit protected.



Installation and Connection


3.2 Encoder Connections

3.2.1 X3A RS422/TTL Incremental Encoder Input



ONLY when the inverter is switched off and the voltage supply is disconnected may the feedback connectors be removed or connected!

Connect the incremental encoder mounted on the motor to the 15-pin Sub-D connector at X3A on the COMBIVERT F5M. This connection provides speed feedback and is imperative to the proper operation of the F5.



The internal voltage of "V_{var}" 24...30 V ⁽¹⁾ is a unregulated supply and will allow up to 170 mA max. current draw, for X3A and X3B total. If higher voltages / currents are required, then an external power supply must be provided.

The +5.2 V is a regulated voltage supply generated from V_{var} and will allow up to 500 mA max. current draw, for X3A and X3B total. If additional current is required from the +5.2 V output, the current from V_{var} decreases in accordance with following formula:


$$I_{\text{var}} = 170 \text{ mA} - \frac{5.2 \text{ V} \times I_{+5\text{V}}}{V_{\text{var}}}$$

Pin No.	Signal
3	A-
4	B-
8	A+
9	B+
11	V _{var} 24...30 V
12	+5.2 V
13	0V (com)
14	N-
15	N+
Shield	Housing

The following specifications apply to encoder interface X3A and X3B, channel 1 and 2 respectively:

- Max. operating frequency: 300 kHz.
- Internal terminating resistance: R_t = 120 Ω
- RS422 or TTL level square wave voltage level: 2...5 Vdc

Input Wiring



1. Maximum Encoder voltage: +5.2 V

2. Encoder line number: 1...16383 ppr
2500 ppr is recommended and gives best speed resolution and regulation performance for applications with a maximum motor speed of up to 4500 rpm.

F5M Interface cutoff frequency: 300 kHz
Observe cutoff frequency of the encoder:

$$f_{\text{limit}} > \frac{g \cdot n_{\text{max}}}{60}$$


g = Encoder increments (ppr)

n = Encoder speed (rpm)

f = Encoder operating frequency (Hz)

3. Signal specifications:

Four signals consisting of two square-wave pulses that are electrically 90° out of phase and their inverse signals (TTL-push-pull signals / RS422-conformity). Minimum "on" voltage level is 2.0V and maximum "off" voltage level is 0.5V. The encoder must be electrically isolated from the motor shaft. Otherwise noise from the motor may corrupt the encoder signals.



4. Cable specifications: The encoder cable shall not be so long such that the voltage drop in supply voltage on the encoder cable results in a voltage less than the minimum encoder supply voltage. Typically encoder lines should not be longer than 160 ft (50 m). The following must be valid for trouble free operation.

$$[(I_{\text{Encoder}} \cdot R_{\text{Line}}) + V_{\text{Encoder (min)}}] < +5.2 \text{ V}$$

R_{Line} is the sum of the resistance of the supply wires both +V and com.

For maximum noise immunity, the encoder cable shall consist of individually shielded twisted pairs with one overall shield. The individual shields should be connected to 0V (com) pin 13 on the Sub D connector and be kept separate from the outer shield. The outer shield should be connected to earth ground, the housing of the Sub D connector.





The cable shall be kept a minimum of 8 inches (20 cm) away from all wires having greater than 24VDC on them. For best results run the encoder cable in a separate conduit from the controller to the motor.

Installation and Connection

3.2.2 X3A TTL Inc. Enc. In Screw Terminals



ONLY when the inverter is switched off and the voltage supply is disconnected may the feedback connectors be removed or connected!




Connect the incremental encoder mounted on the motor to the 8 position terminal connector at X3A. This connection provides speed feedback and is imperative to the proper operation of the F5M.

Plug in screw terminal X3A		1	2	3	4	5	6	7	8
Pos	Signal	Description							
1	A+	TTL incremental encoder track A							
2	A-	Differential signal to A+							
3	B+	TTL incremental encoder track B							
4	B-	Differential signal to B+							
5	N+	TTL Zero track							
6	N-	Difference signal to N+							
7	15/24V	Voltage output 15/20...30V, power supply for the encoder, switchable with dip switch S100							
8	COM	0V reference for voltage supply							
-	GND	connect the outer cable shield to an earth ground connection on the elevator drive .							


The following specifications apply to encoder interface X3A, channel 1

- Max. operating frequency: 300 kHz.
- Maximum cable length: 50m (164 ft) (RS422)
- Internal terminating resistance: $R_t = 120 \Omega$
- RS422 or TTL level square wave voltage level: 2...5 Vdc

Input equivalent circuit



Selection of the supply voltage



The maximum load capacity is dependant on the selected voltage supply.

Max. load capacity with 15V internal supply:300 mA

Max. load capacity with 24V internal supply:170 mA

Max. load capacity with an external 24V supply 1A (dependent on the external voltage source)

The specified currents are reduced by any current drawn on the second interface X3B.

Note: For 5V TTL encoders, a 5V supply is available on second interface, X3B terminal 7.

If the encoder has no zero channel, connect N+ to 5V and N- to com.

For maximum noise immunity, the encoder cable shall consist of individually shielded twisted pairs with one overall shield. The individual shields should be connected to 0V (com) pin 8 on the X3A terminal strip and be kept electrically isolated from the outer shield. The outer shield should be connected to earth ground on the elevator drive.



The cable shall be kept a minimum of 8 inches (20 cm) away from all wires having greater than 24VDC on them. For best results run the encoder cable in a separate conduit from the controller to the motor.

Installation and Connection

3.2.3 X3A Hiperface Encoder

The Hiperface encoder provides two differential analog channels for incremental position and one serial data channel for communication with the encoder. This serial data channel can provide the drive with the absolute position of the motor as well as other operating data.

The analog cosine and sine wave signals of tracks A and B have a voltage of 1 V_{pp} with an Offset of 2.5 V. This analog voltage is measured and a high resolution position value is determined as a result. This high resolution position value is very important for good speed control of a gearless motor.



Therefore it is absolutely necessary to ensure these signals are well shielded! Noise on the analog signals resulting from breaks in the shield or improper shield termination will result in vibration in the motor and poor ride quality.

The internal stored ppr value is compared to the adjusted value in LF.27. If the two are not the same the drive will trigger the error E.ENCC. Refer to parameter LF.26 for more information.


During start-up and then every 100 ms a request is transmitted to the encoder and the absolute position is read out via serial communication. This initial readout of the absolute position provides the drive with the commutation angle for permanent magnet motors. On the very first operation of a permanent magnet motor it is necessary to synchronize the encoder position to one of the pole pairs of the motor. See parameter LF.77 for more information and section 5.11.1.

During normal operation, the difference between the internal absolute position of the encoder and the measured position value in the drive is compared. If the two deviate by more than 2.8 degrees, the drive will trigger the error, E.ENCC. Refer to parameter LF.26 for more information.

Hiperface encoders also provide memory for the user to store a copy of the motor data. The drive supports the functionality to read and write the motor data to the encoder. See parameter LF.26 for more information.

If there is an excess length of cable (10 feet or less), it is OK to coil it into a loop in the controller. Maintain a minimum diameter of 1 foot and keep the cable at least 8 inches away from all high voltage power wires.

**Drive connection
X3A Female SUBD
15 HD**



Pin No	Signal Description
1	- -
2	- -
3	REF_COS signal input A- (difference signal to COS+)
4	REF_SIN signal input B- (difference signal to SIN+)
5	- -
6	- -
7	- -
8	COS+ signal input A (absolute track for counter and direction detection)
9	SIN+ signal input B (absolute track for counter and direction detection)
10	+7.5V Supply voltage for encoder
11	- -
12	- -
13	COM reference potential for supply voltage
14	-DATA Data channel RS485
15	+DATA Data channel RS485

Max. Load Capacity depending on Voltage Supply

Max. load capacity at +7.5 V:300 mA. The specified current is reduced by the load current taken from the second encoder interface X3B interface (see section 3.2.6).

HIPERFACE Cable

Pre-manufactured Hiperface cables offer the best solution against noise and disturbance while at the same time saving installation time. The cables come in standard lengths of 5m,10m,15m,20m, 25m, and 30m.

Cable Part Number

00.S4.809-00xx xx = length in meters, 10 = 10 meters



Mating Connector

00.90.912-003U for encoder (solder type)

Running in Conduit

When this cable must be pulled through metallic conduit, it is necessary to over size the conduit! Use of a 1 1/2 inch trade size conduit will allow the connectors to pass without removal of the connectors. Cutting the cable, or removal of the connectors or their housings voids the warranty and will result in problems with electrical noise after the fact.

Circular connector on HIPERFACE encoder.



Shield wire tied to housing Shield wire tied to housing which is earth ground.

Note: Inner pair shields are tied to 0V (com), pin 13, not earth ground!

Installation and Connection

Technical Data

Input resistance:	120 Ohm
Process data channel:	1Vpp
Parameter channel:	EIA RS485 half duplex
Maximum input frequency:	200 kHz
Encoder line number:	1024 inc
Maximum cable length:	<100 m <i>(based on signal levels, otherwise see below)</i>

Cable length based on cable resistance

The maximum cable length is calculated as follows:

$$\text{Length} = \frac{V - V_{\min}}{I_{\max} * R} = \frac{7.5V - 7.0}{0.2A * 0.07 \Omega/m} = 35.7 \text{ m}$$

where

I_{\max} = supply current of encoder [amps]

V = voltage supply of the drive = 7.5V

V_{\min} = minimum supply voltage of the encoder

R = cable resistance (0.07 Ω/m) for KEB cables)

The following Hiperface®-encoders have been tested for use:

- Stegmann SRS 50/60 Singleturn; SCS 60/70 Singleturn
- Stegmann SRM 50/60 Multiturn; SCM 60/70 Multiturn

However, this does not restrict the use of rotary encoder with same specifications of other manufacturers

Recognition of encoder loss or exchange

The recognition of encoder loss or exchange is a software function and dependent on the encoder type. If the drive senses that the serial communication to the encoder has stopped, it will trigger the error E.ENCC.




If the encoder is replaced or disconnected, the drive will trigger an error or warning that the encoder was changed. The drive will display the error message E.ENCC and lock out operation by changing LF.3 to configuration mode. No further operation is possible.

If the encoder was exchanged the drive will auto reset the E.ENCC fault but will remain in configuration mode because the user will need to learn the new encoder position before operation can continue. See section 5.11.1

If there is an encoder triggered fault or problems with the encoder cables, the E.ENCC error will not clear and the problems must be diagnosed through parameter LF.26. To clear the E.ENCC error, it is necessary to go to parameter 0.LF.26, press "Func" and then press "Enter".

Signals Format of the analog channels



Installation and Connection

3.2.4 X3A EnDat Encoder

The EnDat encoder provides two differential analog channels for incremental position and one serial data channel with clock for communication with the encoder. This serial data channel can provide the drive with the absolute position of the motor as well as other operating data. The EnDat encoder must be version 2.1 or greater for compatibility reasons.

The analog cosine and sine wave signals of tracks A and B have a voltage of 1 Vpp with an Offset of 2.5 V. This analog voltage is measured and a high resolution position value is determined as a result. This high resolution position value is very important for good speed control of a gearless motor.



Therefore it is absolutely necessary to ensure these signals are well shielded! Noise on the analog signals resulting from breaks in the shield or improper shield termination will result in vibration in the motor and poor ride quality.

The internal stored ppr value is compared to the adjusted value in LF.27. If the two are not the same the drive will trigger the error E.ENCC. Refer to parameter LF.26 for more information.

During start-up and then every 30 ms a request is transmitted to the encoder and the absolute position is read out via serial communication. This initial readout of the absolute position provides the drive with the commutation angle for permanent magnet motors. On the very first operation of a permanent magnet motor it is necessary to synchronize the encoder position to one of the pole pairs of the motor. See parameter LF.77 for more information and section 5.11.1.


During normal operation, the difference between the internal absolute position of the encoder and the measured position value in the drive is compared. If the two deviate by more than 2.8 degrees, the drive will trigger the error, E.ENCC. Refer to parameter LF.26 for more information.

ENDAT encoders also provide memory for the user to store a copy of the motor data. The drive supports the functionality to read and write the motor data to the encoder. See parameter LF.26 for more information.

The clock signal serves as synchronisation for the serial data channel.

If there is an excess length of cable (10 feet or less), it is OK to coil it into a loop in the controller. Maintain a minimum diameter of 1 foot and keep the cable at least 8 inches away from all high voltage power wires.

**Drive connection
X3A Female SUBD
15 HD**



Pin No	Signal Description
1	- -
2	- -
3	REF_COS signal input A- (difference signal to COS+)
4	REF_SIN signal input B- (difference signal to SIN+)
5	- -
6	+ CLOCK synch. signal for serial data
7	- CLOCK synch. signal for serial data
8	COS+ signal input A (absolute track for counter and direction detection)
9	SIN+ signal input B (absolute track for counter and direction detection)
10	- -
11	- -
12	+ 5V Supply voltage for encoder
13	COM Reference potential for supply voltage
14	-DATA Data channel RS485
15	+DATA Data channel RS485

Max. Load Capacity depending on Voltage Supply

Max. load capacity at +5.0V; 300 mA. The specified current is reduced by the current taken from the second encoder interface X3B interface (see section 3.2.6).

EnDat Cable

Pre-manufactured EnDat cables offer the best solution against noise and disturbance while at the same time saving installation time. The cables come in standard lengths of 5m, 10m, 15m, 20m, 25m and 30m.

Cable Part Number

00.F5.0C1-40xx xx = length in meters, 10 = 10 meters

For lengths above 30 m a different cable is used.

00.F5.0C1-L0xx xx = length in meters, 40 = 40 meters (NOTE: wire colors listed below change for the longer "L" cables. Consult the factory for wire colors)



Mating Connector

00.90.912-004U for encoder (solder type)

Running in Conduit

When this cable must be pulled through metallic conduit, it is necessary to over size the conduit! Use of a 1 1/2 inch trade size conduit will allow the connectors to pass without removal of the connectors. Cutting the cable, or removal of the connectors or their housings voids the warranty and will result in problems with electrical noise after the fact.

Circular connector on EnDat encoder.



Shield wire tied to housing
Note: Inner pair shields are tied to 0V (com), pin 13, not earth ground!
 Shield wires tied to housing which is earth ground.

Installation and Connection

Technical Data

Input resistance:	120 Ohm
Process data channel:	1Vpp
Parameter channel:	EIA RS485 half duplex
Clock signal output:	EIA RS485
Maximum input frequency:	200 kHz
Encoder line number:	1...2048 inc
Maximum cable length:	100 m <i>(based on signal levels, otherwise see below)</i>
Cable length based on cable resistance	

The maximum cable length is calculated as follows:

$$\text{Length} = \frac{V - V_{\min}}{I_{\max} * R} = \frac{5.25V - 4.75V}{0.2A * 0.003 \Omega/m} = 83.3 \text{ m}$$

where

I_{\max} = supply current of encoder [amps]

V = voltage supply of the drive = 5.25V

V_{\min} = minimum supply voltage of the encoder

R = cable resistance (0.07 Ω/m) for Standard KEB cables

(0.03 Ω/m) for type "L" KEB cables

The following ENDAT encoders have been tested for use:

- Heidenhain ECN 1313 single turn; ECI 1317 Singleturn
- HeidenhainROQ 425 Multiturn; EQI 1329 Multiturn

However, this does not restrict the use of rotary encoder with same specifications of other manufacturers

The recognition of encoder loss or exchange is a software function and dependent on the encoder type. If the drive senses that the serial communication to the encoder has stopped, it will trigger the error E.ENCC.




If the encoder is replaced or disconnected, the drive will trigger an error or warning that the encoder was changed. The drive will display the error message E.ENCC and lock out operation by changing LF.3 to configuration mode. No further operation is possible.

If the encoder was exchanged the drive will auto reset the E.ENCC fault but will remain in configuration mode because the user will need to learn the new encoder position before operation can continue. See section 5.11.1

If there is an encoder triggered fault or problems with the encoder cable the E.ENCC error will not clear and the problems must be diagnosed through parameter LF.26. To clear the E.ENCC error, it is necessary to go to parameter 0.LF.26, press "Func" and then press "Enter".

Signals Format of the analog channels



Installation and Connection

3.2.5 X3A SIN/COS-SSI Encoder

The SIN/COS-SSI encoder provides two differential analog channels for incremental position and one serial data channel with clock for communication with the encoder. This serial data channel can provide the drive with the absolute position of the motor.

The analog cosine and sine wave signals of tracks A and B have a voltage of 1 V_{pp} with an Offset of 2.5 V. This analog voltage is measured and a high resolution position value is determined as a result. This high resolution position value is very important for good speed control of a gearless motor.



Therefore it is absolutely necessary to ensure these signals are well shielded! Noise on the analog signals resulting from breaks in the shield or improper shield termination will result in vibration in the motor and poor ride quality.


During start-up and then every 30 ms a request is transmitted to the encoder and the absolute position is read out via serial communication. This initial readout of the absolute position provides the drive with the commutation angle for permanent magnet motors. On the very first operation of a permanent magnet motor it is necessary to synchronize the encoder position to one of the pole pairs of the motor. See parameter LF.77 for more information and section 5.11.1.

During normal operation, the difference between the internal absolute position of the encoder and the measured position value in the drive is compared. If the two deviate by more than 2.8 degrees, the drive will trigger the error, E.ENCC. Refer to parameter LF.26 for more information.

The clock signal serves as synchronisation for the serial data channel.

If there is an excess length of cable (10 feet or less), it is OK to coil it into a loop in the controller. Maintain a minimum diameter of 1 foot and keep the cable at least 8 inches away from all high voltage power wires.

Drive connection X3A Female SUBD 15 HD



Pin No	Signal Description
1	- -
2	- -
3	REF_COS signal input A- (difference signal to COS+)
4	REF_SIN signal input B- (difference signal to SIN+)
5	- -
6	+ CLOCK synch. signal for serial data
7	- CLOCK synch. signal for serial data
8	COS+ signal input A (absolute track for counter and direction detection)
9	SIN+ signal input B (absolute track for counter and direction detection)
10	- -
11	- -
12	+ 5V Supply voltage for encoder
13	COM Reference potential for supply voltage
14	-DATA Data channel RS485
15	+DATA Data channel RS485

Max. Load Capacity depending on Voltage Supply

Max. load capacity at +5.0V; 300 mA. The specified current is reduced by the current taken from the second encoder interface X3B interface (see section 3.2.6).

SIN/COS-SSI Cable

Pre-manufactured SIN/COS-SSI cables offer the best solution against noise and disturbance while at the same time saving installation time. The cables come in standard lengths of 5m, 10m, 15m, 20m, 25m and 30m.

Cable Part Number

00.F5.0C1-40xx xx = length in meters, 10 = 10 meters



Mating Connector

00.90.912-004U for encoder (solder type)

Running in Conduit

When this cable must be pulled through metallic conduit, it is necessary to over size the conduit! Use of a 1 1/2 inch trade size conduit will allow the connectors to pass without removal of the connectors. Cutting the cable, or removal of the connectors or their housings voids the warranty and will result in problems with electrical noise after the fact.

Circular connector on Sin/Cos-SSI encoder.



Shield wire tied to housing

Note: Inner pair shields are tied to 0V (com), pin 13, not earth ground!

Shield wire tied to housing which is earth ground.

Installation and Connection

Technical Data

Input resistance:	120 Ohm
Process data channel:	1Vpp
Parameter channel:	EIA RS485 half duplex
Clock signal output:	EIA RS485
Maximum input frequency:	200 kHz
Encoder line number:	1...2048 inc
Maximum cable length:	100 m (<i>based on signal levels, otherwise see below</i>)
Cable length based on cable resistance	

The maximum cable length is calculated as follows:

$$\text{Length} = \frac{V - V_{\min}}{I_{\max} * R} = \frac{5.25V - 4.75V}{0.2A * 0.003 \Omega/m} = 83.3 \text{ m}$$

where

I_{\max} = supply current of encoder [amps]

V = voltage supply of the drive = 5.25V

V_{\min} = minimum supply voltage of the encoder

R = cable resistance (0.07 Ω/m) for Standard KEB cables
(0.03 Ω/m) for type "L" KEB cables

The following SIN/COS-SSI encoders have been tested for use:

- Danaher / Hengstler

However, this does not restrict the use of rotary encoder with same specifications of other manufacturers

The recognition of encoder loss or exchange is a software function and dependent on the encoder type. If the drive senses that the serial communication to the encoder has stopped, it will trigger the error E.ENCC.




If the encoder is replaced or disconnected, the drive will trigger an error or warning that the encoder was changed. The drive will display the error message E.ENCC and lock out operation by changing LF.3 to configuration mode. No further operation is possible.

If the encoder was exchanged the drive will auto reset the E.ENCC fault but will remain in configuration mode because the user will need to learn the new encoder position before operation can continue. See section 5.11.1

If there is an encoder triggered fault or problems with the encoder cable the E.ENCC error will not clear and the problems must be diagnosed through parameter LF.26. To clear the E.ENCC error, it is necessary to go to parameter 0.LF.26, press "Func" and then press "Enter".

Signals Format of the analog channels



Installation and Connection


3.2.6 X3B Incremental Encoder Output



ONLY when the inverter is switched off and the voltage supply is disconnected may the feedback connectors be removed or connected!

The second incremental encoder connection serves as a buffered output of the motor encoder. This can be used by other control systems for speed or position control. The output signals are according to the RS422 line driver signal standard.

9 Pin Sub D - Female



Plug in screw terminal



Pin No.	Signal	Pin No.
1	A+	1
2	B+	3
3	N+	5
4	+5.0 V	7
5	24...30 V	-
6	A-	2
7	B-	4
8	N-	6
9	0V com	8
Sub-D Housing	Earth GND	Inverter Housing


The internal 24VDC power supply has a maximum load capacity of 170mA . The 5V supply has a maximum load capacity of 500mA. Both of these values assume no loading on the supplies of connection X3A. If connections or loads are placed on both terminals, the total load between the two must not exceed these values.

The following specifications apply to encoder interface X3B, channel 2

- Max. operating frequency: 200 kHz.
- Maximum cable length: 50m (164 ft)
- External terminating resistance: $R_t = 120 \text{ W}$
- RS422 or TTL level square wave voltage level: 2...5 Vdc



For proper noise immunity, the RS422 standard requires a termination resistor be placed at the device which is receiving the simulated encoder signal. The resistors shall be connected from A+ to A-, B+ to B-, N+ to N- (only when used).



4. Operation of the unit


4.1 Digital Operator

The Elevator drive uses a special operator which provides a user interface and functionality specific to elevator applications. The operator must be plugged into the drive in order for the drive to function correctly.




Unplugging the operator while the drive is in operation will result in immediate shutdown of the drive and will cause the ready relay to drop and the fault output to activate. If it is necessary to remove the operator, do so while the elevator is standing still!

Elevator Operator: Part No. 00.F5.060-2028




Use only the **operator interface** X6C for the serial data transfer using RS232, or 485. The direct connection from PC directly to the Elevator Drive without operator or using the HSP5 diagnostic port is only possible with a **special cable**. Incorrect cabling can lead to the destruction of the PC-interface. Consult the factory for more information.




X6C
RS232, RS485

PIN	RS485	Signal	Meaning
1	–	–	reserved
2	–	TxD	Transmitter signal, RS232
3	–	RxD	Receiver signal, RS232
4	A'	RxD-A	Receiver signal A, RS485
5	B'	RxD-B	Receiver signal B, RS485
6	–	VP	Voltage supply-Plus +5V ($I_{max} = 10 \text{ mA}$)
7	C, C'	DGND	Data reference potential
8	A	TxD-A	Transmitter signal A, RS485
9	B	TxD-B	Transmitter signal B, RS485

4.2 Parameter Identification




4.3 Parameter Selection



Keypad Display

4.4 Changing Parameter Values



Changing Parameter Values

All parameter changes are accepted for operation and saved only after the ENTER key is pressed.

Some parameters, such as the motor data, can not be changed while the elevator is in operation.

4.5 Parameter Structure

Parameter Groups

LF-Parameter: LF. 2 ... LF.99

These parameters allow the user to program the drive for the given job specifications: motor data, mechanical data, speeds, profiles, etc.

LP-Parameter LP.1...LP.23

These parameters are used to configure the positioning control.

Ld-Parameter Ld.18...Ld.33

These parameters are used to configure the advanced controllers within the drive.

US-Parameter: US. 1 ... US.10

The US parameters are comprised of configuration parameters: parameter value reset, selection of operation mode, password entry, etc.

ru-Parameter: ru.0 ... ru.83

The ru parameters are comprised of run parameters for monitoring operation, i.e. actual values for many internal parameters


do-Parameter: do.82 ... do.83

The do parameters are comprised of parameters for defining the relay output functions

4.6 Saving Parameter Values

If the parameter value is changed, a point appears behind the last position in the display. The adjusted parameter value is permanently saved when **ENTER** is pressed. The point after the value disappears to confirm.

Example:



4.7 Error Messages

If a malfunction occurs during operation, the drive shuts down operation and the actual display is overwritten with the error message. By pressing the “ENTER” key, the error message and the fault status is cleared. Exception: E.ENCC errors, see parameter LF.26 for E.ENCC errors.

Example:



Some errors are automatically reset according to the adjustment of parameter LF.5. So it is possible that the error message and the error status of the drive will clear on its own. Refer to parameter LF.98 for the fault history.

***Inverter Status Message
(running/error message) see p. 129***

5. Initial Start-up

5.1 Selecting The Configuration

Before trying to operate the drive it is necessary to establish the correct mode of operation. The F5 drive is capable of driving different types of motors both open and closed loop. Therefore prior to operation, the type of motor and mode of operation (open or closed loop) must be established.



Note: In most cases the elevator control manufacturer will make the adjustment of the configuration and control mode, sections 6.1,6.2,6.3, and therefore it is not necessary to make these adjustments in the field. In this case simply verify parameter LF.4 matches the required configuration number listed below.

The available motors and modes or configurations are listed below. From this list it is possible to select the correct configuration setting of the Drive.

Motor Type	Open Loop	Closed Loop	Configuration Display Code
Induction Geared	-	x	ICL5d
Induction Gearless	-	x	I9L55
PM Synchronous Geared	-	x	PCL5d
PM Synchronous Gearless	-	x	P9L55

5.2 Loading The Configuration

With the configuration code noted, go to parameter US.10 on the keypad of the drive and press “Function.” Select the configuration code indicated and press “Enter.”

Once the configuration is selected, it is now necessary to load the configuration file. This adjusts the drive for the correct motor type and establishes the correct internal settings.

To load the configuration go to parameter US.04, set the display to LoAd and press enter. The display will show Pr09 and the configuration file will be loaded. The display will confirm whether the load was successful. If the display ultimately changes to parameter LF.99 and shows noP, the load was successful. If the file is not completely loaded, the display will show bdPAS for bad operation and will remain at parameter US.4. In this case power cycle the drive and try to load the configuration again. Make sure that no inputs are active while trying to load the configuration. LF.82 should read 0. If still unsuccessful there may be an incompatibility between the operator and the drive. Contact the manufacturer for further assistance.

After loading, the configuration can be verified through parameter LF.4. The same configuration code as that selected in US.10 will be displayed in LF.4. Also after a successful load US.4 will display PAS5.

5.3 Setting The Control Type

The TORQMAX drive supports six different control modes, digital speed selection and control, analog speed control, analog torque control. The drive's I/O will need to be set up according to the desired scheme. From the table below select the desired control scheme and adjust the corresponding number in parameter LF.2.

Control Mode	Setting in LF.2
Absolute Analog Speed Control	AbSPd
Digital Speed Selection	d SPd
Analog Speed Control	A SPd
Analog Torque Control	A tor
Serial Speed Control	SErSP
Binary Speed Selection	bnSPd
Serial Position Control	SPoS

5.4 Entering The Operating Data

The TORQMAX drive utilizes robust algorithms for controlling the motor, therefore even with minimum information about the motor, good performance can still be achieved. However a few basic parameters are required. Their adjustment is outlined below. For purposes of identifying the type of motor in use the following convention will be utilized in this manual. AC induction motors will be referred to as "IM" and AC permanent magnet synchronous motor will be referred to as "PM"

Before you begin to enter the motor data verify that parameter LF.3 is set to conF configuration.

The TORQMAX Drive is capable of driving either induction motors, referred to from here on as "IM" or permanent magnet motors referred to from here on as "PM"

Verify in LF. 4 that the correct motor configuration is loaded and then follow the steps listed below based on what type of motor you have.

5.5 Induction Motors

5.5.1 Motor Overload

The TORQMAX drive is capable of providing solid state motor overload protection. If it is desired that the drive provide this protection, turn the function "on" in parameter LF.08. Then adjust the motor full load amps (FLA) in parameter LF.09. Enter the IM power (hp) in LF.10.

Initial Start Up

5.5.2 Induction Motor Data

Enter the motor rated speed (rpm) in LF.11. For IM this value is not the synchronous speed but the full load rpm which is always less than synchronous speed. An example is a 6 pole motor; the synchronous speed is 1200 rpm but the rated speed is lower, about 1165 rpm. If the rated speed is not listed on the nameplate then the value can be approximated as the synchronous speed less 2.9%, so $1200 \text{ rpm} - 35 \text{ rpm} = 1165 \text{ rpm}$.

Enter the rated FLA of the motor in parameter LF.12.

Enter the rated nameplate frequency in parameter LF.13. In some cases manufacturers of induction motors de-rate the motor by changing the frequency to something less than 60hz, i.e. 40Hz. In this case enter the nameplate value of 40Hz. Most gearless motors will have a very low frequency in the range of 8 to 30 Hz. Enter the frequency as indicated on the motor nameplate.

In LF.14 enter the rated motor voltage. For IM this is the AC voltage at the rated frequency, i.e. 230V or 460V.

The IM power factor can be entered in LF.15. If this value is not known use the default value of 0.90. This parameter sets the magnetizing current level. Higher values result in lower magnetizing current. For older existing high slip or two speed motors use a value of 0.95.

The field weakening speed in LF.16 is calculated by the drive. It may be necessary to adjust it later once the elevator is in operation and running at high speed. For now leave it at the calculated value.

LF.17 is the motor rated torque. With IM this value is calculated and is only for reference.

Entry of the IM motor data is now complete!

5.5.3 Auto-Tuning Induction Motors

For best performance the motor model of the induction motor must be measured by the drive. Use the following steps to complete the measurement for induction motors.

Set up

- 1) Make sure the rated motor power (LF.10), rated motor speed (LF.11), rated motor current (LF.12), rated motor frequency (LF.13), rated motor voltage (LF.14) and rated power factor (LF.15) are entered into the drive before you begin. If the power factor is not on the name plate use 0.90 as the value.
- 2) Remove one brake wire from the controller or reduce the brake pick voltage level, preventing it from picking.

- 3) If the controller is providing the speed command via analog or serial command, set the inspection speed value in the controller to zero. If the drive is providing the command there is no need to change the inspection speed in the drive.

Learn Process

- 1) Set LF.3 = 5 Lrn. This will start the learn process.
- 2) The display will change to StArt.
- 3) Press and hold inspection up. The motor contactor should pull in and the brake should not pick. Motor current will begin to flow, an audible noise in the motor will be heard, and the drive display will change to LS103 .
- 4) The drive will measure various parameters in the motor as well as in the drive's own power stage. During each measurement the display will change to signify what is being measured. In the event of problems during the measurement phase the factory can use the codes to determine what is happening.
- 5) Continue holding the inspection switch ON until the drive displays done.
- 8) Release the inspection switch, the drive will finish by making several calculations, CALC, and updating the parameters values with the measured values.

AUTO TUNE COMPLETE!

Errors: In the event the drive can not complete the measurements two error messages may occur.



FAILd : the drive is not able to begin measurements due to a configuration error. Consult the factory to resolve.

FAIL : the measurement sequence was interrupted, i.e. the inspection switch was release prematurely, electrically the motor was not properly connected, or the controller dropped the enabled signal to the drive. Verify if the controller is dropping the signal by first setting LF.3 to conf and try again. If the controller still drops the enable and the motor contactor, the problem lies in the controller.

E.ccd: the measurement of one of the motor parameters was not possible. Repeat the process and note what code is display just before the error occurs. Then contact the manufacturer for assistance. In some cases the error can be avoided by pre adjusting some motor data.



**Remember to put the drive back into run mode in LF.3 and return the controller adjustments to the previous values!
Reconnect the brake wire!**

Initial Start Up

5.6 PM Synchronous Motors

5.6.1 Motor Overload The TORQMAX drive is capable of providing solid state motor overload protection. If it is desired that the drive provide this protection, turn the function “on” in parameter LF.08. The drive uses the motor current from LF.12. as the trigger level.

5.6.2 Motor Data Depending on the motor manufacturer and the installed encoder, it may be possible to read all motor data from the encoder and preset all data to the manufacturer’s values therefore eliminating the need to adjust the motor data. Refer to section 5.8.3 for a description of this process. Otherwise proceed with the adjustment steps below.

The PM motor power (hp) in LF.10 is calculated from the speed (LF.11) and torque (LF.17). This value is for reference only.

Enter the motor rated speed (rpm) in LF.11. Note in some cases this speed may be faster than the actual speed the motor will turn at. This parameter must agree with parameters LF.13 based on the following equation. Do not round the numbers enter exactly what is calculated.

$$\frac{\text{Rated Freq.} \times 120}{\text{no. of poles}} = \text{Rated Speed}$$

Enter the rated FLA of the motor in parameter LF.12.

Enter the rated nameplate frequency in parameter LF.13. Again refer to the calculation above. Do not round this value enter exactly what is calculated.

In LF.14 enter the rated, no load, motor back EMF rms phase to phase voltage. Follow the steps in section 5.6.3 to measure this value.

LF.17 is the motor rated torque. For PM motors enter the rated motor torque in lbft. If this value is not listed on the motor you can calculate it as follows.

$$\frac{\text{HP}}{\text{rpm}} \times 5258 = \text{lbft} \quad (\text{HP and rpm from motor nameplate})$$

$$\frac{\text{KW}}{\text{rpm}} \times 7043 = \text{lbft} \quad (\text{KW and rpm from motor nameplate})$$

LF.18 is the motor stator phase to phase resistance. Follow the steps in section 5.6.3 to measure this value.

LF.19 is the motor stator leakage inductance. Follow the steps in section 5.6.3 to measure this value.

Entry of the PM motor data is now complete!

5.6.3 Auto-Tuning PM motors

For best performance the resistance and the inductance of the PM motor must be measured by the drive. Use the following steps to complete the measurement for PM synchronous motors.

Set up

- 1) Make sure the rated motor speed (LF.11), rated motor current (LF.12), rated motor frequency (LF.13), rated motor torque (LF.17) and contract speed (LF.20) are entered into the drive before you begin.
- 2) Remove one brake wire from the controller or reduce the brake pick voltage level, preventing it from picking.
- 3) If the controller is providing the speed command via analog or serial command, set the inspection speed value in the controller to zero. If the drive is providing the command there is no need to change the inspection speed in the drive.

Learn Process

- 1) Set LF.3 = 5 Lrn. This will start the learn process.
- 2) The display will change to StArt.
- 3) Press and hold inspection up. The motor contactor should pull in and the brake should not pick. Motor current will begin to flow, an audible noise in the motor will be heard, and the drive display will change to L5103 .
- 4) The drive will measure various parameters in the motor as well as in the drive's own power stage. During each measurement the display will change to signify what is being measured. In the event of problems during the measurement phase the factory can use the codes to determine what is happening.
- 5) Continue holding the inspection switch ON until the drive displays done.
- 8) Release the inspection switch, the drive will finish by making several calculations, CALC, and updating the parameters values with the measured values.

AUTO TUNE COMPLETE!



**Remember to put the drive back into run mode in LF.3 and return the controller adjustments to the previous values!
Reconnect the brake wire!**



Errors: In the event the drive can not complete the measurements two error messages may occur.

FAILd : the drive is not able to begin measurements due to a configuration error. Consult the factory to resolve.



FAIL : the measurement sequence was interrupted, i.e. the inspection switch was release prematurely, or the controller dropped the enabled signal to the drive. Verify if the controller is dropping the signal by first setting LF.3 to conf and try again. If the controller still drops the enable and the motor contactor, the problem lies in the controller.

E.ccd: the measurement of one of the motor parameters was not possible. Repeat the process and note what code is display just before the error occurs. Then contact the manufacturer for assistance. In some cases the error can be avoided by pre adjusting some motor data.

5.7 Machine Data

It is necessary to enter the machine data such that the drive can establish the relationship between linear travel, ft/min and rotary speed in rpm at the motor.

Enter the job contract speed in parameter LF.20.

Then enter the sheave diameter in LF.21. If this value is not known, it can be measured with a tape measure. Some sheave manufacturers will show the “Minimum Groove Diameter” on a plate attached to the sheave. This is the diameter to the bottom of the groove, which is normally about one inch smaller than the actual diameter at which the rope lies. Therefore, when this dimension is provided, add one inch to it and enter that value into LF.21.

LF.22 is the machine gear ratio. It is often listed on the machine as a ratio of gear teeth such as 55:2. In this case divide the ratio ($55/2 = 27.5$) and enter the value. If the ratio is not known, skip ahead to LF.23 and then see LF.25 for an estimated gear ratio which can be entered into LF.22. Remember for gearless jobs the gear ratio is 1.00.

LF.23 is the roping ratio. For most geared applications it is 1:1. For gearless application the rope ratio is typically 2 but can be higher.

LF.24 is the car rated capacity in lbs.

LF.25 is the estimated gear ratio. If the gear ratio is not known, take the value from LF.25 and enter it into LF.22.

Set up for the machine is complete!

5.8 Encoder Feedback

Parameters LF.26...LF.29 and optionally parameters LF.76 and LF.77 are used to establish the encoder feedback.

5.8.1 Encoder card verification

The most important point is to verify that the installed feedback card matches the encoder type on the motor. The drive supports many different types of encoders, some of which require different feedback cards as options. Parameter 0.LF.26 displays the type of encoder feedback card which is currently installed. From the list below verify the encoder interface on the drive matches the encoder on the motor.

0.LF.26	Type of encoder card installed in the drive
rESoL	Resolver
HIPEr	Hiperface
Inc24	15-24V HTL incremental
IncIE	5V TTL incremental
SinCo	Sine Cosine
I24PE	15-24V HTL incremental
EndAt	EnDat Encoder
PHASE	UVW Encoder

5.8.2 Encoder serial com. verification

ENDAT, HIPERFACE, and SIN/COS-SSI encoders support serial communication between the encoder card on the drive and the encoder. This serial communication transmits the digital position value and well as other data about the motor and the encoder. The encoder can trigger faults and advise the drive of the problem. Therefore with these types of encoders it is necessary to verify that serial communication is functioning normally. Parameter 2.LF.26, displays the status of the encoder / encoder interface. When everything is functioning normally the display will show `conn`. If there is an error, the drive will first stop operation with an E.ENCC error and then will display the encoder error code from 2.LF.26 and then a text message representing the code. All diagnostics of the encoder interface should be handled through parameter 2.LF.26. For more information refer to parameter LF.26.

5.8.3 Loading motor data from encoder

When ENDAT or HIPERFACE encoders are used on PM motors, the motor manufacturer may pre-load the encoder with the motor data at the factory. In this case the motor data as well as commutation position, can then be read out from the encoder and loaded into the drive, and thus simplify the set up and commissioning process.

Parameter 3.LF.26 allows the motor data in the encoder to be loaded into the drive.

Reading motor data from the encoder

- 1) go to parameter 2.LF.26 and verify serial communication is OK. Display should show `conn`.
- 2) go to parameter 3.LF.26 and press function. The display should show `ldLE`.
- 3) press the up arrow and the display will change to `rdEnc`
- 4) press enter and the display will change to `no`
- 5) press the up arrow and the display will change to `YES`
- 6) press enter and the display will change to `rERd`. The drive will then read the data from the encoder, update the motor parameters and reload all drive data.

This process will load motor parameters LF.10...LF.19, LF.27, Ld.27...Ld.28 and LF.77. Since the commutation position (LF.77) is also loaded this process eliminates the need to learn the position. Therefore refer only to section 5.11.4 regarding the start up of a PM motor.

5.8.4 Other encoder adjustments

Enter in LF.27 the pulses per revolution of the encoder, i.e. 1024, 2048, 4096 etc.

LF.28 can be used to swap the encoder channels such that the encoder is incrementally counting in the same direction as the motor. Initially leave this parameter set to 0 or no reversal. Whether or not reversal is necessary will be determined later in section 5.11

LF.29 sets the sample time for the speed measurement. Initially the default setting of 4 mSec will work fine.

Set up of the encoder is complete!

5.9 Controller Settings

The speed and torque controller are adjusted in parameters LF.30 through LF.36. For initial start up the default settings will work. Once the elevator is running at high speed, it might be necessary to come back to adjust LF.31... LF.33.

LF.30 is the one parameter which will need to be adjusted for initial operation. If operating open loop set LF.30 = 0 and if operation is closed loop speed or torque control initially set LF.30 = 2. Once the proper direction of rotation is established LF.30 can be changed to a value of 4 if torque control is ultimately desired.

Set up of the controller is complete!

5.10 Speed and Profile Settings

The speeds are adjusted through parameters LF.41...LF.47. The profile is adjusted through parameters LF.50...LF.56.

When operating with digital speed selection and control, each speed must be adjusted respectively.

LF.41 = Leveling speed LF.42 = High speed
LF.43 = Inspection speed LF.44 = Correction speed
LF.45 = TAPS operation speed
LF.46 = Emergency power speed
LF.47 = Intermediate speed or Earthquake speed

The default settings listed on page 106 for the profile parameters LF.50... LF.56 are a good place to start. When operating with analog speed or torque control, only high speed must be adjusted to the contract speed value. In selecting analog control in parameter LF.2, the profile generator in the drive is automatically turned off.

Set up of the speeds and profiles are complete!

5.11 Running the Motor

5.11.1 Stationary Pole Identification (SPI)

The SPI function allows the drive to learn the absolute encoder position for a PM machine under the brake without sheave movement.



The SPI process can be done with the ropes on and the brake set.

This procedure can only be done with a Permanent Magnet Motor. Depending on the motor design, the SPI process may fail. In this case see section 5.11.2.

Before the drive can learn the absolute position, the motor data must be entered correctly and the motor resistance and inductance must be measured by the drive. See section 5.6.2 and 5.6.3.

Initial Steps

- 1) Verify the motor is correctly connected to the drive, i.e. phase U->U, V->V, W->W. With PM motors you can not have an arbitrary phasing. If direction reversal is required, the system direction can be reversed in LF.28 after the pole position is learned.
- 2) Verify the correct mode of operation. LF.4 should be set to either PCL5d or P9L55. If this is not the case see parameter US.10 to change the configuration mode.
- 3) If not already done, enter the motor nameplate data and machine data in parameters LF.10 to LF.25. Learn the motor with the auto tune function, see sections 5.6.2 and 5.6.3.
- 4) Verify the correct encoder feedback card is installed in the drive. See parameter 0.LF.26. Enter the encoder ppr in parameter LF.27. Make sure LF.28 = 0 and the sample time, LF.29 = 4 (4mSec.).

Alignment Process

- 1) Prevent brake from releasing.
- 2) Set LF.3 = SPI and press "Enter". The display will confirm with StArt.
- 3) Press and hold the inspection switch up. The motor sheave should not turn and the display will show position values of the encoder. The brake should not release..

- 4) Once complete, donE will be displayed on the keypad operator. Release the inspection switch and make note of the final position number in LF.77. This position number is valid only for this motor and encoder. If the encoder is physically removed from the motor, this process will need to be done again.
- 5) The display will show noP in LF.99 and LF.3 will automatically be set to run.
- 6) Verify encoder position is correct by running the car and monitoring the current in ru.15. If the current is excessive, the encoder rotation may be incorrect. In this case change LF.28 from a value of 0 to 1 or 1 to 0, else from 2 to 3 or from 3 to 2, and repeat the alignment process.



Errors: In the event the drive can not complete the measurement the following error messages may occur.

FAILP: The drive is not able to begin measurements due to not entering and learning the correct motor data. See section 5.6.2 and 5.6.3.

FAIL: The measurement sequence was interrupted, i.e. the inspection switch was released prematurely, or the controller dropped the enabled signal to the drive. Verify if the controller is dropping the signal by first setting LF.3 to conF and try again. If the controller still drops the enable and the motor contactor, the problem lies in the controller.

FAIL may also occur if the encoder position samples are not consistent within 4,000 counts after 11 samples. In this case try the procedure again and note the learned values. If all displayed values are consistent, it would be sufficient to use an approximate average and enter it into LF.77. Otherwise, if the positions are sporadic and not consistent, verify motor data parameters LF.11-19 then relearn the motor data with S_Lrn. If still unable to learn the encoder position with SPI, refer to section 5.11.2 to learn it with sheave movement.

5.11.2 Absolute Encoder Setup (no ropes)

HIPERFACE, ENDAT, SIN/COS Encoders

The following will outline the procedure for aligning an absolute encoder to the pole of a permanent magnet motor and the following encoders: Hiperface, Endat, SIN/COS. The motor must be mounted in place and be electrically connected to the elevator controller. The motor encoder must also be connected to the controller. The motor must be able to spin freely either by mechanically releasing the brake or through normal electrical release.



If at any point during the set up process, if the drive should give the error E.ENCC, the display will change automatically to 2.LF.26 and display the error code from the encoder. Refer to parameter LF.26 for further information.

Initial Steps

- 1) Verify the motor is correctly connected to the drive, i.e. phase U->U, V->V, W->W. With PM motors you can not have an arbitrary phasing. If direction reversal is required, the system direction can be reversed in LF.28 after the pole position is learned.
- 2) Verify the correct mode of operation. LF.4 should be set to either PCL5d or P9L55. If this is not the case see parameter US.10 to change the configuration mode.
- 3) If not already done, enter the motor nameplate data and machine data in parameters LF.10 to LF.25. Learn the motor with the auto tune function, see sections 5.6.2 and 5.6.3.
- 4) Verify the correct encoder feedback card is installed in the drive. See parameter 0.LF.26. Enter the encoder ppr in parameter LF.27. Make sure LF.28 = 0 and the sample time (LF.29) is set to 4mSec.

Alignment Process

- 1) Set LF.3 = P Lrn. The display should confirm with StArt
- 2) Press and hold the inspection up switch. Motor current will begin to flow in one phase and the current will ramp up to the motor's rated value. The motor sheave should turn slowly and then stop when the motor rotor has lined up with one of the motor poles. The display should show the actual position value of the encoder. As the motor moves this value will change. When the motor rotor has aligned with a pole, the value will stabilize. At this point, the alignment has been found.

Continue holding the inspection switch as the drive will then try to move the motor clockwise and counter clockwise to verify the motor's rotation is consistent with the encoder's. The motor should return to nearly the same position. Go to step 5.

If the motor keeps rotating for more than 30 seconds, the phasing between the encoder and the motor is not correct. Verify the motor connection U to U, V to V, etc. and make sure LF.28 = 0.

- 3) If the drive triggers the error E.ENC1, the encoder's counting maybe backwards. Release the inspection switch. The drive will then automatically swap the encoder channels by changing the value of LF.28 and then display **retry**. Go back to step 2.
- 4) If the drive displays E.ENC1 again the motor is not able to rotate freely. Release the inspection switch and verify the brake is opening completely and that there is not excessive friction. The sheave should be able to turn by hand. Verify the motor phasing U to U, V to V etc.

If it is still not possible to learn the position try the old method by setting LF.3 = conf and LF.77 to 2206.

- 5) When the process is complete, donE will be displayed. Release the inspection switch and make note of the final position number from LF.77 in the job information. This position number is valid only for this motor and encoder. If the encoder is physically removed from the motor, this process will need to be done again.

Return to Normal Operation

- 1) Put the drive into run mode by setting LF.3 to run.
- 2) Run the motor on inspection up and down. The speed displayed in LF.89 should be stable and should match the command speed value in LF.88. Additionally the motor current in LF.93 should be near zero. If the current is not near zero (< 5 amps), the pole position may be off. Try to relearn the position by repeating the alignment process.
- 3) If the motor rotates in the wrong direction refer to section 5.11.4 to reverse the system rotation.
- 4) If the motor uses an EnDat or HIPERFACE encoder, the values may now be stored in the encoder. Refer to parameter 3.LF.26.
- 5) For high speed runs under load, it may be necessary to raise 0.LF36 to a higher value. This value should not be set to a value higher than the motor manufacturer's peak torque value, usually 2.0 to 2.4 times the motor's rated torque found in parameter LF.17.

Initial Start Up

5.11.3 Absolute Encoder Setup (with ropes)

The following will outline the procedure for aligning an absolute encoder for use with a permanent magnet motor and the following encoders: HIPERFACE, ENDAT, SIN/COS. The motor must be mounted in place and be electrically connected to the elevator controller. The motor encoder must also be connected to the drive. In this case the ropes are already on the motor.



At a certain point in the process, it will be necessary to put balanced load into the car to carry out this adjustment.

If at any point during the set up process, the drive should give the error E.ENCC, the display will change automatically to 2.LF.26 and display the error code from the encoder. Refer to parameter LF.26 for further information.

Initial Steps

- 1) Verify the motor is correctly connected to the drive, i.e. phase U->U, V->V, W->W. With PM motors you can not have an arbitrary phasing. If direction reversal is required, the system direction can be reversed in LF.28 after the pole position is learned.
- 2) Verify the correct mode of operation. LF.4 should be set to either PCL5d or P9L55. If this is not the case see parameter US.10 to change the configuration mode.
- 3) If not already done, enter the motor nameplate data and machine data in parameters LF.10 to LF.25. Learn the motor with the auto tune function, see sections 5.6.2 and 5.6.3.
- 4) Verify the correct encoder feedback card is installed in the drive. See parameter 0.LF.26. Enter the encoder ppr in parameter LF.27. Make sure LF.28 = 0 and the sample time (LF.29) is set to 4mSec.

Balancing the car

The following steps are necessary if the car is not at floor level and the weights can not be loaded into the car. Therefore it is necessary to drive the car to a floor.

- 1) Adjust parameter 0.LF.36 equal to LF.17.
- 2) Set the inspection speed to a relatively low value 10-15ft/min.
- 3) Adjust parameter LF.77 to 16,000.
- 4) Try to run the car on inspection up or down. (note the motor will make a loud noise and the control of the motor will be poor.
- 5) If the car fails to move go back to step 3 and change the value to 32,000, 48,000, or 64,000. Try to move the car again after each value.
- 6) Once you find a value which gives some movement you may need to add or subtract 8,000 to increase the torque output of the motor (i.e. you can move a little but the motor does not seem to have enough torque).
- 7) At this point if there is a long distance to cover in the hoist way, the inspection speed can be raised to a higher value.

Balance the car such that when the brake opens, the car does not move at all. It might be necessary to let the car drift until it reaches an equilibrium.

Alignment Process

- 1) Set LF.3 = P Lrn. The display should confirm with StArt
- 2) Press and hold the inspection up switch. Motor current will begin to flow in one phase and the current will ramp up to the motor's rated value. The motor sheave should turn slowly and then stop when the motor rotor has lined up with one of the motor poles. The display should show the actual position value of the encoder. As the motor moves this value will change. When the motor rotor has aligned with a pole, the value will stabilize. At this point, the alignment has been found.

Continue holding the inspection switch as the drive will then try to move the motor clockwise and counter clockwise to verify the motor's rotation is consistent with the encoder's. The motor should return to nearly the same position. Go to step 5.

If the motor keeps rotating for more than 30 seconds, the phasing between the encoder and the motor is not correct. Verify the motor connection U to U, V to V, etc. and make sure LF.28 = 0.

- 3) If the drive triggers the error E.ENC1, the encoder's counting maybe backwards. Release the inspection switch. The drive will then automatically swap the encoder channels by changing the value of LF.28 and then display **retry**. Go back to step 2.
- 4) If the drive displays E.ENC1 again the motor is not able to rotate freely. Release the inspection switch and verify the brake is opening completely and that there is not excessive friction. The sheave should be able to turn by hand. Verify the motor phasing U to U, V to V etc.

If it is still not possible to learn the position try the old method by setting LF.3 = conf and LF.77 to 2206.

- 5) When the process is complete, donE will be displayed. Release the inspection switch and make note of the final position number from LF.77 in the job information. This position number is valid only for this motor and encoder. If the encoder is physically removed from the motor, this process will need to be done again.

Return to Normal Operation

- 1) Put the drive into run mode by setting LF.3 to run.
- 2) Run the motor on inspection up and down. The speed displayed in LF.89 should be stable and should match the command speed value in LF.88. Additionally the motor current in LF.93 should be near zero. If the current is not near zero (< 5 amps), the pole position may be off. Try to relearn the position by repeating the alignment process.
- 3) If the motor rotates in the wrong direction refer to section 5.11.4 to reverse the system rotation.

- 4) If the motor uses an EnDat or HIPERFACE encoder, the values may now be stored in the encoder. Refer to parameter 3.LF.26.
- 5) For high speed runs under load, it may be necessary to raise 0.LF36 to a higher value. This value should not be set to a value higher than the motor manufacturer's peak torque value, usually 2.0 to 2.4 times the motor's rated torque found in parameter LF.17.

5.11.4 Absolute Encoder Position Verification

Verification of the encoder position.

Friction and the inertial load of the cab and counter weights can lead to a small error in the actual position value. The following procedure will verify whether the position is correct or not.

- 1) Set 0.LF.36 = two times LF.17.
- 2) Pick two floors in the middle of the shaft which are far enough apart such that the car reaches contract speed
- 3) Run the car between these floors and monitor LF.94 (peak phase current). Note the peak value for both the up and down run. The stored maximum value is cleared by pressing the down arrow. Make several runs to establish the average value in each direction.
- 4) Add 2000 to the value in LF.77 and run the car again between the same two floors. If the current value goes down then go to step 5. If the current value goes up go to step 6.
- 5) Add 2000 more to the value in LF.77 and run the car again. If the peak current in LF.94 goes down further, add 2000 more and try again. Keep doing this until the motor current begins to rise again. The value with the lowest current is the best value. Jump to step 7.
- 6) If the current went up initially, then lower LF.77 by 2000 and run the car again. If the peak current in LF.94 goes down further, subtract 2000 more and try again. Keep doing this until the motor current begins to rise again. The value with the lowest current is the best value.
- 7) Return the value of LF.77 to the value which gave the lowest current. Make note of this value in the job information for future reference.

5.11.5 Encoder Synchronization

TTL, HTL, SIN/COS Encoders with induction motors

It is necessary to determine whether or not the motor encoder is in phase with the rotation of the motor. As an example the motor is turning clockwise and the encoder is indicating clockwise rotation. The problem comes when the encoder indicates rotation opposite to the actual rotation of the motor. Depending on whether the system is operating in speed control mode or torque control mode it will be necessary to follow one of the following two procedures.

Speed Control, LF.30 = 2

To determine whether or not the encoder is aligned with the motor run the car on inspection in both the up and down direction. If the motor turns out of control, at the wrong speed, or the current going to the motor (see LF.93) is greater than the motor FLA, the encoder is reversed. This can be corrected by adjusting parameter LF.28 from 0 to 1.

Run the car again in both the up and down direction. The motor should now be running in a controlled manner but possibly in the wrong direction, meaning up inspection drives the car down or down inspection drives the car up. Parameter LF.28 can also be used to correct this. If LF.28 = 0 then change the value to 2. If LF.28 = 1 then change the value to 3. Now the motor should be controlled and run in the correct direction.

Torque Control, LF.30 = 4

To determine whether or not the encoder is aligned with the motor run the car on inspection in both the up and down direction. If the motor turns out of control, at the wrong speed, or the current going to the motor (see LF.93) is greater than the motor FLA, the encoder is reversed. This can be corrected by adjusting parameter LF.28. You will need to try all possible settings, LF.28 = 0,1,2,3. One of them should give you controlled operation of the motor and motor current below the FLA of the motor. However the direction of travel of the car in the hoist way may be reversed. If this is the case change LF.28 as described below and reverse the speed reference direction in the elevator controller.

Changes to LF.28 to reverse car direction

0 -> 2	1 -> 3
or	or
2 -> 0	3 -> 1

Changes to LF.28 to reverse encoder counting direction

0 -> 1	2 -> 3
or	or
1 -> 0	3 -> 2

5.12 High Speed Tuning

5.12.1 System Inertia Learn For optimum control of the elevator, it is recommended to learn the system inertia and activate the feed forward torque controller. Feed forward control reduces the dependence on the speed feedback from the motor by predicting what the system will do and providing the required torque command based on that prediction.

The first step in learning the system inertia is to get the car running at contract speed over multiple floors. If the auto tune process in section 5.5.3 or 5.6.3 has not been completed, complete the auto tune first. The counter weight balance shall be adjusted and finalized. Additionally if required, compensation chains or ropes shall be installed in their final state. Note, the best results are possible with compensation. The learn process is carried out by precisely balancing the car with weights inside the car. The procedure is outlined below.

- 1) Pick two floors and run the car only between these two floors. During the learn process the rate of acceleration will be lower so it might take 2 or more floors to reach contract speed.
- 2) Place balanced load in the car.
- 3) Display the actual motor torque in parameter ru.12.
- 4) Run the car up and down, note the value of ru.12 once the car is running at contract speed. When the car is balanced the value will be near zero and should be about the same in each direction, although the value may be opposite in sign, i.e. +15 up and - 15 down.
- 5) Add or subtract weight a small amount at a time, until the values in each direction are close. Excessive friction in the hoist way may result in higher torque values.
- 6) Once the car is balanced, adjust the speed (tach) following error in the controller to the maximum value as during the learn process the actual motor speed will not track the controller's command.
- 7) Set parameter LF.3 to I Lrn and press enter. The display will confirm with StArt. Note: if at any point it is necessary to abort the learn process, press the Func key on the drive's key pad. Additionally, it is not allowed to navigate away from this parameter during the learn process.
- 8) Register a call, the display will change and show the torque value. Monitor the car speed on the controller and make sure the car is getting up to speed. If not, increase the number of floors the car is traveling.

- 9) Run the car up and down a few times. Note that during the acceleration, the same value should be reached and then a much lower value during the constant speed portion of travel. Disregard the values during deceleration.
- 10) After having gotten a sense of the values, it will now be necessary to write down the values after each run. The values to note are the value during acceleration in the up direction and the value at constant speed in the up direction. It does not matter whether they are positive or negative. Write them all down as a positive value. Get values from about ten runs.
- 11) Add all acceleration values together and divide by 10. Add all constant speed values together and divide by 10. Then subtract the constant speed value from the acceleration value. The result is the value you need.
- 12) With the car standing still, press the Enter key on the keypad of the drive. The display will show VALuE. Press the up arrow key and scroll up to the value from step 11.
- 13) Once the value is correct, press Enter. This stores the acceleration torque value in parameter Ld.29. Additionally this calculates the system inertia and sets up the feed forward control in parameters Ld.30...Ld.32. Additionally, US.35 will be adjusted for analog speed control.
- 14) At this point the drive is back to normal run mode. The car should accelerate normally. In the controller, readjust the speed (tach) following error to a more normal value.
- 15) The process can be repeated starting from step 6.

5.12.2 Feed Forward Torque Control, FFTC

- 1) Now that the inertia is set, the FFTC is active. The effectiveness of the control can be simply influenced by the gain value in parameter Ld.32. 90% is the typical value which should give good results. However, if the value is lowered, the influence of the FFTC will be reduced, higher values will intensify the result. Values in the range 50% to 150% can be typical. Setting this value to 0% turns off the FFTC.
- 2) With the FFTC turned on it is possible to reduce the values of A.LF.31, d.LF.31, A.LF.32, d.LF.32, although, it is not always necessary. A.LF.33 and d.LF.33 should be reduced, i.e. by at least a factor of ten.
- 3) Depending on the type of elevator, geared or gearless, more or less offset gain (LF.33) may be required.

Initial Start Up

5.12.3 Speed Gain Adjustment

When not using the FFTC or when the gain of the FFTC must be kept lower, the speed control gains play a greater role in controlling the elevator. Always start adjustment with the proportional gain LF.31 and then proceed on the the integral gains in LF.32 and LF.33. All the gains are divided into 3 values, A for acceleration and contact run, d for deceleration, and P for pre-torque. The pre-torque values are for the pre-torque function only and are described in section 5.12.4.


Proportional Gain

The proportional gain maintains general control and stability over the entire speed range. The proportional gain is split into two values one for acceleration and constant speed (A.LF.31) and one for deceleration (d.LF.31). Additionally, the value can be automatically reduced as the speed transitions from slow speed to contract speed.


LF.31 sets the overall gain. Lower values, less than 1000, may result in loose control and overshoot of the command speed as high speed is reached. Higher values can cause high frequency oscillation or a buzzing sound in the motor. If tighter control is necessary during the start or stop that gain can be raised accordingly in A.LF.31 or d.LF.31.


The gain can be reduced at high speed through US.22 and US.23. Turn the function on in US.22 and set US.23 to the lower value. This can help reduce jitter or vibration at high speed, while still maintaining control at lower speeds.

LF.31 = 1000 Actual speed overshoots during transition into high speed. Raise in steps of 500 until overshoot is gone, 3000 is a good number.



LF.31 = 500 Motor has poor control with strong oscillations. Raise in steps of 500 until better control is achieved.






LF.31 = 5000
 Loud audible noise or vibration from the motor, lower the value in steps of 500 until the noise/vibration stops.

Integral Gain


The integral gain is responsible for correcting long term average error in speed as well as providing increase control and rigidity at lower speeds for starting and stopping. The integral gain is split into two values one for acceleration and constant speed (A.LF.32) and one for deceleration (d.LF.32).

LF.32 provides an overall gain value for all speeds of operation. If this value becomes too high, greater than 600, it can result in torque pulsations during acceleration and deceleration. If the value becomes too low, less than 250, the tracking of the command speed will suffer and the system may not reach contract speed.

LF.32 = 100 Speed lags the command, sometimes does not reach contract speed, under shoots the floor. Raise in steps of 100 until better control is achieved.



LF.32 = 1500 Acceleration is jerky, bunching or spotting occurs during deceleration. Lower LF.32 in steps of 200. A good range is 300-600.




Initial Start Up


LF.33 provides an offset to the gain value at low speeds. Again this parameter provides two adjustments; one for acceleration and one for deceleration. During starting and stopping it is necessary to have higher gain values to overcome friction as well as maintain good control. The total integral gain value is the sum of LF.32 and LF.33 at low speeds.

US.20 and US.21 define the corner speeds where the gain begins to ramp up and where the gain reaches the maximum value. For gearless application it may be necessary to increase US.21 to around 100 ft/min and decrease US.20 to 3 ft/min


Common problems during starting and their solutions



LF.33 = 1000 Speed lags the command on take off. This is typical with worm gear machines when trying to break free. The start feels very hard or abrupt. Raise in steps of 500.




LF.33 = 3000 Higher KI Offset value aids the torque build during starting. Helps to overcome break away torque of machine. Actual speed tracks the command.




LF.33 = 6000 High KI Offset value causing vibration or audible noise in the motor at take off. Lower in steps of 500


Common problems during stopping and their solutions




LF.33 = 500 Speed lags during the final phase of decel, one slow oscillation just before stop, under shooting of floor. Raise in steps of 500.



LF.33 = 3000 Higher offset value leads to bunching or steps during final approach, faster oscillations, reduce value in steps of 500



LF.33 = 1000 Offset value OK



LF.33 = 1000 OK but corner speed US.21 too low. In this case the speed begins to lag during the deceleration but then recovers in the final approach. With gearless it is often necessary to raise the corner speed of the start of the offset to a higher value.

Raise us.21 from 24ft/min to 100ft/min.

Initial Start Up

5.12.4 Synthetic Pre-Torque


Synthetic pre-torque is a feature of the drive which can be used to minimize, if not totally eliminate, the roll back which normally occurs when the brake is lifted.

The function is turned on in parameter LF.30 and adjusted in parameters US.17 & US.18 and P.LF.31 & P.LF.32. The following procedure will assist in the adjustment of the pre-torque.




Adjust brake spring tension, brake voltage, and brake timing first. Note, that it is often advantageous to use lower spring tension and lower brake pick voltage to provide a softer lifting of the brake. This allows for a smoother transition from brake to motor. It should be noted that any subsequent changes to the brake could require readjustment of the synthetic pre-torque.

- 1) Set the speed to zero in order to clearly see the rollback. On iControl and IMC this adjustment is done in the controller by setting pattern gain to zero. On the Motion 4000 and PTC, this adjustment is done setting drive parameter LF.43 = 0.
- 2) Run the car on inspection and note the roll back.
- 3) Turn on the synthetic pre-torque by setting LF.30 = 5. Also adjust US.17 = 0.2 sec. and US.18 = 0.2 sec.
- 4) Run the car on inspection. If there is any vibration or audible noise at the start, lower the value of P.LF.32 by 2500 and try again.
- 5) Increase the value of US.17 by 0.05 sec. If the rollback is reduced proceed to step 6, otherwise continue raising the value of US.17 again by 0.05 sec until a difference in the rollback is perceived.
- 6) Note the value of US.17 and raise it again by 0.05 seconds. If the roll back gets better try raising it again. Keep raising US.17 until it gets worse again. Then back off the value by 0.05 sec. Note there may still be some rollback at this point.
- 7) Increase the value of P.LF.32 in steps of 2000 and run the car. Roll back should be further reduced. Values as high as 20000 are normal. If there is vibration or audible noise at start reduce P.LF.32. In some cases it may help to raise the value of P.LF.31 to minimize vibration during the pre-torque phase. Adjust in steps of 1000. Finally reduce US.18 by 0.05 seconds.
- 8) Return the pattern gain or inspection speed to the previous values. On the iControl and IMC, adjust the speed pick delay such that it is longer than the total value of US.17 plus US.18. On the Motion 4000 and PTC, the speed pick delay will automatically be the sum of US.17 and US.18.
- 9) Run the car on automatic.



The goal is to adjust timer US.17 such that the pre-torque ramp down phase occurs exactly when the brake releases and the roll back occurs. Note: by monitoring LF.86 it is possible to see what phase the drive is in. A value of 4 is the ramp up phase and is controlled by US.17. A value of 3 is the ramp down phase US.18.



When adjusted properly, the brake should pick, the motor holds the load for a short period about $\frac{1}{4}$ second, and then the acceleration begins.



When ever LF.30 is changed from a value of 5 to another value (e.g. 0 for open loop) the values of P.LF.31 P.LF.32 will be overwritten. On changing LF.30 back to 5 the default values of 2000 and 10000 will be asserted. Always check these values if subsequent changes to LF.30 are necessary.

Initial Start Up

5.13 Function Test

5.13.1 Over Speed Function Test


This function allows the drive to easily test under over speed conditions without changing key drive parameters. After the test run, the drive automatically resets to normal operating conditions. Perform the following steps to complete the over speed test.

- 1) Verify normal operation of elevator on automatic. Put the drive into RUN mode by setting LF.3 to run. Run the motor on inspection up and down. The speed displayed in LF.89 should be stable and should match the command speed value in LF.88.
- 2) Enter the desired speed value for the over speed test (preset value in the over speed governor) in LF.49. This is the speed the car will run at when the over speed test is selected in LF.3.
- 3) To activate the function set LF.3 = OStSt. With LF.3 displayed on the keypad press FUNC to display the present value. Press the UP/DOWN keys until OStSt is displayed on the keypad and press the ENTER key to load the value.
- 4) Place a single call to run the car and conduct the over speed test.
- 5) After one run the drive is automatically reset to normal operating parameters.

Over Speed Test Complete!

6. Parameter Description

6.1 US-Parameters



Password

With different passwords different parameter groups can be accessed for advanced programming.




Load defaults

By selecting LoAd and pressing ENTER, all the LF parameters are returned to the factory default values. Note the display will automatically change to show the value of LF.99 upon successful loading of the default values.

Adjustment value: LoAd = reset all LF parameters

Displayed responses: PASS = default successful
bdPAS = default not successful




Load configuration

By selecting LoAd and pressing ENTER, the selected configuration file in US.10 and all the existing LF parameter values will be loaded into the drive. *Note: if the configuration is changed in US.10, the LF parameter values are returned to the factory default values. In this case, this should be done before any programming of the drive is carried out as all parameters will be cleared.* The display will change automatically to LF.99 upon successful loading of the configuration. The process may take several seconds.

Adjustment value: LoAd = Load Configuration

Displayed responses: Pro9 = Loading configuration
PASS = Load successful
bdPAS = Load not successful



Select configuration

This parameter allows the user to select which mode the drive will operate in. The possibilities are closed loop induction motor, closed loop permanent magnet motor, and low speed gearless modes. Select from the list below and then load the configuration file into the drive through parameter US.4.

Adjustment value: ICL5d = Closed loop induction
I9L5S = Closed loop induction gearless
PCL5d = Closed loop permanent magnet
P9L5S = Closed loop permanent magnet gearless

Parameter Description - Basic Set Up

Other US parameters

These US parameters are special parameters which are not needed in every application. They are turned off by default by the control manufacturer. The following serves only as a list of these parameters. For further adjustment refer to section 8.0.

US.14	Comm Error Para Address
US.15	Comm Error Data
US.16	E.OL2 function
US.17	Pretorque Timer-Ramp Up
US.18	Pretorque Timer-Ramp Dwn
US.20	Max speed for max Ki
US.21	Speed for min Ki
US.22	Speed dependent Kp Gain
US.23	Min KPgain at high speed
US.24	KD speed gain
US.25	Phase current check
US.26	Encoder diagnostic
US.27	Power Unit Code
US.28	Analog input zero volt clamp
US.29	HSP5 Watchdog Time
US.33	E.dOH Function
US.34	Analog Pattern Gain
US.35	Reference Splitting
US.37	Function Test

6.2 LF-Elevator Parameters



Signal / operating mode

This value determines the type of speed selection and rotation setting.

Value range:

- AbSPd = Absolute Analog Speed
- d SPd = Digital Speed Selection
- A tor = Analog Torque Control
- A SPd = Analog Speed Control
- SErSP = Serial Com. Speed Control
- bnSPd = Binary Speed Selection
- S PoS = Serial Position Control

Default setting: bnSPd

Value	Control mode	Direction Selection
AbSPd	Abs. Analog Spd. Control 0...+10V terminals X2A.1, X2A2	terminals X2A.14, X2A.15
d SPd	Digital Speed Control ter- minals X2A.10, X2A.11, X2A.12,X2A.13	terminals X2A.14, X2A.15
A tor	Analog Torque Control -10V...0... +10V terminals X2A.1, X2A2, X2A.3, X2A4	terminal X2A.14, does not determine direc- tion used only for triggering the start sequence
A SPd	Analog Speed Control -10V...0...+10V terminals X2A.1, X2A2	terminals X2A.14 & X2A.15 do not determine direction. Used only for trig- gering the start sequence
SErSP	Digital Serial Speed Con- trol Serial communication 16 bit signed speed value	Serial communication 16 bit control word
bnSPd	Binary Speed Con- trol terminals X2A.11, X2A.12, X2A.13	terminals X2A.14, X2A.15
S PoS	Digital Serial Position Control Serial communication 32 bit position value.	Serial communication 16 bit control word

When LF.2 = A tor then: max. system speed is approximately 110% of (LF.20)

When LF.2 = AbSPd or A SPd then: 0 ... ±10V = 0 ... ± max. system speed (LF.20)

Parameter Description - Basic Set Up

a) Analog set speed selection LF.02 = Ab5Pd



A unipolar analog signal is connected to the terminals X2A.1(+) and X2A.2 (-). Terminals X2A.3 and X2A.4 can be used for pre-torque input. Additionally with this setting the analog output (X2A.5) for motor speed becomes unipolar as well.

0 ... 10V = 0 ... max. system speed (LF.20)

Terminals X2A.14 and X2A.15 are used to select direction and activate the start and stop routine. The directions below must be followed in the exact sequence they are listed:

- Start:
- 1.) Enable on X2A.16=on
 - 2.) "Direction" input terminal (X2A.14 = on or X2A.15) = on
 - 3.) Drive commences current check and magnetizes the motor. When ready it will activate the DRO output X2A.27...29.
 - 4.) Give analog speed signal
- Stop:
- 1.) Analog signal => 0V
 - 2.) Terminal X2A.14 / X2A.15 = off
 - 3.) Enable X2A.16=off after the sum of the times adjusted in LF.78 and LF.79.

b) Input coded set speed selection LF.02 = d 5Pd

Digital speed setting uses preset digital values in the drive as command speeds. The drive creates the driving profile between selected speeds.

	X2A.10	X2A.11	X2A.12	X2A.13			
Speed =0	0	0	0	0			
S _{Leveling}	1	0	x	x			
S _{High Leveling}	0	1	x	x			
S _{Intermediate}	1	1	x	x			
S _{High}	0	0	1	x			
S _{Inspection}	0	0	0	1			

Symbol: 1 = Input is active
 0 = Input is not active
 X = Setting has no effect or don't care

c) Analog Torque control LF.02 = R tor

The differential analog signals are connected to the terminals X2A1(+) and X2A2(-) and X2A3(+) and X2A4(-). The actual torque command is the sum of the differential inputs.

Torque command = (X2A1 - X2A2) + (X2A3 - X2A4)



In a torque controlled system the maximum speed is controlled by the elevator control not the drive. However for safety reasons the drive will internally limit the speed to 110% of LF.20 or contract speed.

Terminal X2A.14.5 is used to activate the starting and stopping routine. The directions below must be followed in the exact sequence they are listed:

- Start:**
- 1.) Enable X2A.16=on
 - 2.) Select direction input X2A.14
 - 3.) Drive commences current check and magnetizes the motor. When ready it will activate the DRO output X2A.27...29.
 - 4.) Controller gives analog torque signal

- Stop:**
- 1.) Analog signal => 0V
 - 2.) Direction X2A.14 = off
 - 3.) Enable X2A.16=off after the sum of the times adjusted in LF.78 and LF.79.

d) Analog set speed selection LF.02 = R SPd

A Differential analog signal is connected to the terminals X2A.1(+) and X2A.2 (-). Terminals X2A.3 and X2A.4 can be used for pre-torque input.



0 ... ±10V = 0 ... ±max. system speed (LF.20)

Terminals X2A.14 and X2A.15 are used to activate the start and stop routine. The directions below must be followed in the exact sequence they are listed:

- Start:**
- 1.) Enable on X2A.16=on
 - 2.) "Direction" input terminal (X2A.14 = on or X2A.15) = on
 - 3.) Drive commences current check and magnetizes the motor. When ready it will activate the DRO output X2A.27...29.
 - 4.) Give analog speed signal

- Stop:**
- 1.) Analog signal => 0V
 - 2.) Terminal X2A.14 / X2A.15 = off
 - 3.) Enable X2A.16=off after the sum of the times adjusted in LF.78 and LF.79.

Parameter Description - Basic Set Up

e) Digital serial communication LF.02 = 5Er5P

Serial communication is used to operate the drive in speed control mode. The cyclic serial update rate at 56kbps is about 11mSec. The default serial parameter channel assignments are listed below. Other assignments are possible and are freely assigned via the serial communication. Consult the manufacture for more information on implementing this control scheme.

Digital commands to the drive

The command speed is a 16 bit signed value representing the motor speed.

The control word is a 16 bit value which is used to digitally activate the inputs (enable, direction, reset, etc).

The pre-torque is an 11 bit signed value which is used to provide roll back compensation.

Digital commands from the drive

The actual speed is a 16 bit signed value representing the actual motor speed as measured by the encoder.

The status word provides the status of the drive in addition to the output conditions.

The actual torque provides the torque value back to the controller.



In this mode parameter changes on the keypad are locked out while LF.3 = run. Parameters can be viewed at any time. With the car stopped, change LF.2 = Stop to change the parameters values manually via the keypad.



A short cut exists to toggle between run and Stop. From whatever parameter is currently being viewed, press and hold the FUNC and STOP button to change LF.3=Stop. The display will show “Stop” and returns to the previous parameter. It is now possible to change the parameter value. Press ENT to store the value. Likewise, to toggle to run mode, press and hold the FUNC and START key. The display will confirm by displaying run and then return to the previous parameter.



Once in run mode, the drive must see a serial communication request at the X6C serial port at minimum every 50mSec. If not the drive will trigger an E.BUS fault.

To clear an E.BUS error while in serial com mode: when in this mode, if the controller stops communication with the drive, it may not be possible to clear the E.BUS fault and view other parameters. Therefore the following can be used to override the error such that trouble shooting can occur.

While the display shows E.BUS press and hold both the ENT and the START key. The display will show the previously displayed parameter and allow navigation of the parameters. The internal fault will not reset until the serial communication has been reestablished

f) Binary coded set speed selection LF.02 = bnSPd

Binary speed setting uses preset digital values in the drive as command speeds. The drive creates the driving profile between selected speeds. The inputs are binary coded to allow up to seven speeds. Additionally in this mode, more advanced and multiple profiles can be established. See parameters LF.41...LF.56. One speed can be pre-defined as an emergency run speed in which the drive operates automatically under emergency operation conditions. See parameter LF.61 for more details.

	X2A.10	X2A.11	X2A.12	X2A.13	Para.		
Speed =0	x	0	0	0			
S _{Inspection}	x	1	0	0	LF.43		
S _{Leveling}	x	0	1	0	LF.41		
S _{High_Leveling}	x	1	1	0	LF.44		
S _{High}	x	0	0	1	LF.42		
S _{Intermediate_1}	x	1	0	1	LF.45		
S _{Intermediate_2}	x	0	1	1	LF.46		
S _{Intermediate_3}	x	1	1	1	LF.47		

Symbol: 1 = Input is active
 0 = Input is not active
 X = Setting has no effect or don't care

Parameter Description - Basic Set Up

g) Digital serial position control LF.02 = 5 P05

Serial communication is used to operate the drive in position control mode. The cyclic serial update rate at 56kbps is about 11mSec. The default serial parameter channel assignments are listed below. Other assignments are possible and are freely assigned via the serial communication. Consult the manufacture for more information on implementing this control scheme.

Digital commands to the drive

A 32 bit position value representing the distance to the floor is given to the drive. The drive uses this value to create the run profile and drive the elevator to the floor.

The control word low is a 16 bit value which is used to digitally activate the inputs (enable, direction, reset, special operating modes etc).

The control word high is a 16 bit value which is used to select special operating modes.

Digital commands from the drive

The actual speed is a 16 bit signed value representing the actual motor speed as measured by the encoder.

The status word provides the status of the drive.

The drive output word provides the status of the output functions.



In this mode parameter changes on the keypad are locked out while LF.3 = run. Parameters can be viewed at any time. With the car stopped, change LF.2 = Stop to change the parameters values manually via the keypad.

A short cut exists to toggle between run and Stop. From whatever parameter is currently being viewed, press and hold the FUNC and STOP button to change LF.3=Stop. The display will show “Stop” and returns to the previous parameter. It is now possible to change the parameter value. Press ENT to store the value. Likewise, to toggle to run mode, press and hold the FUNC and START key. The display will confirm by displaying run and then return to the previous parameter.

See also the top of page 84!



Drive configuration

This parameter is used to put the drive into different modes. The modes are defined below.

- Value range:
- run Run mode. All normal functions.
 - conF Configuration mode. Used in special cases to trouble shoot operation
 - StoP Drive stopped. Motor can not run, drive will not respond. When using serial com, this mode allows parameter changes.
 - S Lrn System Learn. Auto tunes the drive to the motor. Refer to section 5.5.3 and 5.6.3 for instructions.
 - I Lrn Inertia Learn. Learns the system inertia and activates the FFTC.
 - P Lrn Pole Learn. Learns the pole positions of PM motors. Refer to section 5.11.1 and 5.11.2 for instructions.
 - OSSt Over Speed Test Function. Allows the car to over speed the machine to test the governor. Refer to section 5.13.1 for instructions.
 - SPI Static Pole Learn. Learns the absolute encoder position for a PM machine under the brake without sheave movement. Refer to section 5.11.1 for instructions.

Default setting: Stop



This parameter is time limited for safety. Once conF is activated you have 90 seconds to complete the task at hand. After the timer runs out, the mode will change to StoP. It will be necessary to change back to conF thus resetting the timer to continue. Once all set up is complete set this parameter to run.

A short cut exists to toggle between run and StoP. From whatever parameter is currently being viewed, press and hold the FUNC and STOP button to change LF.3=StoP. The display will show “Stop” and return to the previous parameter. It is now possible to change the parameter value. Press ENT to store the value. Likewise, to toggle to run mode, press and hold the FUNC and START key. The display will confirm by displaying run and then return to the previous parameter.

Parameter Description - Basic Set Up



Selected motor

This parameter displays the current mode of operation, open or closed loop, geared or gearless, induction motor, synchronous motor. The parameter is read only.


Possible displays:

ICLSd = Closed loop induction

I9L55 = Closed loop induction gearless

PCLSd = Closed loop permanent magnet

P9L55 = Closed loop permanent magnet gearless



Drive fault auto reset

With LF. 5 all drive faults can be automatically reset.

The number adjusted in this parameter determines how many times per hour the elevator drive will automatically reset faults. Before resetting the fault, the drive will wait 4 seconds to allow everything to stop or stabilize. It is not fault specific, so with the default setting of 5, if the drive experiences 6 different faults in one hour the unit will latch the last fault and not reset. See parameter LF.98 for fault history information.

Unit: 1
Value range: 0...10
Default setting: 5

Note: a setting of "0" means no fault resets.



Electronic motor overload protection

This parameter is used to activate and select the type of motor overload function. Depending on the setting of this parameter, the Elevator Drive will trigger a drive fault E.OH2 causing the motor to stop. The trigger level is established in parameters LF.9 or LF.12


Value range: off...on
 Default setting: off
 Adjustment value: as required



This function must be activated to ensure the motor protection function is operational!

The trip curve is in accordance with VDE 0660 Part 104, UL508C section 42, and NFPA 70 Article 430 part C. It is defined as follows:

- 100% of trip current => continuous running
- 120% of trip current => trip after 2 hours
- 150% of trip current => trip after 2 minutes
- 200% of trip current => trip after 1 minute
- 800% of trip current => trip after 5 seconds



Parameter Description - Motor Data



The following parameters configure the Torqmax Elevator Drive to the particular motor. Correct adjustment of these parameters is critical for proper operation of the system. Depending on the mode of operation the units and or range of acceptable values may change. Parameters LF10 through LF.19 have dual functions depending on the type of motor.

For induction motor configuration modes the parameter information will be indicated with the symbol



For synchronous permanent magnet motors, configuration mode the parameter info will be indicated with the symbol



**Electronic
motor overload
current**



This parameter sets the current threshold in amps above which the Elevator drive activates the motor overload function.

Unit: ampere
Value range: 1.0...1.1 x drive rated current
Default setting: 8.0A
Adjustment value: in accordance with motor nameplate



For PM motors the current threshold is set equal to the rated motor current in LF.12. Therefore this parameter is not visible.



Rated motor power



Enter the rated power of the motor.

Unit: hp
 Value range: 0.0...125 hp
 Default setting: 5.0 hp
 Adjustment value: in accordance with the motor name plate



The power value is calculated from the torque and speed. Therefore this parameter becomes read only.



Rated motor speed



Unit: rpm
 Value range : 10.0....6000.0 or 500.0
 (based on config mode)
 Default setting: 1165.0 or 150.0
 (based on config mode)

Adjustment value: in accordance with the motor name plate



You may not enter the motor-synchronous speed (e.g. 1800 rpm for a 4 pole motor, 1200 rpm for a 6 pole motor, and 900 rpm for a 8 pole motor). Ask the manufacturer for the motor rated speed if you cannot find it on the name plate or use the following example to estimate the rated speed.

Example: If the name plate reads 1200 rpm (synchronous speed) then the value that should be entered must be lower. For starting purposes, one can estimate the slip at about 2.9%. Then through running the elevator it is possible to determine whether further adjustments are necessary. 2.9% of 1200 is 35 rpm. So for starting, use the value 1200 - 35 = 1165 rpm which is the default value.

LF.11 Valid Adjustment Range for 60Hz motors

From this parameter along with the rated frequency in LF.13, the Torqmax Elevator Drive calculates the number of motor poles. As a result there are limits as to how low the value can be adjusted for a motor with a certain number of poles. Refer to the table to the right for the valid adjustment range of 60Hz motors.

4 poles	1201...1799 rpm
6 poles	901...1199 rpm
8 poles	721...899 rpm
10 poles	601...719 rpm

Parameter Description - Motor Data



Rated motor speed



Unit: rpm
Value range : 10.0....6000.0 or 500.0
(based on configuration mode)
Default setting: 1165.0 or 150.0
(based on configuration mode)

Adjustment value: in accordance with the motor name plate

For permanent magnet synchronous motors there is no slip. Therefore the value entered must be exactly the synchronous rotational speed based on the rated frequency as noted below. Do not round this value off to the nearest whole number. With this there is no further adjustment necessary.

$$LF.11 = \frac{LF.13 \times 120}{\text{motor poles}}$$



Rated motor current



Enter the motor nameplate rated current (FLA).



Unit: ampere
Value range: 1.0...1.1 x Inverter rated current
Default setting: 8.0 A
Adjustment value: in accordance with the motor name plate



Rated motor frequency



Enter the exact rated frequency of the motor.



Unit: hertz
Value range: 4.0...100.0 Hz
Factory setting : 60.0 Hz
Adjustment value: in accordance with the motor name plate

LF.14

Rated motor voltage



Enter the name plate rated voltage.

Unit: volt
 Value range: 120...500 V
 Default setting: 230 or 460 V based on drive voltage
 Adjustment value: in accordance with the motor name plate



Enter the no load phase to phase back EMF rms voltage at rated speed (LF.11).

Unit: Vrms / at rated speed
 Value range: 1..32000 V
 Factory setting : none
 Adjustment value: in accordance with motor data sheet



Note: this is not the motor name plate voltage. When not sure use 80% of motor nameplate.

This value is measured during auto tuning and will provide the best value.

If this value is adjusted too high, the result may be E.OS errors as soon as the car tries to move. In this case lower this value and perform the autotune of the motor.

LF.15

Power factor



This parameter is not the efficiency of the motor but the ratio of the magnetizing current to the total phase current of the motor. Lower power factor values will increase the magnetizing current to the motor and thus increase the field strength resulting in tighter control of the motor. Higher values decrease the magnetizing current and the field strength.

Unit: 1
 Value range: 0.50...1.00
 Default setting: 0.90
 Adjustment value: in accordance with the motor name plate

Note: If not known, a value of 0.9 is recommended for old high slip motors and a value of 0.65 is recommended for gearless induction motors.



For PM motors this parameter is not required and therefore is not visible.

Parameter Description - Motor Data

LF.16

Field weakening speed




The field weakening speed determines at which speed the peak torque limit starts being reduced. It is necessary to reduce the peak torque limit of the motor since the drive's ability to force current into the motor is limited by the applied voltage as rated speed is reached.

If the drive tries to demand more torque than the motor can produce given the available voltage and actual motor speed, it is possible that the breakdown torque of the motor will be exceeded and as a result the motor will appear to stall and run at less than desired speed.

Generally this phenomenon can be identified as the car reaches contract speed momentarily but then drops to a lower speed or the car speed stalls at some speed lower than contact speed. Monitor parameter ru.42. If the value is reaching 100% or higher, the voltage limit is being reached. As a result the peak torque command must be further limited in order to maintain control of the motor.

The solution is simply to reduce the value of LF.16 to about 60% of synchronous speed (720 rpm for a 1200 rpm motor). A setting of 45% of synchronous speed should be used as the practical lower limit of this parameter.

Unit: rpm
Value range: 0.0...6000 rpm
Default setting: 960.0 rpm
Initial adjustment value: approx. 80% of synchronous speed



For PM motors this parameter is not necessary and therefore is not visible.

LF.17

Rated motor torque



For IM the torque value is calculated from the rated speed (LF.11) and rated power (LF.10). Therefore this value is read only.

Unit: lb ft
 Value range: 1..10000 lb ft
 Default setting: Calculated



For PM motors the torque value must be entered and is used to establish the torque constant. Enter the rated name plate torque.

Unit: lb ft
 Value range: 1..10000 lb ft
 Default setting: 18 lb ft
 Adjustment value: enter the motor name plate value

Some motors have the torque stated in Nm. To convert Nm to lb ft: multiply Nm by 0.738.

If the torque is not listed on the name plate you may use the the following equations to calculate the torque:

$$\text{Torque [lb ft]} = \frac{\text{Name plate HP} \times 5258}{\text{Nameplate Speed (rpm)}}$$

OR

$$\text{Torque [lb ft]} = \frac{\text{Name plate kW} \times 7043}{\text{Nameplate Speed (rpm)}}$$

OR

$$\text{Torque [lb ft]} = \frac{\text{Name plate Nm}}{1.355}$$

Parameter Description - Motor Data

LF.18

PM motor resistance



This parameter not required for closed loop induction motor operation and will not be visible in these modes.



For PM motors enter the phase to phase resistance value. Some motor manufacturers list the per phase value therefore you must multiply by two. This value can also be measured by the drive's auto-tune function, see parameter LF.3. Incorrect settings of this parameter could lead to oscillation in the current control and audible noise in the motor, since the regulator values for the current control are calculated from this value.

Unit: ohms
Value range: 0.000...49.999
Default setting: 1.000
Adjustment value: enter the motor resistance value

LF.19

PM motor inductance



This information is not used for induction motors and therefore the parameter is not visible in induction motor mode.



This is the total phase to phase reflected leakage inductance of the motor winding. The inductance listed on the manufacturer's data sheet will most likely be for one phase. So it will be necessary to multiply the value by two and then enter it into the drive. This value can also be measured by the drive's auto-tune function, see parameter LF.3. Incorrect settings of this parameter could lead to oscillation in the current control since the regulator values for the current control are calculated from this value.

Unit: mH
Value range: 0.01...500.00
Default setting: 1.00
Adjustment value: enter the value from the manufacturer's data sheet.



The following parameters relate to the machine data of the elevator. It is important to enter the correct values, such that both the motor and the car run at the correct speed.

LF.20

Contract speed

This is the elevator contract speed.

The speeds adjusted in parameters LF.42...LF.47 are limited by LF.20. Other internal values are calculated from LF.20.

With an analog speed signal the following is valid:

$$0 \dots \pm 10V = 0 \dots \pm \text{contract speed (LF.20)}$$

Unit: feet per minute

Value range: 0...1600ft/min

Default setting: 0 ft/min

Adjustment value: maximum speed of the system



If the motor does not run at the correct speed do not adjust this parameter! See parameter LF.22.

LF.21

Traction sheave diameter

Unit: Inches

Value range: 7.00...80.00 in

Default setting: 24.00 in

Adjustment value: measure the sheave diameter

LF.22

Gear reduction ratio

Enter the actual gear ratio. If the ratio is not known, see parameter LF.25 and enter the value from LF. 25 into LF.22

Unit: 1

Value range: 1.00 ... 250.00

Default setting: 30.00

Adjustment value: in accordance with the gear name plate,



The ratio can be determined by counting the revolutions of the motor during one rev of the traction sheave.

Once the car is running on high speed, if the measured speed is slightly above or below the contract speed, the gear ratio can be changed slightly to compensate. Higher values in LF.22 will increase the car speed, lower values will decrease the car speed. Make very small changes at first!

Parameter Description - Machine Data

LF.23

Roping ratio

Unit: 1
Value range: 1...8 (1:1...8:1)
Default setting: 1
Adjustment value: in accordance with the system data

LF.24

Load weight

Unit: pounds
Value range: 0...30000lbs
Default setting: 0 lb
Adjustment value: in accordance with the system

LF.25

Estimated gear reduction

This parameter is read only and will change when adjustments are made to LF.11, LF.20, LF.21 or LF.23.

This parameter can be used to estimate the gear ratio if it is not known. After correctly entering values into LF.11, LF.20, LF.21, and LF.23, read this value and then enter this value into LF.22. Then to verify, run the car at inspection speed, measure the actual speed with a hand tach. If the car speed is slower than the adjusted inspection speed (LF.43), then increase LF.22. If it is higher than the adjusted inspection speed, decrease LF.22.

Note: If LF.20 = 0.00 ft/min the value of LF.25 will be the same as the last calculated value.

Unit: .01
Value range: 1.00...99.99

Parameter Description - Encoder Set Up



This parameter displays the type of encoder feedback installed in the drive. It is also used to reset E.ENCC error. Under normal operation this parameter displays the type of encoder feedback card installed in the drive. See the list below.

Additionally, if an E.ENCC error has occurred, and the problem has been corrected, the error can be reset by displaying the value of 0.LF.26 and pressing ENTER. This is the only way to manually reset the E.ENCC error. See 2.LF.26 below for more information on E.ENCC errors.

Display	Channel 1 (X3A)	Channel 2 (X3B)
noInt	No feedback card installed	
SSI	5V TTL incremental Synchronous Serial Interface, absolute multi turn position encoder	
rESoL	Resolver	5V TTL incremental output
HIPEr	Hiperface	5V TTL incremental output
Inc24	15-24V HTL incremental	5V TTL incremental output
IncIE	5V TTL incremental	5V TTL incremental output
SinCo	Sine Cosine / -SSI	5V TTL incremental output
I24PE	15-24V HTL incremental	5V TTL incremental output
EnDat	EnDat	5V TTL incremental output
PhASE	UVW	5V TTL incremental output



This parameter displays the type of encoder connected to the drive. It is only supported by HIPERFACE, EnDat or SIN/COS-SSI encoders.

Operator	Encoder
Display	Type
noEnc	No Encoder Detected
SCS67	SCS 60/70
SCn67	SCM 60/70
SinCo	SIN/COS no abs.
SinCo	SIN/COS abs.
SSI	SSI abs.
Sr556	SRS 50/60
Srn56	SRM 50/60
EnDat	EnDat
EnDat	EnDat Single Turn
EnDat	EnDat Multi. Turn
EncUn	Encoder Undefined



This parameter displays the status of the connected encoder along with error messages and in case of a malfunction. It is only supported by HIPERFACE, EnDat or SIN/COS-SSI encoders.

Refer to the table on the following page for possible displays and their meanings.



When the status of the encoder interface changes to a value other than “communication established” conn, and the drive is enabled, the drive will trigger an E.ENCC fault. Press enter and the drive will change the display to this parameter and show the fault code. Once the problem has been corrected, the E.ENCC fault can be cleared by displaying the value of parameter 0.LF.26 and pressing enter.

Parameter Description - Encoder Set Up

2LF26 Fault Codes

Display	Description	Fault cause and solution
conn	Serial Com. Established	Position values are being transferred to the encoder, encoder and serial interface are working.
EncId	Unknown encoder ID	Encoder is an unknown type and does not support the required serial communication protocol. Encoder is the wrong type, i.e. EnDat connected to a HIPERFACE feedback card. Solution: verify encoder type.
bdCbi	Cable break. inc. channels	The interface looks at each incremental channel for the idle voltage value of 2.5V with reference to common (pin 13). If this voltage is not present an error will be triggered with this fault code. Solution: check all signal connections, replace cable with new. 1)
bdCba	Cable break. abs. channels	The interface looks at each data or clock channel for the idle voltage value of 2.5V with reference to common (pin 13). If this voltage is not present an error will be triggered with this fault code. Solution: check all signal connections, replace cable with new. 1)
PoSde	Position deviation too high	The position deviation between the incremental channels and the absolute values is greater than 2.8 degrees. On SIN/COS the comparison is made between occurrences of the zero pulse. Too many or too few counts between the zero pulse will trigger this error. Normally, this is caused by a bad encoder cable and/or poor shielding and grounding of the cable. Solution: replace the cable. 1)
BdPPr	Enc. ppr does not match	Compares the internal value of ppr stored inside the encoder with the setting of LF.27. If they do not match this error code will be activated. Solution: verify correct encoder ppr and enter it in LF.27.
BdInt	Interface Card not recognized	The serial interface card is not recognized by the main CPU of the drive. Replace the feedback card.
bdSuP	Bad internal enc. supply	The internal power supply of the encoder has failed
OHEnc	Encoder over heat	Encoder temp is measure by the encoder and the error is passed on to the drive via serial com.
OSEnc	Encoder over speed	Actual speed has exceeded the max speed of the encoder.
ErEnc	Internal encoder failure	Internal encoder signals are incorrect or out of tolerance. Replace the encoder
FrtEn	Formatting the encoder	The encoder will be formatted according to the prescribed structure. This will allow further read/write cycles to occur.
nEEnc	New encoder found	The feedback card has recognized that a new or different encoder is now connected to the drive. Therefore it is necessary to confirm. Reenter the values in LF.26,LF.27,LF.77. This message can also occur if the cable is incorrectly wired or the encoder is damaged. Try to swap the cables or encoders in this case.
noFrt	Encoder memory not formatted	Encoder memory structure is not valid and therefore can not be read
EncBS	Encoder is busy	The encoder is busy during data transfer and cannot accept the transmission.
OFF	No com to Enc. Card	There is no communication between the encoder and the drive.

1) If the cable is coiled up in the control panel, try uncoiling it out onto the floor in case this is the problem.

3LF.26

This parameter reads or writes data from or to the encoder. It is only supported by HIPERFACE or EnDat encoders.


When the encoder is supplied pre installed from the motor manufacturer, the motor manufacturer can store the motor data information in the encoder. This allows the end user to simply read out the motor data from the encoder and thus avoid having to enter the motor data, auto tune the motor, or learn the encoder position.



Follow the procedure carefully as it is possible to overwrite the stored data with no chance to recover the stored values.

Reading data from the encoder

Start



r d E n c

ENTER
F/R

n o

START

y e s

ENTER
F/R

r E A d


n o p

Enter YES to confirm. Drive will read encoder data, update the parameter values and then reprogram itself using the new values.

Finished

Parameter Description - Encoder Set Up

Storing data to the encoder



The parameters which are saved in the encoder are the following:
LF.10...LF.19, Ld.27, Ld.28, 0.LF.36, LF.77

If there is a problem in the process of reading or storing the data, the display will give an error message. The most common cause of these problems is a bad encoder cable or improperly formatted encoder.

LF.27

Encoder pulse number

Unit: pulse per revolution
 Value range: 256...16384 pulse per revolution
 Default setting: 1024 pulse per revolution
 Adjustment value: in accordance with the manufacturer specifications



If the incremental encoder pulse number is not correctly adjusted, the elevator drive can run very slowly, or over-speed is possible or other unforeseen conditions may occur. Therefore, it is absolutely necessary to adjust this parameter correctly.

LF.28

Encoder channel swap / direction

This parameter can be used to swap the two encoder channels, reverse the direction of the entire system, or both swap encoder channel and reverse the system direction. **See also section 5.11.4**

Unit: 1
 Value range: 0...3
 Default setting: 0
 Adjustment value: 0 nothing reversed
 1 encoder change A <--> B swapped
 2 motor rotation reversed
 3 motor rotation reverse and A<-->B swapped

LF.29

Encoder sample time

This parameter is used to adjust the sample time of the encoder feedback for calculation of the actual motor speed value. With certain motors or encoders it may be beneficial to use a time other than the factory setting. Lower values lead to higher bandwidth and faster response times of the motor. However lower values also increase the systems susceptibility to electrical noise on the encoder signal. Therefore on some systems having higher noise levels, lower values may not be suitable. If this electrical noise is a problem, the motor will produce an audible noise while running.

Unit: -
 Value range: 0_5, 1, 2, 4, 8, 16, 32 mSec
 Default setting: 4 mSec
 Adjusted value: based on application requirements

Example: with a 4 mSec sample time the resulting speed measurement resolution using a 1024 encoder is +/-3.5 rpm. A setting of 8 mSec gives +/-1.8 rpm.

With Sin/Cos, Hiperface, EnDat encoders see also parameter LF.76 for extended resolution adjustments.

Parameter Description - Control Settings



Control Mode

Used in conjunction with LF.2 to adjust the control method.

Unit: 1
Value range: 0...5
Default setting: 0

Adjustment values

- 0 Open loop induction motor operation for construction, inspection and test purposes only.
- 1 Open loop induction motor operation with sensorless motor management, Valid when LF.2 = AbSPd, d SPd, A SPd, SErSP, bnSPd
- 2 Closed loop speed control. Valid when LF.2 = AbSPd, d SPd, A SPd, SErSP, bnSPd
- 3 Closed loop speed control with pre-torque input active. Valid when LF.2 = AbSPd, d SPd, A SPd and using a load weight system to provide a pre-torque signal to the drive. Analog inputs X2A.3 and X2A.4 serve as the pre-torque input.
- 4 Closed loop torque control. Valid when LF.2 = A tor. Both analog inputs serve as torque inputs and are internally summed together.
- 5 Closed loop speed control with synthesized pre-torque. Valid when LF.2 = AbSPd, d SPd, A SPd, SErSP, bnSPd. Provide a synthesized pre-torque without a load weigher. See parameters US.17, US.18, US.31 and US.32 for further adjustment.



When using induction motors, the TORQMAX F5 can be run open loop in inspection to verify whether the encoder functions normally. By setting the parameter LF.30 = 0, the inverter runs the motor open loop. The encoder feedback (motor speed) is displayed in parameter LF.89 but has no effect on the operation of the motor. Therefore, this mode can be used to verify whether the encoder is functioning properly. Generally, when running empty car up the actual motor speed in LF.89 should be equal to the set speed in LF.88. If these values are off by more than 20 rpm when running empty car up, there is most likely an encoder or encoder cable problem.

When using permanent magnet synchronous motors only closed loop operation (2,3,4,5) is permitted.



Running the TORQMAX open loop, in automatic mode, at high speed or leveling speed can result in high motor currents and or poor performance. Always verify that this parameter is set correctly before running in automatic mode!

A.L.F.31

Kp speed accel.

d.L.F.31

Kp speed decel.

P.L.F.31

Kp speed pretorque

The proportional gain of the speed controller is split into two values, one for acceleration and constant run and one for deceleration. This provides the greatest degree of flexibility. The default values are set the same for both and will work for most applications. However if the motor does not track the speed command tight enough, then the value should be increased. If the motor makes audible noise or vibration in the car, then the gain value should be reduced. Adjustment steps of +/- 250 are reasonable.

Unit: 1

Value range: 1...32767

Factory setting : 3000 Accel. , 3000 Decel. , 2000 Pre-torque

The pre-torque gain setting is used to provide control during the pre-torque phase. In most cases it is not necessary to adjust the proportional gain. However, if a vibration is felt in the car during the pre-torque phase this gain can influence it. Try values of 500, 1000, 4000, and 6000 to determine whether or not there is any influence.

A.L.F.32

Ki speed accel.

d.L.F.32

Ki speed decel.

P.L.F.32

Ki speed pretorque

The integral gain of the speed controller is split into two values, one for acceleration and constant run and one for deceleration. The default values are a good starting point and will work for most applications. Higher integral values can lead to pulsation during acceleration and deceleration.

Unit: 1

Value range: 1...32767

Default setting: 350 Accel. , 250 Decel. , 10000 Pre-torque

The pre-torque gain setting controls the rate of the build of torque and the stiffness of the motor as the brake releases. Once the pre-torque timing is adjusted, this gain can be adjusted to control the strength of the pre-torque. In general lower spring tension and lower brake pick voltages result in a smoother transition of the load from brake to motor. This gain should be adjusted as high as necessary to prevent the sheave from moving during break release. Typical values are between 5,000 and 20,000. If the value gets too high, vibration or audible noise in the motor may occur during the pre-torque phase. Refer to section 5.12.4 for more adjustment information.

Parameter Description - Control Settings



Ki speed offset accel.



Ki speed offset decel.

This gain value is effective only at low speeds. This value is added to the I term gain in LF.32 to provide greater control and more stability.

This offset acceleration gain will assist the motor in catching the load during starting. It is especially important for high efficiency geared or gearless applications. Values of 2,000 to 5,000 are useful.

The offset deceleration gain will allow the system track the command speed tightly at low speed. Often lower values are required than for starting. Values of 500 to 2,000 are useful.

Unit: 1

Value range: 0...8000

Default setting: 3000 Accel. , 1000 Decel.

The offset gain value is tapered off beginning at about 8 ft/min and the offset reaches zero at 24ft/min. The corner speeds can be adjusted through parameters US.20 and US.21.



Maximum torque



Max. torque emergency oper.

The peak torque limit prevents the motor from exceeding its breakdown torque limit. If the torque limit is reached, the acceleration process will take longer with a full load. This can also cause the car to over shoot the floor during deceleration. This value can be raised.

The maximum torque during emergency operation is activated through parameter LF.61. This allows the drive to limit the torque and therefore the output current to the rated value to prevent the drive from drawing too much current from a battery back up supply.

Unit: pound feet (lb ft)

Value range: 0.0...torque at the drive's current limit

Default setting 0.LF.36: For IM: 3 x Rated motor torque
(approx. 3 x LF.17)

For PM: 1.5 x Rated motor torque
(approx. 1.5 x LF.17)



This initial low setting protects the motor from high current in case the encoder position is wrong.)



Note: For PM motors to run with 100% load in the car, it may be necessary to raise this value to 200%...240% of LF.17 based on the motor manufacturers rated peak torque.


Default setting 1.LF.36: 1.LF.36 = LF.17



Open loop torque boost

Adjusts the torque boost only during open loop operation (LF.30=0). If the torque boost is too low the motor may not be able to lift the load. Too much boost can lead to high current while running open loop.

Unit: % of input voltage
 Value range: 0.0...25.5 %
 Default setting: 5.0 %
 Adjustment value: dependent on load



Switching frequency

Using parameter LF.38 the switching frequency of the inverter can be set. The switching frequency can be constantly 8 kHz or 16kHz with an automatic reduction based on the heat-sink temperature.



If the display often shows the error message E.OL2, then this parameter should be set to zero. Some power stages only support 8Khz. On these units it is not possible to change to this value.

Unit: 1
 Value range: 0 = switching frequency constantly 8 kHz
 1 = 16kHz with automatic reduction
 Default setting: 0
 Adjusted value: as needed

Parameter Description - Driving Profile

The run profile is defined by up to seven different speeds and up to three different sets of accelerations and decelerations. Various combinations of these are available depending on the mode of control adjusted in parameter LF.2. The following section describes the adjustment of the speeds and profiles.

A digital display showing the parameter code 'LF.41' in a segmented font.

Leveling speed, S_L

Leveling speed. The transition to zero speed is always made using the jerk adjusted in LF.56. this provides a very smooth approach to the floor. Acceleration from zero speeds uses profile 1.

Unit: feet per minute
Value range: 0...25 ft/min
Default setting: 0 ft/min
Adjustment value: approx. 4 ft/min

A digital display showing the parameter code 'LF.42' in a segmented font.

High speed, S_H

High speed. Acceleration from zero speed and deceleration to leveling or high leveling uses profile 0

Unit: feet per minute
Value range: 0...LF.20
Default setting: 0 ft/min
Adjusted value: LF.20 or smaller

A digital display showing the parameter code 'LF.43' in a segmented font.

Inspection speed, S_I

Inspection speed. Acceleration and deceleration rates are based on profile 1.

Unit: feet per minute
Value range: 0... 150 ft/min or LF.20 whichever is lower
Default setting: 0 ft/min
Adjusted value: approx. 35 ft/min

A digital display showing the parameter code 'LF.44' in a segmented font.

High leveling speed, S_{HL}

High leveling speed or second inspection speed. Can be also be used for short floor or one floor travel. Acceleration is based on profile 1, which can offer independent setting from profile 0 used in high speed operation.

Unit: feet per minute
Value range: 0...LF.20
Default setting: 0 ft/min
Adjusted value: dependent on use.

LF.45

Earthquake speed, S_{EQ}

Earthquake speed is available on Motion 4000 controllers which are programmed for that feature. It uses profile 0 acceleration and deceleration.

Unit: feet per minute
 Value range: 0...150 ft/min
 Default setting: 0 ft/min
 Adjusted value: as required

LF.46

Emergency gen. speed, S_{EG}

Emergency generator speed is available on Motion 4000 controllers which are programmed for that feature. It uses profile 2 acceleration and deceleration.

Unit: feet per minute
 Value range: 0...LF.20
 Default setting: 0 ft/min
 Adjusted value: as required

LF.47

Intermediate speed, S_{INT}

Intermediate speed is used on PTC controllers a uses profile 0 acceleration and deceleration. This speed can be assigned as TAPS operation speed.

Unit: feet per minute
 Value range: 0...LF.20
 Default setting: 0 ft/min
 Adjusted value: as required

LF.49

Over Speed Function Test

This parameter allows the user to test the over speed function of the drive. See Section 5.13.

Unit: feet per minute
 Value range: 1...2400 ft/min
 Step: 1
 Default setting: 100 ft/min
 Adjusted value: as required

Parameter Description - Driving Profile

The run profile is defined by jerks, acceleration, and deceleration. Each jerk, accel and decel holds three different values and is indexed through the offset number (lead number in front of the parameter number). These different values make up three different run profiles which are either assigned based on the selected speed or through another parameter. The adjustment range for each is the same although the default values vary.



When adjusting a profile, change the offset number first and then go to each parameter. The profile number will not change when switching between parameters making it easy to adjust one complete profile. Refer to section 4.3 for selecting the profile number.

In general higher values result in a hard/fast profile, while lower values give softer, slower transitions.

**Empirical values: 2.00...3.00 for retirement homes, hospitals, apartment buildings
3.00...5.00 for office buildings, banks etc.**

When LF.2 is set to AbSPd, A SPd or A Tor, the values of all profiles are automatically set to the maximum values "OFF" thus turning off the ramp generator.

When LF.2 is set d SPd, bnSPd or S PoS the default values are loaded in all profiles.

Profile 2 is used for emergency generator or TAPS operation as selected in parameter LF.61.

0LF50

1LF50

2LF50

Starting jerk

Sets jerk at start of the run.

Unit: feet per second³

Value range: (calc. min.¹⁾)...32.00 ft/s³ (OFF)

Default values:

Profile 0 = 3.0 ft/s³

Profile 1 = 3.5 ft/s³

Profile 2 = 1.5 ft/s³

0LF51

1LF51

2LF51

Acceleration

Sets the rate of acceleration.

Unit: feet per second²

Value range: 0.30...12.0 ft/s² (OFF)

Default values:

Profile 0 = 3.3 ft/s²

Profile 1 = 3.5 ft/s²

Profile 2 = 1.5 ft/s²

1) Calc.min. - The calculated minimum value depends on the value of the rate of acceleration or deceleration that the jerk must work with. Therefore the minimum jerk value is limited by the actual adjusted value of the acceleration or deceleration. If a lower jerk value is required, you must first reduce the rate of acceleration or deceleration.

0.L.F.52

1.L.F.52

2.L.F.52

Acceleration jerk

Sets the jerk during the roll into constant speed.
 Unit: feet per second³
 Value range: (calc. min.¹⁾)...32.00 ft/s³ (OFF)
 Default values:
 Profile 0 = 4.0 ft/s³
 Profile 1 = 4.5 ft/s³
 Profile 2 = 1.5 ft/s³

0.L.F.53

1.L.F.53

2.L.F.53

Deceleration jerk

Sets the jerk in the roll out of constant speed.
 Unit: feet per second³
 Value range: (calc. min.¹⁾)...32.00 ft/s³ (OFF)
 Default values:
 Profile 0 = 4.5 ft/s³
 Profile 1 = 5.0 ft/s³
 Profile 2 = 1.5 ft/s³

0.L.F.54

1.L.F.54

2.L.F.54

Deceleration

Sets the rate of deceleration.
 Unit: feet per second²
 Value range: 0.30...12.0 ft/s²
 Default values:
 Profile 0 = 3.5 ft/s²
 Profile 1 = 3.5 ft/s²
 Profile 2 = 1.5 ft/s²

0.L.F.55

1.L.F.55

2.L.F.55

Approach jerk

Sets the jerk during the final approach to the floor.
 Unit: feet per second³
 Value range: (calc. min.¹⁾)...32.00 ft/s³ (OFF)
 Default values:
 Profile 0 = 2.5 ft/s³
 Profile 1 = 3.5 ft/s³
 Profile 2 = 1.5 ft/s³




L.F.56




Stop jerk

Sets the jerk and rate of deceleration during the transition from leveling speed to stop.
 Unit: feet per second³
 Value range: off, 0.30...32.00 ft/s³
 Default value: 2.00 ft/s³

Parameter Description - Driving Profile

Graphical view of speed profiles Binary speed selection (LF.2 = 5 Po5)





Important! If the high speed, or high leveling speeds are turned off and leveling speed is not activated immediately afterward, the drive will use the stop jerk in LF.56 for the slowdown profile. This will result in a very slow deceleration of the car and may cause the car to overshoot the desired stopping point. Leveling speed must always be activated to ensure the normal deceleration profile.

Parameter Description - Driving Profile

Recommended Profile Settings

These are the recommended profile settings for the Motion 4000 controller when using standard 6 pole (1165 rpm) motors with geared machines. For other motors and gearless these values can also be used as a good starting point however, further adjustment may be required.

	Contract Speed [ft/min]					
	100	150	200	250	300	350
Start Jerk LF.50 [ft/sec ³]	1.0	2.0	2.75	3.1	3.0	3.0
Acceleration LF.51 [ft/sec ²]	0.9	1.7	2.75	3.3	3.3	3.3
Accel. Jerk LF.52 [ft/sec ³]	2.0	3.0	3.75	4.0	4.0	4.0
Decel. Jerk LF.53 [ft/sec ³]	2.5	3.0	3.75	4.0	4.25	4.5
Deceleration LF.54 [ft/sec ²]	1.8	2.25	2.6	3.0	3.25	3.5
Approach Jerk LF.55 [ft/sec ³]	2.5	2.5	2.5	2.5	2.5	2.5
Stop Jerk LF.56 [ft/sec ³]	2.0	2.0	2.0	2.0	2.0	2.0



The minimum jerk value is limited by the rate of acceleration or deceleration. If it is not possible to adjust the jerk rate lower, it may be necessary to lower the respective rate of acceleration or deceleration first and then try to lower the jerk.

LF.57

Speed following error

Triggers a drive warning if the actual motor speed deviates from the commanded speed by more than the window defined in parameter LF.58 and for the length of time defined in LF.59. This function only works in close loop speed control mode, ie. LF30=2,3 or 5.

Settings: 0 = Off (Use when LF.30 = 4)

1 = On, drive indicate speed following error when motor speed varies from the set speed by the amount in LF.58 and for the time in LF.59, output X2A.18 (or whichever output is programmed with ASD function).

LF.58

Speed difference

Sets the +/- window for the speed following error in percent of the set speed.

Unit: %
 Value range: 0...30%
 Default setting: 10%
 Adjustment value: as necessary

LF.59

Following error timer

Defines the length of time the following error can exist before the fault is triggered.

Unit: Seconds
 Value range: 0.0...1.0 sec.
 Default setting: 1.0 sec.
 Adjustment value: as necessary



When trying to trouble shoot the cause of this fault, it helps to increase LF.58 and LF.59 to the maximum values to prevent the fault from triggering.

Parameter Description



Emergency operation mode

Determines how the emergency power function is activated. The emergency power function allows the drive to run off of a UPS or battery back up system, 480V units can be run from a 230V 1 phase supply. 230V units can be run from a 230V 1 phase supply.

When active the under voltage fault level is reduced to 160VAC. The input phase failure detection is shut off, and the torque limit is reduced to the rated torque of the motor.

If a speed is programmed for this function, then whenever the speed is selected, the drive automatically goes into emergency operation. If the function is triggered by a digital input (X2A.10), the input must be active when the drive is enable and must remain active for at least one second.

Settings: Off = no function

SPd1 = Earthquake speed serves as the emergency operation speed.

SPd2 = Emergency Gen. speed serves as the emergency operation speed.

SPd3 = Intermediate speed three serves as the emergency operation speed.

di 1 = Digital input X2A.10 activates operation with TAPS.



Note: If a 480V unit is being powered from a 230V UPS system, the maximum car speed can be 50% of contract speed. Higher speeds will result in loss of control due to low DC bus voltage

A setting of SPd1, SPd2 or SPd3 can not be used if the one floor positioning function (LP.1 = P onE) of the drive is activated.

LF.67

Pre-torque gain

A car weighing system can be used to provide an analog signal to the elevator drive which is proportional to the load in the cabin. When LF.30 is set to 3, this analog signal is used to generate an exact counter torque to hold the car stationary when the brake is released. This is important for gearless speed control applications.

- 10 V	→ the car is empty	→ negative rated torque
0 V	→ car weight + half load = counterweight	→ 0
10 V	→ the car is full	→ positive rated torque

If the rated torque is too small or too large, it can be increased or decreased with LF.67.

Unit:	-
Value range:	0.25 ... 2.00
Default setting:	1
Adjusted value:	depends on the required torque

LF.68

Pre-torque offset

If the counter weight is not 50 % (cabin weight + 50% of max. load), the pre-torque can be adjusted with LF.68.

Unit:	%
Value range:	- 100.0 % ... 100.0 %
Default setting:	0 %
Adjusted value:	depends on the counter weight

LF.69

Pre-torque direction

This parameter can be used to invert the direction of the pretorque being applied to the motor.

Unit:	1
Value range:	0 => +10V = positive torque
	1 => -10v = positive torque
Default setting:	0
Adjusted value:	depends on the required torque direction

Parameter Description



Speed pick delay

For the Motion 4000 controller, this time delay allows the brake to release before the motor starts turning. With iControl the drive will hold the speed command at zero for the adjusted time thus overriding the speed pick delay adjusted in the controller.

Unit: seconds

Value range: 0.0...3.0 s

Default setting: 0.3 s

Adjusted value: 0.3 s



Note: When the pre-torque function is active (LF.30 = 3 or 5), the speed pick delay is the sum of the pre-torque ramp timers US.17 and US.18. Proper adjustment of these timers will automatically provide the required speed pick delay.



Brake pick delay

This time delays the release on the brake when the BRK output is used in the brake control circuit.

Unit: seconds

Value range: 0.0...3.0 s

Default setting: 0.05 s

Adjusted value: 0.05 s



Encoder resolution multiplier

This parameter can be used to increase the resolution of encoders with analog sine/cosine tracks. The encoder types are SIN/COS, Hiperface, EnDat.

Unit: 1

Value range: 0...13

Default setting: 2 for incremental encoders
8 for Sin/Cos, EnDat, or Hiperface encoders

The value corresponds to the multiplier using the following relation.

Actual Encoder Resolution = Encoder base ppr x $2^{(LF76)}$

Example: Sin/Cos encoder with base resolution of 2048 ppr

With LF.76 = 8 the actual measured resolution is:

$$2048 \times 2^8 = 524288 \text{ counts / rev}$$

Higher values give better resolution especially for gearless applications. However higher values make the system more susceptible to disturbances due to noise. Therefore the actual value which can be used will ultimately be limited by the noise being picked up on the encoder cable.



Absolute encoder position

This parameter is only visible in closed loop PM motor mode (LF.4 = PCLSD or P9LSS). LF.77 displays the position of the encoder in relation to one of the motor poles.

Unit: 1

Value range: 0 ... 65535h

Default setting: 0

Adjusted value: according to encoder position

If the position value is already known, simply enter the value in this parameter. If it is not known then follow the procedure in section 5.11.1 to measure the position. If the encoder was pre-programmed by the motor vendor, this value can be read out from the encoder in parameter 3.LF.26. Refer to section 5.8.3.



If the position is not known, then the drive will determine the correct position value. This process is best done when the motor is free to turn, i.e. without the ropes on the main sheave.

If it is not possible to remove the ropes from the sheave then it can be possible to make this measurement with a balanced car.

See section 5.11.1 and 5.11.2 for learn procedures.

Parameter Description



Brake engage time

This parameter determines how long the drive will maintain full current and control of the motor after the direction inputs, X2A.14 and X2A.15 have been turned off. After the adjusted time, motor current will continue to flow, however the analog input will be clamped and the speed control gains will be reduced. This time should be adjusted longer than the actual required time for the brake to mechanically drop.



Note: when using digital speed selection the selected speed input must be turned off before or at the same time as the direction input is turned off. When using analog or serial speed control, the command speed should be brought to zero before turning off the direction signal.

Unit: seconds

Value range: 0.00 ... 3.00 Seconds

Default setting: 0.50 Seconds



Current hold time

Once the time in LF.78 has expired, current will continue flowing to the motor, but the drive will ramp the motor torque down to zero over the time adjusted in LF.79. This provides a smooth transition of the load to the brake and a quiet de-energization of the motor. This time should be adjusted such that the drive shuts off the current before the controller drops the drive enable (X2A.16) and opens the motor contactor. If the drive enable is dropped before the current is shut off, it is possible the drive will respond with base block protection "BBL" which can prevent further operation for 1 to 3 seconds depending on the drive size. Therefore the times should be adjusted to prevent this. Additionally, during this time the speed control is turned off to prevent the motor from driving against the brake.



The total time between the drop of the direction signals (X2A.14 & X2A.15) and the turn off of motor current is LF.78 + LF.79. The time delay for dropping the enable (X2A.16) and the opening of the motor contact should be greater than the sum of LF.78 and LF.79.

Unit: seconds

Value range: 0.00 ... 3.00 Seconds

Default setting: 0.30 Seconds



Software version

Display of the software version of the Elevator Operator.



Software date

Display of the software date.

Format DDMM.Y

Note: The lead character of the date may be blanked if it is a zero.

Example: date code 0208.1 display reads as 208.1

Diagnostic Parameters

Terminal X2A



X2A Input state

This parameter displays the status of the digital inputs on terminal X2A. Each input has a specific value. See the table below for decoding.

Terminal			Description
Value	Number(s)	Function ¹⁾	
0	none	none	No signals are active on terminal X2A.10 to X2A.17
1	X2A.16	EN	Only the enable signal is active on X2A.16. Drive will not run until one of the direction signals on X2A.14 or X2A.15 are active
2	X2A.17	RST	Only the fault reset signal is active on X2A.17
4	X2A.14	U	Only the up signal is active on X2A.14. Drive will not run until enable signal on X2A.16 is active.
5	X2A.16,X2A.14	EN,U	Both the enable and up signals are active. This is normal during operation.
8	X2A.15	D	Only the down signal is active on X2.4. Drive will not run until enable signal on X2.1 is active.
9	X2A.16,X2A.15	EN,D	The enable and down signals are active. This is normal during operation.
16	X2A.10	I1	Only the option input signal at X2A.10 is active. Drive will not run until enable signal on X2A.16 and direction signal on X2A.14 or X2A.15 are active.
17	X2A.10,X2A.16	EN,I1	Both the enable and option input signals are active. A direction signal is required to allow operation.
21	X2A.10, X2A.14, X2A.16	EN,U,I1	Enable, up and option input signals are active. In analog speed mode, the drive should run.
25	X2A.10, X2A.15, X2A.16	EN,D,I1	Enable, down and option input signals are active. In analog speed mode, the drive should run.
32	X2A.11	INS	Only the Inspection speed signal is active. Drive will not run until enable signal on X2A.16 and direction signal on X2A.14 or X2A.15 are active.
33	X2A.11,X2A.16	EN,INS	Both the Enable and Inspection speed signals are active. A direction signal is required to allow operation.
37	X2A.11, X2A.14, X2A.16	EN,U,INS	Enable, Up and Inspection speed signals are active. The drive should run in binary speed mode.
41	X2A.11, X2A.15, X2A.16	EN,D,INS	Enable, Down and Inspection speed signals are active. The drive should run in binary speed mode.

1) Function is described for Binary speed selection (LF.2 = bnSPd). If using digital speed selection use terminal number and table for LF.2=d SPd on page 73.

On the Motion 4000 controller only the enable input is used.

Terminal			Description
Value	Number(s)	Function	
64	X2A.12	L	Only the Leveling speed signal at X2A.11 is active. Drive will not run until enable signal on X2A.16 and direction signal on X2A.14 or X2A.15 are active.
65	X2A.12,X2A.16	EN,L	Both the Enable and Leveling speed signals are active. A direction signal is required to allow operation.
69	X2A.12, X2A.14, X2A.16	EN,U,L	Enable, Up and Leveling speed signals are active. The drive should run in binary speed mode.
73	X2A.12, X2A.15, X2A.16	EN,D,L	Enable, Down and Leveling speed signals are active. The drive should run in binary speed mode.
96	X2A.11, X2A.12	HL	Only the High Leveling speed signal at X2A.12 is active. Drive will not run until enable signal on X2A.16 and direction signal on X2A.14 or X2A.15 are active.
97	X2A.11, X2A.12, X2A.16	EN,HL	Both the Enable and High Leveling speed signals are active. A direction signal is required to allow operation.
101	X2A.11, X2A.12, X2A,14, X2A.16	EN,U,HL	Enable, Up and High Leveling speed signals are active. The drive should run in binary speed mode.
105	X2A.11, X2A.12, X2A,15, X2A.16	EN,D,HL	Enable, Down and High Leveling speed signals are active. The drive should run in binary speed mode.
128	X2A.13	H	Only the High speed signal is active. Drive will not run until enable signal on X2A.16 and direction signal on X2A.14 or X2A.15 are active.
129	X2A.13, X2A.16	EN,H	Both the Enable and High speed signals are active. A direction signal is required to allow operation.
133	X2A.13, X2A.14 X2A.16	EN,U,H	Enable, Up and High speed signals are active. The drive should run in binary speed mode.
137	X2A.13, X2A.15 X2A.16	EN,D,H	Enable, Down and High speed signals are active. The drive should run in binary speed mode.

Diagnostic Parameters



X2A Output state

Terminal X2A

This parameter displays the status of the digital outputs on terminal X2A. Each output has a specific value. If more than one output is active, the sum of the value is displayed.

Value table:

Value	Output Terminal	Function
1	X2A.18	+24VDC Solidstate out - AS, At speed
2	X2A.19	+24VDC Solidstate out - FLT, Drive fault
4	X2A.24...26	Form C Relay - RDY, Drive Ready
8	X2A.27...29	Form C Relay - DRO, Drive On



Operation phase

Display

- 0 =
- 1 =
- 2 =
- 3 =
- 4 =
- 5 =
- 6 =
- 7 =


Speed

- Zero speed or analog deceleration
- Low speed selected or analog start & run
- High speed run selected
- PreTorque Ramp down phase (US.18)
- PreTorque Ramp up phase (US.17)
- No Direction Selected
- no meaning
- no meaning



Inverter load

Display of the actual inverter load in %. 100% equals rated load of the inverter.



Motor command speed

Displays the motor set speed in rpm, calculated from the system data.



Actual motor speed

Displays the actual motor speed in rpm measured from the motor encoder .

Actual motor speed should always be the same sign (polarity) as LF.88 and within 20 rpm. Otherwise there is a problem with the encoder, the encoder cable, or the setting of parameters LF.28.



To verify the encoder operation with induction motors, run the elevator drive in open loop (LF.30=0), set the inspection speed (LF43) to 50% of contract speed if possible and run the car empty up. The actual motor rpm value displayed in LF.89 should be nearly equal to the value displayed in LF.88. If the value in LF.89 varies by more than +/- 10 rpm or the value is greater or less than LF.88 by more than 20 rpm, there is a problem with either the encoder or the encoder cable.




Actual elevator speed

Displays the car speed in ft/min; only when the encoder is connected.


This is a calculated value. The car speed should always be verified with an independent measuring device.

Diagnostic Parameters



Phase current

Displays the actual phase current.
Resolution 0.1A




Peak phase current

Maximum motor phase current that occurs during operation. Display in [A]. The value can be deleted by pressing the UP or DOWN key. The memory is also deleted when the inverter is switched off.



Actual DC voltage

Displays the actual dc-bus voltage
Resolution: 1V




Peak DC voltage

Displays the maximum dc-bus voltage measured. In addition the highest value which occurs in ru.11 is stored in ru.12. (Erasing the peak storage : see parameter ru. 8)



Actual output frequency

Displays the actual output frequency.
Resolution: 0.1 Hz









Last fault







Displays the last 8 drive faults which occurred. The fault list can be viewed by changing the number to the left of the LF on the display. This number is the parameter offset number. Zero is the newest fault and 7 is the oldest. See the adjustment steps below to view the fault messages. A list of common faults, their causes, and trouble shooting tips is located on the following pages.

Error messages are always represented by an “E” in the left most position of the display. The drive fault displays are listed and described on the following pages. All faults are automatically reset up to an adjustable number of times. See parameter LF.5.







Error Messages






6.3 Error Messages and Their Cause

Display	Description	Cause and Solution
 Under voltage	The DC bus voltage drops below the permissible value, the input is single phasing, or there is a phase imbalance of greater than 2%.	<ul style="list-style-type: none"> • Input voltage is too low or unstable • Input wiring is wrong • Isolation transformer is too small • Isolation transformer is not connected correctly • One phase of the input line is missing • Phase imbalance greater than 2%
 Over voltage	The DC bus voltage rises above the permissible value either during motor regenerative operation or as a result of line side voltage spikes.	<ul style="list-style-type: none"> • Input voltage is too high – install a step down transformer • Voltages spikes on the line – install 5% line choke • Braking resistor is not connected or has a broken connection or the resistance is too high – verify braking resistor resistance • Inverter is poorly grounded
 Over current	Occurs when the specified peak output current is exceeded or if there is a ground fault.	<ul style="list-style-type: none"> • Short circuit on the motor leads • Ground fault on the motor leads – verify motor wiring • Contacts on motor contactor are damaged or burned causing arcing - check and replace • Inverter poorly grounded • Incorrect motor data – verify data LF10-LF19 • Shorted output transistor
 Overload	Time dependent overload. See overload curves on page 21. Error can not be reset until display shows E.nOL!	<ul style="list-style-type: none"> • Motor wired for incorrectly • Motor data is wrong, specifically motor current • The inverter is sized too small • High mechanical load (friction) on gear, guides, or rails... etc
 Low speed overload	Time dependent overload at low speed. See overload curve on page 28. Error can not be reset until display shows E.nOL!	<ul style="list-style-type: none"> • Stand still current of the motor is too high – reduce the switching frequency of the inverter to 8kHz (LF.38 = 0) see also US.16. • Motor data is not adjusted properly • Inverter sized too small • High mechanical load (friction) on gear, guides, rails...etc • Motor wired incorrectly
 Cool down phase completed	The drive has cooled down after an E.OL or E.OL2 error.	<ul style="list-style-type: none"> • The errors E.OL and E.OL2 can only be reset after E.nOL is displayed


Display	Description	Cause and Solution
 Inverter overheat	The heat sink temperature rises above the permissible limit (see technical data)	<ul style="list-style-type: none"> • Insufficient cooling – increase the airflow around the inverter • Ambient temperature is too high - add a cabinet cooler • Fan is not turning - use US.37 to test fans • Lower the carrier frequency in LF.38 • The heatsink temp can be viewed in ru.38
 Over temperature cooled down	Over temperature reset is now possible	<ul style="list-style-type: none"> • Internal or external temperature has dropped to a safe level. Error “E.OH“ can be reset.
 Motor over temperature	The external motor temperature sensor tripped	<ul style="list-style-type: none"> • Resistance at the terminals T1/T2 > 1650 Ohm • Motor temperature sensor indicating an over-heated motor • See parameter US.33 • Can occur if the program is cleared from the drive’s control card; try US.4 = LoRd
 Over speed	Error over speed	<ul style="list-style-type: none"> • Speed was greater than 110% of the contract speed entered in LF.20. Speed is measured by the motor encoder. • Verify motor data LF.10 – LF.19 and LF.27 • If the encoder position in LF.77 is wrong this error can occur on starting. • Electrical noise on the encoder cable can also cause this error. • When driving a PM motor, if parameter LF.14 is adjusted too high, E.OS may be triggered at the beginning of the run.
 DC Bus charging error	This occurs for a short time during the power up of the drive, but will clear automatically if everything is OK	<ul style="list-style-type: none"> • Input voltage is wrong or to low • Braking resistor connected to the wrong terminals or braking transistor is not functioning • Hardware failure –replace inverter
 Encoder signal loss	Error signal loss or during absolute position search: wrong rotation direction or too much drag	<ul style="list-style-type: none"> • One or more of the signals A+, A-, B+, B-, Z+, Z- are missing. • One or more of the differential signals is latched, i.e. both A+ and A- at are +5V at the same time. Check the encoder connections as well as the signal levels. All + and - signals should be opposite (0V and >2.0V) while the motor is standing still. • If learning encoder position on a PM motor verify brake is picking fully. Or if the ropes are on try moving the car to a different part of the hoist way. Lastly the PM motor phasing may be incorrect.

Error Messages

Display	Description	Cause and Solution
 Encoder communication error	<p>This indicates that there is a problem either with the serial communication between the drive and the encoder or the encoder signals. The full meaning of this error must be decoded through parameter 2.LF.26.</p>	<ul style="list-style-type: none"> • See parameter 2.LF.26 for fault diagnostics • This error does not reset with the RST input or the auto reset function. To clear this error go to parameter 0.LF.26, press function to show the value and then press enter.
 Power unit code	<p>Error Power Unit Code. During the initialization phase the power stage was not identified</p>	<ul style="list-style-type: none"> • Hardware failure replace the elevator drive
 Power unit code changed	<p>Error Power Unit Code Changed. Indicates the power unit code has changed. This is typically experienced when exchanging control cards.</p>	<ul style="list-style-type: none"> • The unit will automatically configure itself for the new power stage and clear the error. • The drive will keep a history of all changes for future reference. • To manually clear this error, go to parameter US.27, press "function" and then "enter" and the error should clear.
 Error current check	<p>Error current check. Prior to every run the drive sends current to each phase of the motor to verify the connection. Afterward, the drive applies magnetizing current and monitors whether the motor is magnetized or not.</p>	<ul style="list-style-type: none"> • One or more motor leads is not connected. • Motor contactor is not closing or not closing in time - verify switching time of contactor • Motor contactor contacts are burnt or damaged - Inspect contactor • Motor windings are damaged. Measure motor resistance. • Drive is not able to generate acceptable current levels - after checking everything above it the problem could be drive related. • The phase current check can be bypassed by setting US.25 = 1
 External Fault	<p>This error indicates a fault was triggered from the option input X2A.10.</p>	<ul style="list-style-type: none"> • This is used to trigger an external fault in case of excessive speed deviation. See. LF.57 for details.
 Encoder card invalid	<p>This error indicates the feedback card has an invalid identification code.</p>	<ul style="list-style-type: none"> • The card was most likely damaged. Replace the feedback card.

Display	Description	Cause and Solution
 Electronic motor overload	Electronic Motor Overload protection was activated.	<ul style="list-style-type: none"> Excessive motor current above the value adjusted in LF.9 for IM or LF.9 and LF.12 for PM motors. Look for mechanical loading problems or motor data adjustment in parameters LF.10...LF.19.
 Bus com. fault	This message indicates that serial communication between the keypad operator and the drive or the drive and the elevator control has been lost. See parameter US.29 to bypass this fault.	<ul style="list-style-type: none"> If communication is restored this fault will clear after 4 seconds. If not remove the operator, cycle power to the drive, verify the red pilot LED on the control board of the drive turns on and stay on, (not flashing), and then install operator again. When using serial communication with the elevator controller, make sure the serial cable to the controller is plugged into X6C on the operator. Also refer to parameter LF.2 part "e" or "g" for more info on clearing E.BUS faults in this case. Power Cycle the Motion 4000 controller to reset all processors and resume serial com.
 Base block time	This message precedes most faults and also occurs if the drive enable is turned off while the car is running.	<ul style="list-style-type: none"> Indicates the output transistors have been safely shut off and are being blocked from further operation.
 No Power Unit	This indicates the power stage is not ready for operation.	<ul style="list-style-type: none"> Typically the result of a hardware failure. Replace the drive.
 Error calculate drive data	Something prevented the drive from learning the motor data.	<ul style="list-style-type: none"> Can occur while auto tuning the motor. The drive may not be able to measure the resistance or inductance. Make note of the message being displayed just before this error message occurs and contact the factory for assistance.

Status Messages



Inverter status

When the drive powers up, the default display is parameter LF.99. This parameter shows various messages indicating the current operation of the drive. Each code and its meaning is described below.

Normal Operating Messages

Display	Significance	Comments
noP	No Operation, idle state	terminal X2.1 (Drive Enable) is not set
LS	Low speed	drive is enabled but no direction of rotation is set, motor current still off
Facc	Forward acceleration	Normal run - positioning off
Fcon	Forward constant running	Normal run - positioning off
FdEc	Forward deceleration	Normal run - positioning off
rAcc	Reverse acceleration	Normal run - positioning off
rCon	Reverse constant running	Normal run - positioning off
rdEc	Reverse deceleration	Normal run - positioning off
boff	Brake OFF	Indicates brake should be in the process of releasing at beginning of run
bon	Brake ON	Indicates brake should be setting at end of run
rFP	Read for position	Position control is active, however a position run has not be initiated by the controller
PA	Positioning active	The drive is operating in position control mode and is presently commanding the run profile
PnA	Position not accessible Drive forced zero speed	It is not possible to reach the target position given the current adjustment of the profile (acceleration and deceleration). This may also occur at the end of the run if the correction distance is too great. See LP.4 for more info.
Cdd	Calculate drive data	This message is displayed when the drive is learning the motor data or encoder position.

7.0 Run Parameters

The run parameters display operational values within the elevator drive. They can be used for trouble shooting or calibration purposes. Each parameter is listed below along with a description of what it displays. Some parameters may display information only used by factory service personnel during diagnostic or repair. It is not necessary to understand the function of each of these parameters.

ru. 0
Inverter state This parameter displays the operational status of the inverter. The status codes are defined with parameter LF.99.

ru. 1
Set speed This parameter displays the set speed or commanded value. This value is before the ramp generator.

Units: rpm

ru. 2
Command speed This parameter displays the actual commanded speed of the motor. This is the speed the motor should turn at.

Units: rpm

ru. 3
Actual output frequency This is the actual output frequency to the motor.

Units: Hz

ru. 7
Actual speed value This is the processed actual speed value as measured by the motor encoder.

Units: rpm

ru. 9
Encoder 1 speed This is the raw measured speed value as measured by the encoder connected to input X3A.

Units: rpm

ru.10
Encoder 2 speed This is the raw measured speed value as measured by the encoder connected to input X3B.

Units: rpm

Diagnostic parameters

rU.11

Commanded torque

This is the internal torque command value which is fed into the current controller.

Units: Nm

rU.12

Actual torque

This is the actual torque value which is calculated from the motor current.

Units: Nm

rU.13

Actual load

This is the load level of the inverter. 100% equals rated load.

Units: %

rU.14

Peak load

This is the peak load level of the inverter. 100% equals rated load. The highest value is stored. The stored value can be reset by pressing the up or down key. It will also reset when the power is turned off.

Units: %

rU.15

Phase current

This is the actual phase current flowing to the motor. The currents in the three phases are averaged.

Units: Amps

rU.16

Peak current

This is the peak phase current. The highest value is stored. The stored value can be reset by pressing the up or down key. It will also reset when the power is turned off.

Units: Amps

rU.17

Torque current

This is the per phase value for the reflected rotor current. This current is the torque producing component of the phase current and will be proportional to the torque.

Units: Amps

rU.18

DC bus voltage

This is the actual value of the DC bus voltage. Normally it will be 1.4 times higher than the input line voltage.

Units: Volts

rU.19

Peak DC bus voltage

Peak DC bus voltage. The highest value is stored. The stored value can be reset by pressing the up or down key. It will also reset when the power is turned off.

Units: Volts

ru.20

Output voltage

This is the actual phase to phase output voltage to the motor.

Units: Volts

ru.21

Input terminal state

The raw status of the input terminals. Each input is binary weighted according to the table below. If an input is activated the value corresponding to the input is displayed. If multiple inputs are activated the sum of the values is displayed. This parameter includes software linked inputs.

Input Terminal	Function	Value	Example: Input X2A.16 and X2A.14 are active.
X2A.16	Enable	1	
X2A.17	Reset	2	
X2A.14	Up	4	1 + 4 = 5
X2A.15	Down	8	
X2A.10	Option-Emerg. Pwr.	16	Other examples:
X2A.11	Leveling speed	32	96 = Inspection speed
X2A.12	High Level speed	64	224 = intermediate speed 3
X2A.13	High Speed	128	+ 5 for up
none	Internal function	256	+9 for down
none	Internal function	512	
none	Internal function	1024	
none	Internal function	2048	

ru.22

Input terminal state

This is the processed status, after filters, software switches etc. of the inputs. The same weighting scheme applied as in parameter ru.21.

ru.23

Output terminal state

This is the state of the internal output conditions. Multiple active conditions results in the sum of the values.

Condition	Value
0	1
1	2
2	4
3	8
4	16
5	32
6	64
7	128

Diagnostic parameters

ru.24

Output flag
state

This is the state of the internal output flags. Multiple active flags result in the sum of the values.

Flag	Value
0	1
1	2
2	4
3	8
4	16
5	32
6	64
7	128

ru.25

Output status

This is the state of the actual outputs. Multiple active outputs result in the sum of the values.

Output	Function	Value
X2A.18	At Speed	1
X2A.19	FLT	2
X2A.24...26	RDY	4
X2A.27...29	DRO	8
A	Software Link	16
B	Software Link	32
C	Software Link	64
D	Software Link	128

ru.26

Active parameter
set

This parameter displays the active internal parameter set.

ru.27

Analog pattern
raw

This parameter displays the value of the actual pattern signal applied between terminal X2A.1 and X2A.2. The value is in percent +/- 100.0% = +/- 10.00V. This value is unfiltered and unprocessed.

Units: %

ru.28

Analog pattern
processed

This parameter displays the processed analog pattern value. Filters, offsets and gains are applied to this value. Again 100.0% = 10.00V on the input.

Units: %

ru.29**Analog pre-torque raw**

This parameter displays the value of the actual pre-torque signal applied between terminal X2A.3 and X2A.4. The value is in percent $\pm 100.0\% = \pm 10.00V$. This value is unfiltered and unprocessed.

Units: %

ru.30**Analog pre-torque processed**

This parameter displays the processed analog pre-torque value. Filters, offsets and gains are applied to this value. Again $100.0\% = 10.00V$ on the input.

Units: %

ru.31**Analog option raw**

This parameter displays the value of the analog signal applied to an option interface board. The value is in percent $\pm 100.0\% = \pm 10.00V$. This value is unfiltered and unprocessed.

Units: %

ru.32**Analog option processed**

This parameter displays the processed analog option value. Filters, offsets and gains are applied to this value. Again $100.0\% = 10.00V$ on the input.

Units: %

ru.33**Analog Out 1 preamp**

Analog output 1 preamp display. The value is in percent $\pm 100.0\% = \pm 10.00V$.

Units: %

ru.34**Analog Out 1 post-amp**

Analog output 1 post amp display. The value is in percent $\pm 100.0\% = \pm 10.00V$.

Units: %

ru.35**Analog Out 2 preamp**

Analog output 2 preamp display. The value is in percent $\pm 100.0\% = \pm 10.00V$.

Units: %

ru.36**Analog Out 2 post-amp**

Analog output 2 post amp display. The value is in percent $\pm 100.0\% = \pm 10.00V$.

Units: %

ru.37**Motor pot value**

Value of the internal function.

Units: %

Diagnostic parameters

rU.38

**Power module
temperature**

This is the temperature of the output transistors.

Units: °C

rU.39

**Overload
counter**

Overload counter display. Once the load of the drive goes above 100% this counter begins to increment. If the load drops below it decrements. If the Counter reaches 100 the drive will shut down with an E.OL error.

rU.40

**Power on
counter**

Power On counter counts the time while powered up.

Units: hours

rU.41

Run counter

Run counter counts the time actual providing power to the motor and running the elevator.

Units: hours

rU.42

**Modulation
grade**

This is the percent utilization of the DC bus voltage. 100% means the DC bus is 100% utilized and the output voltage is equal to the input voltage. If this value reaches 100% or goes above 100% as a result of over modulation, loss of control of the motor will occur.

Units: %

rU.43

Timer 1

Displays the value of an internal timer.

rU.44

Timer 2

Displays the value of an internal timer.

rU.45

**Actual
switching
frequency**

This is the actual carrier frequency the drive is operating at. Under certain conditions the drive may lower the carrier frequency in order to provide more current at low frequencies.

rU.46

**Motor
temperature**

Displays the motor temperature. This value is only valid when the motor has a KTY thermal sensor installed and that sensor is connected to the T1/T2 terminals.

Units: °C

rU.54

**Position
counter**

Displays the value of the internal position counter.

Units: counts

ru.81 Active Motor Power

This is the actual electrical power going to the motor. A negative value means power being generated by the motor.

Units: kW

ru.85 Peak Motor Speed

Displays the peak speed as measured by the motor encoder. Can be reset by pressing the down arrow key or after power off.

Units: rpm

ru.87 Magnetizing Current

Only for Induction motors, displays the actual magnetizing current. The value will drop as contract speed is reached because the flux controller is adjusting for field weakening.

Units: amps rms



All remaining ru parameters are not important for the function of the elevator drive and therefore are not documented here.

Advanced Parameters

8.0 Advanced Adjustments

There are additional US parameters which can provide further functional adjustments of the drive. These US parameters are all those greater than US.10. The following will provide a basic description of the function of each parameter.

US. 14 **Comm error** **para address**

In the event of a communication error between the operator and the drive, the operator stores for diagnostic purposes, the address of the parameter it was trying to communicate with.

US. 15 **Comm error** **para data**

In the event of a communication error between the operator and the drive, the operator stores for diagnostic purposes, the data it was trying to send to the parameter in the drive.

US. 16 **E.OL2 function**

The E.OL2 function is designed to protect the inverter from dangerous currents when operating at very low output frequencies. With some geared motors and mainly with gearless motors the drive is forced to provide high currents at output frequencies below 3 Hz. This causes considerable thermal loading on the power transistors. In an attempt to protect itself the drive will monitor the load current when operating below 3 Hz. If the safe value is exceeded, the drive will trigger the error E.OL2. See section 2.7 for a table with the actual current values. A value of 0 in US.16 provides this function.

A value of 16 takes into consideration the actual temperature of the power modules. If the temperature is lower, the threshold level for the output current is raised allowing more current to flow before triggering the error.

A value of 64 will cause the drive to automatically lower the carrier frequency when the output current reaches the E.OL2 limit. By doing so the actual threshold value is raised preventing E.OL2 and the drive keeps running. It is possible that under certain cases the carrier frequency might become low enough to be audible.

- 0 = Standard function E.OL2 at listed current values
- 16 = Heatsink temperature dependent E.OL2
- 64 = Auto carrier frequency reduction
- 80 = both temp dependent and auto carrier freq. reduction

US. 17

Pre-torque
timer ramp up

The function of this parameter is dependent on which mode of pre-torque is selected in LF.30.

LF.30 = 3 analog pre-torque from load weigher

This timer controls the build time for the Pre-torque function. Once the direction input is activated this timer begins counting. In the mean time the current check takes place and then finally the motor is magnetized. At this point the analog pre-torque value is evaluated and the torque begins to build on the motor. If this value is set too short the torque build will stop before the current check is done or before it has reached its nominal value. As a result it will appear that the Pre-torque function does not work. If the value is too long the actual pre-torque made by the motor will appear to over compensate.

LF.30 = 5 Synthesized pre-torque

This timer inserts dead time prior to brake release during which the current check function occurs and the motor becomes magnetized. In this case it should always be adjusted less than the actual mechanical brake pick time.

Unit: 0.1 seconds

Value range: 0.0...10.0

Default setting: 0.3

Adjustment values: (when LF.30 = 3) 0.3 to 0.5 sec

(when LF.30 = 5) 1/2 of the total speed pick delay
time but less than the mechanical brake pick time

Refer to section 5.12.4 for a detailed adjustment procedure.

US. 18

Pre-torque
timer ramp
down

The function of this parameter is dependent on which mode of pre-torque is selected in LF.30.

LF.30 = 3 analog pre-torque from load weigher

This timer controls the ramp down time for the analog pre-torque function. Once the pre-torque is established it is necessary to ramp the command torque down to provide a smooth transition when the brake releases. Without any ramp, the turn off of pre-torque will be abrupt and with too much ramp time the actual start of movement will be influenced.

LF.30 = 5 Synthesized pre-torque

This timer controls the window during which the synthesized pre-torque function is actually active. **The mechanical release of the brake must take place during this time period.**

Unit: 0.1 seconds

Value range: 0.0...10.0

Default setting: 0.1

Adjustment values: (when LF.30 = 3) 0.1 to 0.2

(when LF.30 = 5) 0.15 to 0.25

Refer to section 5.12.4 for a detailed adjustment procedure.

Advanced Parameters

US. 20

Max. speed for
max. KI

These parameters can be used to tailor the KI Offset gain to a specific speed range at low speed. Worm gear applications require a smaller KI Offset value but over a broader speed range. Whereas a gearless motor will require a much higher KI Offset value but at only the very lowest speed. With these two parameters the Offset can be tailored to the application. The default values are applicable to geared applications.

US. 21

Speed for min
KI

For gearless applications US.20 should be reduced to 3 ft/min and US.21 raised to 75 ft/min.

US.20

Unit: 1 ft/min

Value range: 0..1600


Default setting: 8 ft/min

US.21

Unit: 1 ft/min

Value range: 0..1600

Default setting: 24 ft/min




US. 22 Speed dependent KP gain

These parameters allow the KP gain to be scaled dependent on the command speed of the elevator. In some cases it is beneficial to reduce the gain at high speed to minimize system response to hoistway vibrations or disturbances. Parameter US.22 turns the variable gain function on or off and parameter US.23 adjusts the value to which the gain is reduced.

US. 23 Min KP gain at high speed

US.22
Unit: -
Value range: off, on
Default setting: off

US.22
Unit: 1
Value range: 0..32000
Default setting: 1000



US. 24 KD speed gain

This acts as a derivative gain for the speed control. Generally the use of the derivative term is not necessary. However, there are some applications, where it could be useful. An example of which would be if for some reason it was necessary to keep the KP and KI gain values very low to prevent oscillation. In this case the KD gain could be used to maintain stability.

Unit: -
Value range: 0...32000
Default setting: 0
Recommended adjustment: 500 - 1500

Advanced Parameters

US. 25 Phase current check

This parameter can be used to select what type of current check is performed. Additionally it determines whether or not the brake on/off message is displayed. In the event there is a problem getting a consistently positive phase check, it is possible to switch to only a magnetizing current check. The possibilities are defined below.

<u>Value</u>	<u>Function</u>
0	Off (for temporary adjustment only)
1	Magnetization current check with brake on/off display
2	Magnetization current check without brake on/off display
3 _(default)	Phase current check with brake on/off display
4	Phase current check without brake on/off display

US. 27

Power unit
code

Each voltage and size power stage has its own unique ID code. This parameter displays the ID number of the power stage. In the event the control card is replaced, when the new control card is installed the drive will display the message E.PUCH indicating that the ID of the power stage has changed since the last power on sequence. Before you are able to proceed further it is necessary to confirm the new ID number through this parameter. Simply display the ID number and press enter. This will clear the error message E.PUCH and allow the unit to go into operation.

US. 28

Analog input
noise clamp

This parameter can be used to suppress noise on the analog speed pattern. When adjusted to a value greater than zero it will act as a hysteresis level above which the analog signal must rise before the drive begins to act on it. With a negative value the drive applies the same hysteresis to constant speed, i.e. at high speed.

Unit: 0.1 % = 10mV
 Value range: 0.1...10.0 %
 Default setting: 0.1 %
 Recommended adjustment: 0.1%

US. 29

HSP5
Watchdog time

This parameter adjusts the serial watchdog on the HSP5 com. link between the operator and the drive. If the operator is removed from the drive, the serial communication stops. If it does not restart before this timer expires the drive will trigger a fault and stop the operation of the motor.



A setting of 0 or OFF turns off the watchdog allowing operation of the drive with the operator removed. Note this mode of operation is recommended only for trouble shooting purposes.

When serial communication is used between the drive and the controller (LF.2 = SErSP or SPoS, the watch dog time is internally lowered to 20 mSec.

Unit: 0.01 sec
 Value range: 0.01...10.00 sec
 Default setting: 1.00 sec
 Recommended adjustment: 1.00 sec

Advanced Parameters

US. 33 E.dOH function

This parameter can be used to activate the temperature sensor input (T1 T2) on the drive. With this input activated, if the resistance between T1 and T2 becomes greater than 1650 ohms, the drive will trigger an E.dOH error indicating that the temperature sensor is too hot. Note: there is a 60 second time delay between when the sensor triggers and when the drive triggers the fault.

Value range: off...on
Default setting: off

US. 34 Analog pattern gain

The analog pattern can be scaled directly through this parameter. As an example if the analog signal is +/- 0...5 V, the pattern gain can be changed to 2.00 to provide full scale control of the motor speed.

Value range: 0.01...20.00
Default setting: 1.00

US. 35 Reference splitting

This function creates a slope between two successive speed values which are transferred serially. This parameter should be adjusted for a time double the actual serial update rate of the speed command. The function smooths out the relative course steps which can occur during rapidly changing speed commands.

Value range: 0:Off, 1...200 mSec
Default setting: 0:Off

US. 37 Function Test

This parameter allows the user to test certain functions in the drive. They are described below.

Test Name	Value	Comments
None	0 (OFF) default	
Fan Test	1	Turns on all cooling fans such that user can visually check to see they are running. Power cycle clears or set back to 0.

This page left blank.

9.0 Output Configuration

9.1 Digital Output Parameters

The digital output parameters can be used to configure the digital outputs for operation. Normally these parameters only need to be adjusted by the Elevator control builder.

do.82 Output X2A.24..26

This parameter determines the function of the relay output X2A.24..26. The function can be selected from the table on the following page.

Default setting: rdy

do.83 Output X2A.27..29

This parameter determines the function of the relay output X2A.27..29. The function can be selected from the table on the following page.

Default setting: dro (used for IMC and I Control)


Factory setting: brC (used for PTC)

Switching conditions for the digital outputs. Only one condition can be assigned to each output.

Designator	Function
FLt	Fault - indicates there is a drive fault. Output activates when there is a drive fault, E.xxx
Rdy	Ready - indicates the drive is ready for operation. Output activates when the drive and ready for operation and there are no active faults E.xxx
dro	Drive On - indicates the drive is on and in control of the motor. Output activates after the following conditions are met: enable input active, direction input active, motor phase current check passed, motor magnetizing current OK. The output turns off when one of the following occurs: enable input is turned off, direction input is turned off and the motor speed has decelerated to zero speed and timer LF.78 has expired, drive fault E.xx, current to the motor is interrupted for any other reason.
ASd	At Speed - indicates the actual speed is tracking the command speed. Output is active as long as the actual speed matches the commanded speed. If during operation the actual speed is greater than or less than the commanded value, the output will turn off. See also parameters LF.57, LF.58, LF.59 for adjustment.
HSd	High Speed Run - indicates when the actual motor speed is above twice the value adjusted in LF. 41 (leveling speed). The output turns on when the actual speed is greater than 2 x LF.41. When the actual speed drops below 1.5 times LF.41 the output turns off. The speed is measured by the motor encoder.
brC	Brake Control - for controlling the brake. Output activates after the following conditions are met: enable input active, direction input active, motor phase current check passed, motor magnetizing current OK. The output turns off when one of the following occurs: enable input is turned off, direction input is turned off and the motor speed has decelerated to zero speed, drive fault E.xx, current to the motor is interrupted for any other reason.
Mcc	Main Contactor Control - for controlling the main motor contactor. Output activates after the following condition is met: enable input active. The output turns off when one of the following occurs: enable input is turned off, drive fault E.xx. Note: when using this input, it is necessary to qualify the direction signal(s) through an auxiliary contact on the main contact for proper timing.

Output Configuration

9.2 Timing Graph - Analog Control




Event Sequence

- 1) Drive is enabled, outputs assigned to Mcc activate.
- 2) Direction signal is given. Note if Mcc output function is used, direction signals must be qualified by the closing of the main contactor.
- 3) The drive performs a current check to be sure the motor is connected and that rated magnetizing current is produced. This current check requires about 300mSec to complete.
- 4) If pretorque is not used the analog input is clamped for the period adjusted in LF.70. If pre-torque is used, the drive is applying pre-torque to the motor during this time. In either case motion can not occur so the controller must delay the pattern by at least the amount adjusted in LF.70 or the sum of the timer values in US.17 and US.18. After this time the controller can begin to ramp the analog command. This time should be adjustable to accommodate different brake release times.
- 5) Once the actual speed is above two times the leveling speed adjusted in LF.41, the HSD output function turns on.
- 6) If there is speed deviation during the run that exceeds the adjustment of LF.58 and LF.59, the ASD output turns off.
- 7) Once the speed deviation corrects itself, the ASD output turns on again.
- 8) When the elevator decelerates below, 1.5 times the leveling speed adjusted in LF.41, the HSD output turns off.
- 9) When the analog speed pattern is reaches zero, the controller should drop the direction signal. Exception, in the event of re-leveling leave the direction signal active and simply provide the re-leveling command with the analog pattern signal. When the direction turns off the timer in LF.78 begins. Additionally, the Brk output function turns off when the direction signal is turned off. If the controller is controlling the brake, the brake should be set at this time.
- 10) The drive maintains full control and current to the motor for the time period adjusted in LF.78. After which, the drive will reduce speed control gains and begin to ramp the motor current down to zero over the time adjusted in LF.79.
- 11) After the sum of the times in LF.78 and LF.79 the motor current is zero and it is safe to disable the drive and open the main contactor. Since LF.78 and LF.79 are adjustable to account for variable brake drop times, the corresponding time delay should also be adjustable in the controller.
- 12) Drive is disabled and the Mcc output turns off.

Output Configuration

9.3 Timing Graph - Digital Control



Event Sequence

- 1) Drive is enabled, outputs assigned to Mcc activate.
- 2) Direction signal is given. Note if Mcc output function is used, direction signals must be qualified by the closing of the main contactor.
- 3) The drive performs a current check to be sure the motor is connected and that rated magnetizing current is produced. This current check requires about 300mSec to complete.
- 4) The high speed signal is given. Note this signal can be given together with the direction signals or afterward.
- 5) If pretorque is not used the speed is held at zero the period adjusted in LF.70. If pre-torque is used, the drive is applying pre-torque to the motor during the total time in US.17 and US.18. These times are adjustable to accommodate different brake release times. The drive begins to accelerate the motor based on the adjusted pattern.
- 6) Once the actual speed is above two times the leveling speed adjusted in LF.41, the HSD output function turns on.
- 7) If there is speed deviation during the run that exceeds the adjustment of LF.58 and LF.59, the ASD output turns off.
- 8) Once the speed deviation corrects itself, the ASD output turns on again.
- 9) The high speed signal is removed and the drive begins to decelerate the elevator to the floor. Note variations in the turn off of the high speed signal will result in inconsistent approach to the floor. Therefore this signal must have minimal delay in processing from the controller.
- 10) When the elevator decelerates below, 1.5 times the leveling speed adjusted in LF.41, the HSD output turns off.
- 11) When the elevator reaches the floor, the controller should drop the direction signal. Exception, in the event of re-leveling leave the direction signal active and simply provide the re-leveling command by selecting leveling speed. When the direction turns off the timer in LF.78 begins. Additionally, the Brk output function turns off when the direction signal is turned off. If the controller is controlling the brake, the brake should be set at this time.
- 12) The drive maintains full control and current to the motor for the time period adjusted in LF.78. After which, the drive will reduce speed control gains and begin to ramp the motor current down to zero over the time adjusted in LF.79.
- 13) After the sum of the times in LF.78 and LF.79 the motor current is zero and it is safe to disable the drive and open the main contactor. Since LF.78 and LF.79 are adjustable to account for variable brake drop times, the corresponding time delay should also be adjustable in the controller.
- 14) Drive is disabled and the Mcc output turns off.

This Page Left Blank.

10.1 Elevator Drive Data

These parameters provide access to advance elevator drive parameters related to the motor model, system mechanical model, and advanced control settings. These values should only be changed when instructed to do so by the manufacturer.

Ld.18

Field weakening corner

This parameter provides a better adjustment of the field weakening torque curve. Under certain situations, if the input voltage is sagging too low or the motor has very high slip, it is possible that the voltage limit might be reached. This can be confirmed by monitoring ru.42. If ru.42 reaches 100% or more the drive is operating at the voltage limit and potentially can cause poor control of the motor.


To prevent this from happening the drive has an adjustable torque curve which prevents the voltage limit from being reached. The value of this parameter is normally calculated when the motor data is loaded in the LF parameters. After entering the data, this value can be fine tuned.

Unit: 1 rpm

Value range: 0..4000

Default setting: calculated from motor data

Adjustment values: increment /decrement by steps of 10%



Ld.19

Field weakening curve

Sets the rate of decay of the motor flux above the corner speed adjusted in Ld.18. This parameter is only available for induction motors.

Advanced Drive Data

Ld.20

Stator resistance

The per phase induction motor stator resistance in ohms. This parameter is only available for induction motors.

Ld.21

Sigma inductance

The equivalent induction motor sigma inductance. This value is calculated from the per phase stator and rotor leakage inductances. This parameter is only available for induction motors.

Ld.22

Rotor resistance

This is the per phase induction motor rotor resistance. This parameter is only available for induction motors.

Ld.23

Magnetizing inductance

This is the per phase induction motor magnetizing inductance. This parameter is only available for induction motors. The magnetizing inductance can be monitored in parameter ru.87. If the actual magnetizing current is too high lower this inductance value in steps of 20. If it is too low, raise the value.

Ld.24

Motor control

This parameter activates various controllers in the drive. Each function is binary weighted as listed below. The sum of the these values determines which are on or off.

- 1 = Motor model control observer active
- 2 = Rotor resistance temperature adaptation
- 8 = Maximum output voltage regulation (max 110%)
- 32 = Active flux control
- 128 = Flux proofing



After the auto tuning process the motor model control observer is automatically turned on. If for any reason the auto tuning process did not provide the desired control, the function can simply be turned off by setting this parameter to 8.

Ld.25

Vmax regulation

Sets the output voltage level as a percentage of the available with 100% equal to the maximum available. The drive will attempt to regulate the output voltage from going above this value by reducing the magnetizing current of induction motors or de-fluxing for PM motors. The nominal value is 97% which will regulate the voltage to just under 100%.

Ld.27

KP current

Current control proportional gain. Calculated from the motor data.

Ld.28

KI current

Current control integral gain. Calculated from the motor data.

Ld.29

Acceleration torque

The acceleration torque is used to calculate the system inertia. By entering a torque value in this parameter, the corresponding inertia is calculated from the mechanical data in LF.20...LF23 and the acceleration rate adjusted in 2.LF.51. The resulting inertia value is loaded into Ld.30 and the feed forward torque control turned on. The total system inertia, motor and load in kgm^2 . The torque value is determined by using the I Lrn function in parameter LF.3. The value is the acceleration torque minus the torque while running at contract speed. The I Lrn function will automatically bring you to this parameter to enter the torque value.

Ld.30

System inertia

This is the system inertia in kgm^2 as calculated through parameter Ld.29 or via measurements made via PC software. When this value is not equal to zero and the gain value in Ld.32 is also not equal to zero the FFTC function is active.

Ld.31

FFTC filter

Feed forward torque control filter. Provides a filter on the output of the FFTC. For digital speed or position control a value of 3 is recommended. For analog control a value of 5 is recommended. 0=off, 1=2msec, 2=4mSec, 3=8mSec, 4=16mSec, etc.

Ld.32

FFTC gain

Determines the relative gain of the feed forward torque command. 100% = unity command. A value of 90% is recommend. Higher values strengthen the response, lower values weaken the response. It may be necessary when using FFTC to lower the value of LF.32 and LF.33.

Ld.33

Torque command filter

Provides a PT1 filter on the torque command signal before it is feed into the current control.
0=off, 1=0.5msec, 2=1msec, 3=2msec, 4=4mSec, 5=8mSec, etc

11.0 Position Control

11.1 Position Control

These parameters are used to configure the position controller in the drive. In order to use this function, the elevator control must be designed to give the proper signal sequence ensuring correct operation.

LP.1

Position Control

This parameter turns the position controller on and off and also is used to activate the teach function.

Settings

OFF: Drive operates as a standard unit without positioning control. However, when LF.2 is set to **5 P05** the position control is turned on via serial communication from the controller.

tEAch: Used to learn distances

P 0nE: One floor positioning is active

LP.2


Min. slowdown dist.

This parameter shows the minimum required slow down distance, based on the adjusted profile in parameters LF.53, LF.54, LF.55 and LF.42, to slow down from contract speed.

LP.3

Slowdown distance

This value is the actual distance to the floor. The drive calculates the run profile required to bring the car to the floor. This value is sent to the drive from the controller via serial com. The value on the display is not updated when LF.2 = **5 P05** and the parameter becomes read only.



LP.4


Correction distance

The correction distance can be used to reset the position error as the car comes to the floor. When the drive sees the leveling zone marker, the position counter is reset to reflect the actual distance entered in this parameter. The controller passes the leveling zone sensor signal to the drive via serial communication.

With this parameter the amount of stabilized leveling can be adjusted. A value of zero means no correction, the function is off and the leveling distance is the distance adjusted in the controller.

A value of 6.0" the distance of the leveling zone to the dead zone, will provide no leveling and the system will be on the verge of overshooting the floor.

The optimum adjustment for direct to the floor operation is a value of 5.7"-.5.9". If a little leveling is desired set the value to 5.0"-.5.5".



Correction distance adjustment tips

If the correction is too hard, a slight bump may be felt just as the car is coming to the floor. To reduce this effect lower the leveling distance adjustment in the Motion 4000 elevator control from 2.0 inches to 1.0.

LP.12

Current position

This shows the actual position in inches from actual position of the car at power up of the drive.

LP.21

Scaling increments high

Parameters LP21, LP22, LP23 provide a means independent from parameters LF.20, LF.21, 22,, 23 to adjust the scaling of inches into counts on the motor encoder. The scaling is defined by the following relationship:

LP.22

Scaling increments low

$$\text{counts/inch} = \frac{\text{LP21} \times 10000 + \text{LP22}}{\text{LP23}}$$

LP.23

Scaling distance

Initially these values are calculated from the values entered into parameters LF.21, LF.22, LF.23, LF.27, and LF76. After adjusting these parameters, it is possible to change the values in LP.21,LP.22,LP.23. Keep in mind that any changes made to the LF parameters 21, 22, 23, 27 and 76 will force LP21, 22, 23 to recalculate.

12.0 Trouble Shooting

12.1 Operation Problems

Problem	Cause	Solution
<p>Machine does not rotate or only turns slightly -Machine stalls and draws high current</p> <p>-No response from inverter</p>	<p>-Motor data incorrect</p> <p>-Encoder rotation incorrect</p> <p>-Inverter in 'configuration' or 'Stop' mode</p> <p>-Input signals incorrect</p>	<p>-Verify correct motor data in LF.10-Lf.19. Verify correct correlation between rated speed, rated frequency and number of poles for PM machines: $LF.11 = 120 \times LF.13 / \# \text{ poles}$</p> <p>-Verify encoder mounting. Note value of LF.77, then relearn the encoder position for PM machines. If the relearned value is different from the previous value by more than 2,000 then slippage may have occurred on the encoder.</p> <p>-Set LF.3 = run</p> <p>-Verify input terminal state in LF.82 for digital speed selection or analog input in ru.27 for analog speed and inverter state in LF.99 while running inspection.</p>
<p>Sheave rotates very fast and causes E.OS error</p>	<p>-Motor data incorrect</p> <p>-Encoder position not correct</p> <p>-Encoder sample time too high</p> <p>-Speed gains too high on unroped machine</p>	<p>-Verify correct motor data in LF.10-Lf.19. Verify correct correlation between rated speed, rated frequency and number of poles for PM machines: $LF.11 = 120 \times LF.13 / \# \text{ poles}$</p> <p>-Verify encoder mounting. Note value of LF.77, then relearn the encoder position for PM machines. If the relearned value is different from the previous value by more than 2,000 then slippage may have occurred on the encoder.</p> <p>-Set LF.29 = 4ms or 8ms</p> <p>-For an unroped machine, lower speed gains to about LF.31 = 300, LF.32 = 50, LF.33 = 0. Raise again when machine is loaded.</p>
<p>Unable to learn encoder position -E.EnCl errors</p>	<p>-Motor data incorrect</p> <p>- Incorrect encoder rotation</p> <p>-Friction. Sheave unable to move freely</p> <p>-Encoder sample time too high</p>	<p>-Verify correct motor data in LF.10-Lf.19. Verify correct correlation between rated speed, rated frequency and number of poles for PM machines: $LF.11 = 120 \times LF.13 / \# \text{ poles}$</p> <p>-Swap A and B encoder channels. Change LF.28 from a value of 0 to 1 or from 1 to 0, else from 2 to 3 or from 3 to 2, and relearn the encoder position.</p> <p>-Verify brake is opening. If machine is unroped, the sheave should be movable by hand. If machine is roped, move balanced car to a different position in hoistway.</p> <p>-Set LF.29 = 4ms or 8ms</p>

Problem	Cause	Solution
<p>Unable to learn encoder position -E.EnCI errors</p> <p>-E.EnCC errors</p>	<p>-Motor phasing incorrect</p> <p>-Determine fault displayed in 2.LF.26 before clearing error and correct as needed</p>	<p>-Verify output connections: U-U, V-V, W-W. For PM machines, phases cannot be swapped to invert motor rotation. If unable to learn position with LF.28 = 0,1,2,3 swap V-W phases and try again for all values of LF.28.</p> <p>-2.LF.26 = PoSde (Position deviation). Verify encoder mounting, uncoil extra lengths of encoder cable and separate from noise sources, install ferrite rings.</p> <p>-2.LF.26 = bdCb (Bad Cable). Verify encoder connections, uncoil extra lengths of encoder cable and separate from noise sources, install ferrite rings.</p> <p>-Verify correct encoder card in 0.LF.26 and encoder type in 1.LF.26.</p> <p>-Check for bent or missing encoder pins.</p>
<p>Elevator fails to reach contract speed</p>	<p>-Torque limit reached</p> <p>-Voltage limit reached</p>	<p>-Increase torque limit in 0.LF.36.</p> <p>-Monitor the modulation grade in ru.42. If the value reaches 100% or higher, then the voltage limit is being reached and more output voltage is required than what is being input. Verify input voltage is correct and not sagging.</p> <p>For Induction Motors also check:</p> <p>-Higher values of power factor in LF.15 mean a weaker motor field which reduces the voltage requirement. In case of problems, raise this value to 0.9 or even 0.95. Perform motor auto tune again after changing.</p> <p>-LF.16 can be used to reduce the magnetizing current at higher speeds to prevent the drive from hitting the voltage limit. Lowering this value to 60% of the motor synchronous speed will help limit the voltage requirement. See also Ld.18 and Ld.19.</p> <p>-Monitor the value grade in ru.42. If the voltage reaches 100% or goes higher, the voltage limit is being reached. Further adjust LF.15, LF.16 and US.19.</p>
<p>Audible Motor Noise -Noise caused from physical vibration</p>	<p>-Speed gains LF.31-LF.33 are too high.</p> <p>-Encoder sample time too high</p> <p>-Incorrect motor data</p>	<p>-After machine has been roped, start with low gain values and increase as needed. For example, LF.31 = 500, LF.32 = 100, LF.33 = 200.</p> <p>-Increase LF.29 encoder sample time to 8ms or 16ms.</p> <p>Verify LF.11 - LF.19. Use LF.3 = S_Learns function to learn the resistance, inductance, and back EMF if unknown.</p> <p>-Raise LF.29 to 4ms or 8ms. If noise continues, try 16ms.</p>

Trouble Shooting

Problem	Cause	Solution
Audible Motor Noise -Noise due to electrical noise -Squealing noise	-Encoder sample rate too low -Encoder multiplier too low -Electrical noise coupled on encoder cable -Incorrect motor data -Incorrect motor data -Current gains too high	-Raise LF.29 to 4ms or 8ms. If noise continues, try 16ms. -Set LF.76 = 8 for PM machines -To prevent or eliminate motor noise make sure the encoder cables are run through their own conduit away from the motor or line power wires. Keep the encoder cable as short as possible. Do not leave extra lengths of wire coiled up inside the control panel. Make sure the controller is well grounded especially at the disconnect. If necessary run an additional bond wire to the building ground. -Verify LF.11 - LF.19. Use LF.3 = S_Learns function to learn the resistance, inductance, and back EMF if unknown. -Verify LF.10 - LF.19. Relearn motor data with LF.3 = S_Lrn. -Verify motor data LF.10-LF.19. Use S_Lrn if not already done.
Overshoot on deceleration	-Torque limit being reached -Decel profiles set too long	-Increase 0.LF.36. Anytime the LF.17 rated torque is re-entered, the maximum torque is automatically calculated to 150% x LF.17. -Adjust decel and jerk levels higher to determine if overshoot caused by signal timing.
Drive not giving DRO signal	-Input signals incorrect -Motor phase current check not passed -If it is a hardware issue it is possible to test the outputs in the procedures on the right.	-Verify enable and direction signals are being received in LF.82. -If motor phase current check does not pass E.br will be triggered. <u>Check # 1:</u> Put car in inspection mode. Prevent brake from releasing (i.e. reduce pick voltage). Set drive to configuration mode, LF.3 = conf. In this mode the drive gives a fake DRO signal whenever the drive is enabled, regardless of whether motor current is flowing. Try to run on inspection. If the controller acknowledges the DRO then the hardware is working. This means the loss of DRO under normal operation may be timing related or possible a problem developing the rated motor current for motor magnetization on induction motors. <u>Check #2</u> Put the car in inspection mode. On the X2A terminal strip swap the wire connected to terminal 24 and 27. Then swap the wires connected to 26 and 29. You are swapping the relays being used. Then change the setting for do.82 and do.83 and adjust do.42 as needed to invert any output. Try to run the car on inspection. If everything works put the car back on automatic and monitor the controller for dro faults. If this solves the problem, the drive can be left in this configuration. Just be sure to note the changes on the prints.

Problem	Cause	Solution
Cannot overspeed the machine to test governor	-Inverter overspeed level reached.	-The inverter overspeed level is automatically calculated as 110% of the contract speed in LF.20. Decrease LF.62 or the gear ratio in LF.22 can be raised to cause the machine to turn faster. A value of 1.5 times the existing value will cause the machine to turn 1.5 times faster without triggering the inverter overspeed fault. Return LF.22 to normal value when overspeed test has been completed.
Rollback -Significant amount of rollback	-Pre-torque not turned on -Pre-torque gain too low -Load weigher out of calibration	-If using analog pre-torque, set LF.30 = 3. Otherwise, synthesized pre-torque can be activated with LF.30 = 5. It is best to activate and adjust the synthesized pre-torque after the car is running on automatic. -For analog pre-torque, the gain is adjusted in LF.67. For synthesized pre-torque, P.LF.32 can be adjusted. -For PM machines, use synthesized pre-torque instead.
At beginning of run... -Pause at start -Noise / Vibration (briefly) at start	-Speed Start /Break release delay set too long -Driving against brake	-Decrease LF.70 as necessary to minimize the amount of time the inverter holds the speed signal at zero before starting profile. For shoe brakes a value of 0.3 seconds is a good starting point; For disc brakes, this may need to be lowered to 0.1 seconds. -Turn the pre-torque off by setting LF.30 = 2, then extend the speed start delay in LF.70 for digital speed commands or extend the pattern delay for analog speed commands to determine if this is the problem.
Cannot drive full load Will not pick full load or car only moves in down direction with full load or up direction with empty car	-Motor data incorrect -Encoder position incorrect -Speed gains too low -Encoder ppr incorrect	-The drive may also be reaching the torque limit if the motor data in LF.11 - LF.19 is incorrect or if the encoder position in LF.77 is incorrect. -After the machine has been roped, the speed gains will need to be raised to control the motor. Typical starting values are LF.31 = 1200, LF.32 = 200 and LF.33 = 300. For Induction Motors also check: -The drive may also be reaching the torque limit if the motor data in LF.11 - LF.19 is incorrect or encoder ppr in LF.27 is incorrect.

Trouble Shooting

12.2 Drive Faults

Drive Fault	Cause	Solution
E.ENC1 Error Encoder	<ul style="list-style-type: none"> -A/B channels Incorrect -UVW phasing incorrect -Friction 	<ul style="list-style-type: none"> -Swap A and B encoder channels. Change LF.28 from a value of 0 to 1 or from 1 to 0, else from 2 to 3 or from 3 to 2, and relearn the encoder position. -Verify motor phasing U-U, V-V, W,W. -Verify that the brake is picking, otherwise check for excessive friction. Should be able to move sheave by hand.
E.OS Error Over Speed	<ul style="list-style-type: none"> -The measured speed was greater than 110% of the contract speed. -This can be an actual over speed event of the car -Encoder position incorrect: causes sheave to jerk briefly 	<ul style="list-style-type: none"> -Verify the motor data in LF.8...LF.19. A wrong frequency or speed value could cause the motor to spin too fast. -Verify the machine data in LF.20...LF.25. The wrong sheave diameter or gear ratio can lead to excessive motor speed. -Verify the ppr number in LF.27. A wrong value could also cause the motor to spin too fast. -Relearn encoder position.
E.br Error Low Current	<ul style="list-style-type: none"> -At the start of each run, the drive tests the motor current. If the current flowing in one or more phases is too low the test fails and E.br is triggered. -PM contactor damaged -The timing of the closing of the PM contactor to the enable and direction signals is wrong. -Loose connection between the drive and motor or loose connection in the drive. 	<ul style="list-style-type: none"> -Inspect the motor contactor for damage. -Check for loose connections at the motor/motor contactor. -Try to bypass the motor contactor. If the problem clears then the issue is the contactor.
E.OL Error Over Load	<p>The drive itself is overloaded. Greater than 105% of the drive's rated current is flowing for more than 30 seconds</p>	<ul style="list-style-type: none"> -Verify parameter settings, motor connections and the motor itself/ -Look for mechanical problems which would create a high friction load on the machine.
E.OL2 Error Low Speed Over Load	<p>This is a time dependent overload when the output frequency is below 3Hz and excessive current is drawn. When the drive is properly sized this should not be a problem. However if it is, there might be a mechanical cause.</p> <ul style="list-style-type: none"> -Incorrect motor data 	<ul style="list-style-type: none"> -Check for brake over lap or other condition that would result in high motor load during starting. -Lower the carrier frequency to 8kHz, LF.38=0. -Verify correct motor data; In particular LF.11 = LF.13 x 120 motor poles

Drive Fault	Cause	Solution
E.OH Error Over Heat	Heatsink temp of the drive is too high.	<p>-Verify the heatsink temp in parameter ru.38. Under normal operation it should be below 65°C.</p> <p>-Make sure there is adequate air flow through drive's heatsink.</p> <p>-Check for clogged fans or inoperative fans (when heatsink temp is above 45°C all fans should be running).</p>
E.OH2 Error Electronic Motor Overload	The average current flowing to the motor exceeds the setting of parameter LF.12. This parameter should be adjusted to the rated FLA name plate current of the motor.	<p>-Check the motor phase current in LF.93, if the average current is above the FLA of the motor then there could be an adjustment problem or a mechanical load problem.</p> <p>-Verify all motor data and check parameters LF.8 - LF.19.</p> <p>-Check to be sure the encoder is functioning. The motor rpm in LF.89 should be equal to LF.88.</p> <p>-Check for mechanical loading problems.</p>
E.OP Error Over Voltage	<p>-This error occurs whenever the DC bus voltage rises above 800V for 460V and 400V for 230V units.</p> <p>-If the fault is triggered while the unit is sitting idle the problem is voltage spikes on the main line.</p> <p>-If the fault occurs while the unit is in braking resistors.</p>	<p>-Verify the input voltage to the drive. Also look at LF.94 and LF.95 to read the actual and peak DC bus voltage. With 480VAC input the DC bus should be around 675VDC and with 230VAC around 325VDC. A higher factor may indicate severe harmonic distortion on the AC line.</p> <p>-Install a 5% line reactor on the main line in front of the drive to filter out the spikes. Note: an isolation transformer will now reduce these spikes. They will pass through the transformer.</p> <p>-Check the connection of the braking resistors and the resistance of the resistor assembly. If the resistance is too high, the drive can not dissipate the overhauling energy and the voltage will rise up to the limit.</p>
E.hyb Error Encoder Card	The control card is reading an invalid ID code from the encoder card.	Encoder card is damaged. Replace the encoder card. If the problem persists, damage was done to the control card as well therefore replace it as well.
E.hybC Error Encoder Card Change	This error indicates the encoder card has been changed since the last power on. This normally happens when installing a new encoder card.	To manually clear this error, go to parameter 0.LF.26 and re-enter the existing value to confirm the change.
E.UP Error Under Voltage	-The DC bus voltage is too low or there is more than 2% imbalance phase to phase on the main line.	<p>-Verify the input voltage.</p> <p>-Check for main line blown fuses. The phase to phase voltages should be within 2% of each other. Greater than 2% will result in damage to the drive.</p>

Trouble Shooting

Drive Fault	Cause	Solution
<p>E.OC Error Over Current</p>	<p>This error occurs whenever there is a phase to phase short or phase to ground short.</p> <p>-Typically it can be triggered by an internal short in the motor, i.e. punch through of the winding insulations either phase to phase or phase to ground.</p> <p>-Another cause for E.OC is an electrical noise problem normally associated with bad grounding of the drive and controller.</p> <p>-Damaged or burned contacts on the motor contactor can also cause this error to occur.</p> <p>-There could be a short in the braking resistor assembly.</p> <p>-If E.OC occurs every time the drive is in run, and even when the motor leads are disconnected (open loop-induction only), the problem is a blown power transistor.</p>	<p>-Check the motor winding with a megger. Look for damaged wires connecting the motor to the controller.</p> <p>-Check all ground connections between drive, motor, controller and the main supply. Make sure there is a solid ground connection going all the way back to the main distribution/fuse panel in the building.</p> <p>-Inspect the motor contactor for damage, replace as needed.</p> <p>-Check for shorts to ground or a total resistance value below the acceptable limit.</p> <p>-Power transistor is defective. Replace the drive.</p>
<p>E.PuCh Error Power Unit Code Changed</p>	<p>The control card is reading a different power stage ID number. This typically happens when the control card is installed in a different sized or voltage drive.</p>	<p>To manually clear this error, go to parameter US.27 and re-enter the existing value to confirm the change.</p>
<p>E.PuCI Error Power Unit Code Invalid</p>	<p>The control card is reading a different power stage ID number which is not valid.</p>	<p>Turn off the power, unplug the ribbon cable from the power stage to the control stage, and then plug it back in and power the unit up again. If the error persists, replace the drive.</p>
<p>bbL</p>	<p>This is not an error. It is a status in which the power transistors are blocked. This status precedes all faults and can also be triggered if the enable signal is dropped while the motor is running. It is a normal system function.</p>	<p>None</p>

A.1 Parameter List Reference



Para.	Name	E	R	Res.	Lower Limit	Upper Limit	Default	Unit	
LF.2	Signal/Operating Mode	E	R/W	1	1	7	7	text	
LF.3	Drive Configuration	E	R/W	1	0	5	2	text	
LF.4	Selected Motor	E	R	1	0	4	-	text	
LF.5	Drive Fault Auto Reset	E	R/W	1	0	10	5	-	
LF.8	Electronic Motor Overload Protection	E	R/W	1	0	1	0	text	
LF.9	Electronic Motor Overload Current	E	R/W	0.1	1	110%Rtd	8	A	
LF.10	Rated Motor Power	E	(IM)	R/W	0.1	0.5	125	5	hp
			(PM)	R	0.1	0.5	125	5	hp
LF.11	Rated Motor Speed	E	R/W	0.1	10	6000 (500.0)	1165 (150.0)	rpm	
LF.12	Rated Motor Current	E	R/W	0.1	1	110%Rtd	8	A	
LF.13	Rated Motor Frequency	E	R/W	0.1	4	200 (50.0)	60 (50.0)	Hz	
LF.14	Rated Motor Voltage	E	R/W	1	120	500	230/460	V	
	Voltage Constant ke	E		1	1	32000	1	V @ rated rpm	
LF.15	Power Factor	E	R/W	0.01	0.5	1	0.9	-	
LF.16	Field Weakening Speed	E	R/W	0.5	1	6000.0 (500.0)	960.0 (100.0)	rpm	
LF.17	Rated Motor Torque	E	(IM)	R				lb ft	
			(PM)	R/W	1	1	10000	18	
LF.18	PM Motor Resistance	E	R/W	0.001	0	49.99	1.00	ohms	
LF.19	PM Motor Inductance	E	R/W	0.01	0.01	500	10.0	mH	
LF.20	Contract Speed	E	R/W	1	0	1600	0	ft/min	
LF.21	Traction Sheave Diameter	E	R/W	0.01	7	80	24	inches	
LF.22	Gear Reduction Ratio	E	R/W	0.01	1	240	30	-	
LF.23	Roping Ratio	E	R/W	1	1	8	1	-	
LF.24	Load Weight	E	R/W	1	0	30000	0	lb	
LF.25	Estimated Gear Reduction		R	0.01	0	655.35	-	-	
0.LF.26	Encoder Interface	E	R	1	0	32	1	-	
1.LF.26	Encoder Interface	E	R	1	0	32	1	-	
2.LF.26	Encoder Interface	E	R	1	0	256	1	-	
3.LF.26	Encoder Interface	E	R/W	1	0	2	1	-	
LF.27	Encoder Pulse Number	E	R/W	1	256	16384	1024	ppr	
LF.28	Encoder Channel Swap / Direction	E	R/W	1	0	3	0	-	
LF.29	Encoder Sample Rate	E	R/W	1	0.5	32	4	mS	
LF.30	Control Mode	E	R/W	1	0	4	0:IM, 2:PM	-	
A.LF.31	KP Speed (accel)	E	R/W	1	1	50396	3000	-	
d.LF.31	KP Speed (decel)	E	R/W	1	1	50396	3000	-	
P.LF.31	KP Speed (Synth. Pre-Torque)	E	R/W	1	1	50396	2000	-	
A.LF.32	KI Speed (accel)	E	R/W	1	1	26214	350	-	
d.LF.32	KI Speed (decel)	E	R/W	1	1	26214	250	-	
P.LF.32	KI Speed (Synth. Pre-Torque)	E	R/W	1	1	26214	10000	-	
A.LF.33	KI Speed Offset (accel)	E	R/W	1	0	8000	3000	-	
d.LF.33	KI Speed Offset (decel)	E	R/W	1	0	8000	1000	-	
0.LF.36	Maximum Torque	E	R/W	1	0	23590	3xLF17 : IM 1.5xLF17 : PM	lbft	
1.LF.36	Maximum Torque Emergency Operation	E	R/W	1	0	23590	LF17	lbft	

Parentheses designate value in gearless modes

Parameter List Reference

Para.	Name	E	R	Res.	Lower Limit	Upper Limit	Default	Unit
LF.37	Open Loop Torque Boost	E	R/W	0.1	0	25.5	5	%
LF.38	Switching Frequency	E	R/W	1	0	1	0	-
LF.41	Leveling Speed	E	R/W	0.1	0	16%ofLF20	0	ft/min
LF.42	High Speed	E	R/W	0.1	0	LF.20	0	ft/min
LF.43	Inspection Speed	E	R/W	0.1	0	150 or LF20 whichever is lower	0	ft/min
LF.44	High Leveling Speed	E	R/W	0.1	0	25%ofLF20	0	ft/min
LF.45	Earthquake Speed	E	R/W	0.1	0	150	0	ft/min
LF.46	Emergency Generator Speed	E	R/W	0.1	0	100%ofLF20	0	ft/min
LF.47	Intermediate Speed	E	R/W	0.1	0	100%ofLF20	0	ft/min
0.LF.50	Starting Jerk	E	R/W	0.01	0.3 or calc. min.	32.00: off	3.0	ft/s ³
0.LF.51	Acceleration	E	R/W	0.01	0.3	12.00: off	3.3	ft/s ²
0.LF.52	Acceleration Jerk	E	R/W	0.01	0.3 or calc. min.	32.00: off	4.0	ft/s ³
0.LF.53	Deceleration Jerk	E	R/W	0.01	0.3 or calc. min.	32.00: off	4.5	ft/s ³
0.LF.54	Deceleration	E	R/W	0.01	0.3	12.00: off	3.5	ft/s ²
0.LF.55	Approach Jerk	E	R/W	0.01	0.3 or calc. min.	32.00: off	2.5	ft/s ³
LF.56	Stop Jerk	E	R/W	0.01	0.3	32.00: off	2.0	ft/s ³
LF.57	Speed Following Error	E	R/W	1	0	1	1	text
LF.58	Speed Difference	E	R/W	1	0	30	10	%
LF.59	Following Error Timer	E	R/W	0.1	0	1	1	sec
LF.61	Emergency Operation Mode	E	R/W	1	0	4	0	text
LF.67	Pre-torque Gain	E	R/W	0.01	0.25	2	1	-
LF.68	Pre-torque Offset	E	R/W	0.1	-100	100	0	%
LF.69	Pre-torque Direction	E	R/W	1	-1	1	1	-
LF.70	Speed Pick Delay	E	R/W	0.1	0	3	0.3	s
LF.71	Brake Pick Delay	E	R/W	0.1	0	3	0.05	s
LF.76	Encoder Resolution Multiplier	E	R/W	1	0	13	2	-
LF.77	Absolute Encoder Position	E	R/W	1	0	65535	0	-
LF.78	Brake Engage Time	E	R/W	0.01	0	3	0.5	s
LF.79	Current Hold Time	E	R/W	0.1	0.1	3	0.3	s
LF.80	Software Version		R				1.61	-
LF.81	Software Date		R					-
LF.82	X2-Input State		R	Table				-
LF.83	X2-Output State		R	Table				-
LF.86	Operation Phase		R	1	0	7		-
LF.87	Inverter Load		R	1				%
LF.88	Motor Command Speed		R	0.1				rpm
LF.89	Actual Motor Speed		R	0.1				rpm
LF.90	Actual Elevator Speed		R	1				ft/min
LF.93	Actual Phase Current		R	0.1				A
LF.94	Peak Phase Current		R	0.1				A
LF.95	Actual DC Bus Voltage		R	1				V
LF.96	Peak DC Bus Voltage		R	1				V
LF.97	Actual Output Frequency		R	0.1				Hz
LF.98	Last Fault		R	Table				
LF.99	Inverter State		R	Table				

Parameter List Reference



Para.	Name	E	R	Res.	Lower Limit	Upper Limit	Default	Unit
LP.1	Position Control	E	R/W	1	0:off	2 : P onE	0	-
LP.2	Min. Slowdown Distance		R	0.1	0.0	200.0	0.0	inches
LP.3	Slowdown Distance		R	0.1	0.0	200.0	0.0	inches
LP.4	Correction Distance	E	R/W	0.1	0.0	200.0	0.0	inches
LP.12	Current Position		R	0.1	0.0	9999.9	0.0	inches
LP.21	Scaling Increments High	E	R/W	1	0	9999	0	-
LP.22	Scaling Increments Low	E	R/W	1	0	9999	0	-
LP.23	Scaling Distance	E	R/W	0.1	0.0	999.9	0	inches

Para.	Name	E	R/W	Res.	Lower Limit	Upper Limit	Default	Unit
US.00	Operator application		R	1	-	-	-	-
US.01	Password	E	R/W	1	0	9999	660	-
US.03	Load Defaults	E	R/W	1	1	1	0:bdPAS	-
US.04	Load Configuration	E	R/W	1	1	1	0:bdPAS	-
US.10	Select Configuration	E	R/W	1	0	4	1	text
US.16	E.OL2 Function	E	R/W	1	0	255	0	-
US.17	Pre - Torque Timer Ramp Up	E	R/W	0.01	0.00	32.00	0.30	sec
US.18	Pre - Torque Timer Ramp Down	E	R/W	0.01	0.00	32.00	0.10	sec
US.20	Max. Speed for Max. KI	E	R/W	1	0	1600	8	fpm
US.21	Speed for Min. KI	E	R/W	1	0	1600	24	fpm
US.22	Speed Dependent KP Gain	E	R/W	1	0	1	0	-
US.23	Min KP Gain at High Speed	E	R/W	1	0	50396	1000	-
US.24	KD speed gain	E	R/W	1	0	5000	0	-
US.25	Phase Current Check	E	R/W	1	0	4	3	-
US.26	Encoder Diagnostic	E	R	1	0	255	-	-
US.27	Power Unit Code	E	R/W	1	0	255	-	-
US.28	Analog Input Noise Clamp	E	R/W	0.1	-2.5	2.5	0.1	%
US.29	HSP5 Watchdog Time	E	R/W	0.01	0.0 = oFF	10.00	1.00	Sec
US.33	EdOH function	E	R/W	1	0 = off	1 = on	0	-
US.34	Analog Pattern Gain	E	R/W	0.01	0.01	20.00	1.00	-
US.35	Reference Splitting	E	R/W	1	0 (off)	200	0	mSec
US.37	Function Test	E	R/W	1	0 (off)	1	0	-

Parameter List Reference


Para.	Name	E	R	Res.	Lower Limit	Upper Limit	Default	Unit
d0.82	Output X2A.24...26	E	R/W	1	0	6	2	-
d0.83	Output X2A.27...29	E	R/W	1	0	6	3	-

Para.	Name	E	R	Res.	Lower Limit	Upper Limit	Default	Unit
Ld.18	Field Weakening Corner	E	R/W	0.1	0.0	6000.0	83% of LF.11	rpm
Ld.19	Field Weakening Curve	E	R/W	0.01	0.01	2.00	1.20	-
Ld.20	Stator Resistance	E	R/W	0.001	0.001	50.000	1.000	ohms
Ld.21	Sigma Inductance	E	R/W	0.01	0.01	500.00	10.00	mH
Ld.22	Rotor Resistance	E	R/W	0.001	0.001	49.9999	1.000	ohms
Ld.23	Mag. Inductance	E	R/W	0.1	0.1	3276.7	100.0	mH
Ld.24	Motor Control	E	R/W	1	0	255	8	-
Ld.25	Vmax Regulation	E	R/W	1	0	110	97	%
Ld.27	KP Current	E	R/W	1	0	32767	1500	-
Ld.28	KI Current	E	R/W	1	0	32767	500	-
Ld.29	Acceleration torque	E	R/W	1	0	32767	0	Nm
Ld.30	System Inertia	E	R/W	1	0	1073741823	0	kgcm ²
Ld.31	FFTC Filter	E	R/W	1	0	9	0	-
Ld.32	FFTC Gain	E	R/W	0.1	0.0	200.0	0.0	%
Ld.33	Torque Command Filt.	E	R/W	1	0	10	0	-

A.2 Customer Parameter Values



Para.	Name	Customer Value	Unit	Motion 4000 Default	PTC Default	iControl / IMC Default
LF.2	Signal/Operating Mode			S PoS	BnSPd	A SPd
LF.3	Drive configuration			run	run	run
LF.4	Selected Motor			ICLSd or PgL5S	ICLSd or PgL5S	ICLSd or PgL5S
LF.5	Drive Fault Auto Reset			5	5	5
LF.8	Electronic Motor Overload Protection			on	on	on
LF.9	Electronic Motor Overload Current		A			
LF.10	Rated Motor Power		hp			
LF.11	Rated Motor Speed		rpm			
LF.12	Rated Motor Current		A			
LF.13	Rated Motor Frequency		Hz			
LF.14	Rated Motor Voltage		V			
	Voltage Constant ke			<i>measured</i>	<i>measured</i>	<i>measured</i>
LF.15	Power Factor		-			
LF.16	Field Weakening Speed		rpm			
LF.17	Rated Motor Torque		lb ft			
LF.18	PM Motor Resistance		ohms	<i>measured</i>	<i>measured</i>	<i>measured</i>
LF.19	PM Motor Inductance		mH	<i>measured</i>	<i>measured</i>	<i>measured</i>
LF.20	Contract Speed		ft/min			
LF.21	Traction Sheave Diameter		inches			
LF.22	Gear Reduction Ratio		-			
LF.23	Roping Ratio		-			
LF.24	Load Weight		lb			
LF.27	Encoder Pulse Number		ppr	1024 or 2048	1024 or 2048	1024 or 2048
LF.28	Encoder Channel Swap / Direction		-	0	0	0
LF.29	Encoder Sample Rate		mS	4	4	4
LF.30	Control Mode		-	2	2	2
A.LF.31	KP Speed (accel)		-	3000	3000	3000
d.LF.31	KP Speed (decel)		-	3000	3000	3000
P.LF.31	KP Speed (Pre-Torque)		-	200 / 2000 ¹⁾	200 / 2000 ¹⁾	200 / 2000 ¹⁾
A.LF.32	KI Speed (accel)		-	350	350	350
d.LF.32	KI Speed (decel)		-	250	250	250
P.LF.32	KI Speed (Pre-Torque)		-	400 / 10000 ¹⁾	400 / 10000 ¹⁾	400 / 10000 ¹⁾
A.LF.33	KI Speed Offset (accel)		-	3000	3000	3000
d.LF.33	KI Speed Offset (decel)		-	1000	1000	1000

 Shaded boxes have job specific default values from the factory.
 1) analog pre-torque (LF.30 = 3) / synthetic pre-torque (LF.30 = 5)


Customer Parameter Values

Para.	Name	Customer Value	Unit	Motion 4000 / PTC Default	iControl / IMC Default
0.LF.36	Maximum Torque		lbft	<i>calculated</i>	<i>calculated</i>
1.LF.36	Max.Torq. (emergency)		lbft	<i>calculated</i>	<i>calculated</i>
LF.37	Open Loop Torque Boost		%	5	5
LF.38	Switching Frequency		-	0 or 1	0 or 1
LF.41	Leveling Speed		ft/min	4	0
LF.42	High Speed		ft/min		
LF.43	Inspection Speed		ft/min	35	0
LF.44	High Leveling Speed		ft/min	18	0
LF.45	Earthquake Speed		ft/min	0	0
LF.46	Emergency Gen. Speed		ft/min	0	0
LF.47	Intermediate Speed		ft/min	0 (200 on PTC)	0
0.LF.50	Starting Jerk		ft/s ³	3.00	OFF
0.LF.51	Acceleration		ft/s ²	3.50	OFF
0.LF.52	Acceleration Jerk		ft/s ³	4.00	OFF
0.LF.53	Deceleration Jerk		ft/s ³	4.50	OFF
0.LF.54	Deceleration		ft/s ²	3.50	OFF
0.LF.55	Approach Jerk		ft/s ³	2.50	OFF
1.LF.50	Starting Jerk		ft/s ³	3.50	OFF
1.LF.51	Acceleration		ft/s ²	3.50	OFF
1.LF.52	Acceleration Jerk		ft/s ³	4.50	OFF
1.LF.53	Deceleration Jerk		ft/s ³	5.50	OFF
1.LF.54	Deceleration		ft/s ²	3.50	OFF
1.LF.55	Approach Jerk		ft/s ³	3.50	OFF
2.LF.50	Starting Jerk		ft/s ³	1.50	OFF
2.LF.51	Acceleration		ft/s ²	1.50	OFF
2.LF.52	Acceleration Jerk		ft/s ³	1.50	OFF
2.LF.53	Deceleration Jerk		ft/s ³	1.50	OFF
2.LF.54	Deceleration		ft/s ²	1.50	OFF
2.LF.55	Approach Jerk		ft/s ³	1.50	OFF
LF.56	Stop Jerk		ft/s ³	2.00	OFF
LF.57	Speed Following Error			on	on
LF.58	Speed Difference		%	10	10
LF.59	Following Error Timer		sec	1.0	1.0



Shaded boxes have job specific default values from the factory.

Para.	Name	Customer Value	Unit	M 4000 / PTC Default	iControl / IMC Default
LF.61	Emergency Operation Mode		-	off	off
LF.67	Pre-torque Gain		-	1.00	1.00
LF.68	Pre-torque Offset		%	0.00	0.00
LF.69	Pre-torque Direction		-	0	0
LF.70	Speed Pick Delay		s	0.30	0.30
LF.71	Brake Pick Delay		s	0.2	0.05
LF.76	Encoder Resolution Multiplier		-	2 (8) ¹⁾	2 (8) ¹⁾
LF.77	Absolute Encoder Position		-	<i>measured</i>	<i>measured</i>
LF.78	Brake Engage Time		s	0.45	0.5
LF.79	Current Hold Time		s	0.2	0.3
LF.80	Software Version		-	1.61	1.61
LF.81	Software Date		-		

 Shaded boxes have job specific default values from the factory.
1) 8 for PM gearless motors

Para.	Name	Customer Value	Unit	M 4000 / PTC Default	iControl / IMC Default
LP.1	One Floor Positioning		-	off	off
LP.2	Maximum Slowdown Distance		in	<i>calculated</i>	<i>calculated</i>
LP.3	Slowdown Distance		in	<i>measured</i>	<i>measured</i>
LP.4	Correction Distance		in	0.0	0.0
LP.12	Current Position		in	<i>measured</i>	<i>measured</i>
LP.21	Scaling Increments High		-	<i>calculated</i>	<i>calculated</i>
LP.22	Scaling Increments Low		-	<i>calculated</i>	<i>calculated</i>
LP.23	Scaling Distance		in	<i>calculated</i>	<i>calculated</i>

Advanced Parameters

Para.	Name	Customer Value	Unit
US.16	E.OL2 function		-
US.17	Pre - Torque Timer ramp up		sec
US.18	Pre - Torque Timer ramp dwn		sec
US.20	Max Speed for Max KI		fpm
US.21	Speed for Min KI		fpm
US.22	Speed Dependent KP Gain		-
US.23	Min KP Gain at High Speed		-
US.24	KD speed gain		-
US.25	Phase Current Check		-
US.26	Encoder Diagnostic		-
US.27	Power Unit Code		-
US.28	Analog Input Noise Clamp		%
US.29	HSP5 Watchdog Time		mS
US.33	EdOH function		-
US.34	Analog Pattern Gain		-
US.35	Reference Splitting		mSec
US.37	Function Test		-

Digital I/O Handling

Para.	Name	Customer Value	Unit
do.82	Output X2A.24...26		-
do.83	Output X2A.27...29		-

Advanced Drive Data

Para.	Name	Customer Value	Unit
Ld.18	Field Weakening Corner		rpm
Ld.19	Field Weakening Curve		-
Ld.20	Stator Resistance		ohms
Ld.21	Sigma Inductance		mH
Ld.22	Rotor Resistance		ohms
Ld.23	Mag. Inductance		mH
Ld.24	Motor Control		-
Ld.25	Vmax Regulation		%
Ld.27	KP Current		-
Ld.28	KI Current		-
Ld.29	Acceleration Torque		Nm
Ld.30	System Inertia		kgcm ²
Ld.31	FFTC Filter		-
Ld.32	FFTC Gain		%
Ld.33	Torque Command Filt.		-

© MCE

Mat. No.	00PC0UB-K171
Rev.	1B
Date	05/2010